Nespresso EN640B

Nespresso Gran Lattissima by De'Longhi

Instruction Manual - Model EN640B

Introduction

Welcome to the world of Nespresso Gran Lattissima. This machine is designed to provide you with a wide range of coffee and milk-based beverages with ultimate convenience. Its intuitive design and advanced features ensure a perfect cup every time. Please read this manual carefully to ensure proper use, maintenance, and to fully enjoy your new coffee machine.

Product Overview

The Nespresso Gran Lattissima combines the precision of Nespresso capsule brewing with an innovative fresh milk system. Key features include:

- **One-Touch Operation:** Prepare 9 different coffee and milk recipes at the touch of a button.
- **Patented Fresh Milk System:** Easily prepare frothed milk for lattes and cappuccinos. The milk container is removable and can be stored in the refrigerator.
- **Fast Heat-Up:** Ready to brew in approximately 25 seconds.
- **19-Bar High-Performance Pump:** Ensures optimal extraction of coffee aromas and a dense crema.
- **Intuitive Descaling System:** Programmable based on water hardness.
- **Energy Saving Function:** Automatic shut-off after 9 minutes of inactivity (programmable).
- **Dishwasher Safe Parts:** Removable components are easy to clean.



Front view of the Nespresso Gran Lattissima machine with a prepared espresso.


DēLonghi
descale
rinse
lungo
hot foam
hot milk
espresso
latte macchiato
caffè latte
ristretto
cappuccino
flat white
remove to clean
rinse
milk

The control panel with one-touch beverage selection buttons.



The machine showcasing its milk container and various coffee capsules.

Setup

1. **Unboxing:** Carefully remove all packaging materials and place the machine on a stable, flat surface.
2. **Rinse Water Tank:** Before first use, rinse the water tank with fresh drinking water and fill it to the MAX level.
3. **Power On:** Plug the machine into a grounded power outlet. Press the Power button to turn on the machine. The buttons will blink as the machine heats up.

4. **First Rinse Cycle:** Place a container under the coffee outlet. Press any coffee button to start a rinse cycle. Repeat this process 2-3 times to clean the internal system.
5. **Milk System Assembly:** Attach the milk container to the machine. Ensure it is securely connected.


NESPRESSO
max

Top view showing the milk container and capsule insertion area.

Operating Instructions

Making Coffee (without milk)

1. Ensure the water tank is filled with fresh water.
2. Lift the lever and insert a Nespresso Original Line capsule. Close the lever.
3. Place your cup on the drip tray. Adjust the sliding drip tray for different cup sizes.
4. Select your desired coffee: Ristretto, Espresso, or Lungo by pressing the corresponding button. The machine will automatically brew and stop.

Making Milk-Based Beverages

1. Fill the milk container with fresh milk up to the MAX level indicator.
2. Attach the milk container to the machine.
3. Lift the lever and insert a Nespresso Original Line capsule. Close the lever.
4. Place your cup on the drip tray.
5. Select your desired milk-based beverage: Cappuccino, Latte Macchiato, Cafe Latte, Flat White, Foamed Milk, or Hot Milk by pressing the corresponding button. The machine will first froth and dispense milk, then brew the coffee.
6. After each milk preparation, turn the milk system knob to the 'Rinse' position to clean the milk spout.



Side view demonstrating the brewing process.



Visual guide to one-touch operation, milk system, and rinsing.



Examples of various cup options and coffee types.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your Nespresso Gran Lattissima.

- **Daily Cleaning:** After each milk preparation, perform the automatic rinse cycle for the milk system. Empty and rinse the drip tray and used capsule container daily.

- **Milk Container:** The milk container and its components are dishwasher safe. For manual cleaning, disassemble and wash with warm water and mild detergent.
- **Water Tank:** Rinse the water tank regularly with fresh water.
- **Descaling:** The machine has an intuitive descaling system. The 'Descaling' indicator light will illuminate when descaling is required. Follow the instructions in the full user manual for the descaling procedure.
- **Exterior:** Wipe the machine's exterior with a soft, damp cloth. Do not use abrasive cleaning agents or immerse the machine in water.

Troubleshooting

If you encounter issues with your machine, please refer to the following common solutions:

- **No Coffee Flow:** Check if the water tank is filled, if a capsule is correctly inserted, or if the machine needs descaling.
- **Milk Not Frothing:** Ensure the milk container is clean and properly assembled. Use cold, fresh milk. Check if the milk spout is clear.
- **Leaking:** Verify that the water tank and drip tray are correctly positioned.
- **Machine Not Turning On:** Check the power connection and the power outlet.

For more detailed troubleshooting steps or specific error codes, please consult the comprehensive user manual provided with your machine or visit the Nespresso support website.

Specifications

Brand	Nespresso
Model Name	Gran Lattissima
Model Number	EN640B
Color	Black
Product Dimensions	7.9"D x 14.4"W x 10.8"H
Item Weight	9.2 pounds
Pump Pressure	19 Bar
Coffee Input Type	Capsules
Operation Mode	Fully Automatic
Special Features	Auto Shut-Off, Milk Frother, Self-Priming System, One-Button Operation



Product dimensions for placement and planning.

Warranty and Support

Your Nespresso Gran Lattissima machine is covered by a manufacturer's warranty. For specific details regarding

the warranty period and terms, please refer to the warranty card included in your product packaging or visit the official Nespresso website.

For technical assistance, troubleshooting, or to order accessories and descaling kits, please contact Nespresso Customer Service. You can find contact information on the Nespresso website or in your product documentation.

Return Policy: This product is subject to a 30-day return policy for refund or replacement, as per the retailer's terms.

Protection Plans: Extended protection plans are available for purchase to cover your machine beyond the standard manufacturer's warranty. Options include 3-Year and 4-Year Protection Plans, as well as a monthly Complete Protect plan.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question