Whirlpool SW ROYAL PLUS 7.5 (H)

Whirlpool 7.5 Kg 5 Star StainWash Royal Plus Fully Automatic Top Load Washing Machine User Manual

Model: SW ROYAL PLUS 7.5 (H)

1. Introduction

This manual provides essential information for the safe and efficient operation of your new Whirlpool 7.5 Kg 5 Star StainWash Royal Plus Fully Automatic Top Load Washing Machine. Please read this manual thoroughly before using the appliance and keep it for future reference. Proper use and maintenance will ensure optimal performance and longevity of your washing machine.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the washing machine is properly grounded.
- Do not operate the machine with a damaged power cord or plug.
- Keep flammable materials away from the appliance.
- Do not allow children to play on or in the appliance.
- Unplug the machine before performing any maintenance or cleaning.
- Do not wash items that are soiled with cooking oils, gasoline, or other flammable substances.
- Ensure water inlet and drain hoses are securely connected to prevent leaks.

3. Product Overview

The Whirlpool StainWash Royal Plus is a fully automatic top-load washing machine designed for efficient and thorough cleaning. Key features include an in-built heater for stain removal and sanitization, multiple wash programs, and advanced wash technologies.



Front view of the Whirlpool 7.5 Kg StainWash Royal Plus Fully Automatic Top Load Washing Machine, highlighting the 'In-Built Heater Stainwash' feature.

Key Features:

- **In-Built Heater:** Removes up to 50 tough stains and sanitizes clothes with 3 hot water modes. Effective on stains up to 48 hours old.
- **5 Star Energy Rating:** Ensures best-in-class energy efficiency.
- **7.5 Kg Capacity:** Suitable for small to medium-sized families.
- **Spiro Wash Technology:** Provides a thorough and powerful wash action.
- **ZPF Technology:** Zero Pressure Fill technology for faster tub filling even with low water pressure.
- **Hard Water Wash Program:** Specifically designed to optimize wash performance in hard water conditions.
- **Auto Tub Clean:** Automatically cleans the wash tub to maintain hygiene.
- **Express Wash:** For quick washing cycles.
- **Delay Wash:** Allows you to set a delayed start time for your wash cycle.
- **Max 740 RPM:** Higher spin speeds for faster drying.



Visual representation of key features including the in-built heater, multiple hot modes, germ removal, 6th Sense Technology, and stain removal capabilities.

4. Setup and Installation

Proper installation is crucial for the performance and safety of your washing machine. It is recommended to have the appliance installed by a qualified technician.

Items Included in Box:

- 1 Washing Machine Unit
- User Manual
- Warranty Card
- Inlet Pipe
- Detergent Cup
- Rat Mesh
- Drain Pipe
- Drain Hose with Clamp

Installation Steps (General Guidelines):

1. **Unpacking:** Carefully remove all packaging materials. Inspect the machine for any damage.
2. **Location:** Place the washing machine on a firm, level surface. Ensure there is adequate space around the machine for ventilation and access.
3. **Leveling:** Adjust the leveling feet at the bottom of the machine to ensure it is stable and perfectly level. This prevents excessive vibration and noise during operation.
4. **Water Connection:** Connect the inlet pipe to a cold water tap and to the water inlet valve on the back of the machine. Ensure connections are tight to prevent leaks.
5. **Drainage:** Securely attach the drain hose to the drain outlet at the back of the machine and route it to a suitable drain pipe or sink. Ensure the drain hose is not kinked or blocked.
6. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the machine's requirements (240 Volts).

Diagram showing the product dimensions (58D x 54W x 101H Centimeters) and the 5-star energy savings guide.

5. Operating Instructions

Follow these steps for basic operation of your washing machine.

Control Panel Overview:



Detailed view of the control panel, showing program selection, settings, and indicators.

Washing Procedure:

1. **Load Laundry:** Open the lid and place clothes loosely into the wash tub. Do not overload the machine.
2. **Add Detergent:** Add the appropriate amount of detergent to the detergent dispenser. For best results, use a high-efficiency (HE) detergent.
3. **Close Lid:** Ensure the lid is securely closed before starting a cycle.
4. **Select Program:** Turn the program selector knob or press the appropriate button on the control panel to choose your desired wash program (e.g., Daily, Heavy, Delicates, Stainwash).
5. **Adjust Settings (Optional):** Depending on the selected program, you may adjust settings such as water level, temperature (Hot, Warm, Allergen Free), or special features like Delay Wash or Express Wash.
6. **Start Cycle:** Press the 'Start/Pause' button to begin the wash cycle.



Illustration of additional features like Delay Start, Express Wash, and two drying modes.

6. Wash Programs

Your Whirlpool washing machine offers 12 wash programs to cater to various fabric types and soil levels. Refer to the control panel image for specific program names.

Common Programs and Features:

- **Daily:** For everyday laundry with normal soil.
- **Heavy:** For heavily soiled items like jeans or work clothes.
- **Delicates:** Gentle wash for delicate fabrics.
- **Stainwash:** Utilizes the in-built heater and specific wash actions to tackle tough stains.
- **Hard Water Wash:** Optimized for areas with hard water, ensuring better detergent dissolution and wash quality.
- **Hot Water Modes:** Select from Warm, Hot, or Allergen Free temperatures for enhanced cleaning and sanitization.



Visual highlighting of the Hard Water Wash feature, 12 available wash programs, and the Smart Sensor technology.

7. Maintenance and Care

Regular maintenance helps ensure the longevity and efficient operation of your washing machine.

Cleaning the Machine:

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- **Detergent Dispenser:** Clean the detergent dispenser regularly to prevent residue buildup.
- **Lint Filter:** Check and clean the lint filter after every few washes to ensure proper drainage and prevent lint transfer to clothes.
- **Auto Tub Clean:** Utilize the 'Auto Tub Clean' feature periodically to clean the inside of the wash tub and prevent odor buildup.

Long-Term Storage:

If the machine will not be used for an extended period, unplug it, turn off the water supply, and drain any remaining water from the hoses and tub.

8. Troubleshooting

Before contacting customer service, refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; Power outage.	Check power connection; Ensure lid is fully closed; Check household circuit breaker.
No water filling	Water tap off; Inlet hose kinked; Water pressure too low.	Open water tap; Straighten hose; Check water supply pressure.
Machine vibrates excessively	Machine not level; Load unbalanced; Shipping bolts not removed.	Adjust leveling feet; Redistribute laundry; Ensure all shipping bolts are removed.
Water not draining	Drain hose kinked or blocked; Drain pump filter clogged.	Check and clear drain hose; Clean drain pump filter.
Poor wash performance	Overloading; Incorrect detergent amount; Wrong wash program.	Reduce load size; Use correct detergent quantity; Select appropriate wash program.

If the problem persists after attempting these solutions, please contact Whirlpool customer support.

9. Specifications

Specification	Detail
Model	SW ROYAL PLUS 7.5 (H)
Capacity	7.5 Kilograms
Energy Efficiency	5 Star
Annual Energy Consumption	0.0099 KWh/kg/cycle

Specification	Detail
Maximum Rotational Speed	740 RPM
Product Dimensions (DxWxH)	58D x 54W x 101H Centimeters
Item Weight	32 kg
Material (Drum)	Stainless Steel
Controller Type	Fully Automatic
Special Features	Inbuilt Heater, Hard Water Wash, ZPF Technology, Express Wash, Delay Wash, Auto Tub Clean, Spiro Wash
Voltage	240 Volts
Manufacturer	Whirlpool of India Limited



Official Power Savings Guide indicating 5-star energy efficiency and consumption details.

10. Warranty and Support

Warranty Information:

Your Whirlpool washing machine comes with a **2 Years Comprehensive Warranty** and an additional **10 years warranty on the Motor & Prime Mover**. To avail of the brand warranty, please retain your purchase invoice.

Customer Support:

For service requests, technical assistance, or warranty claims, please contact Whirlpool customer support. Refer to the warranty card or the official Whirlpool website for contact details specific to your region.
Manufacturer: Whirlpool of India Limited, Plot No. A- 4, MIDC, Ranjangaon, Taluka- Shirur, Pune District, Maharashtra, India.

© 2024 Whirlpool. All rights reserved.