Ufesa 72805690

UFESA 72805690 Air Fryer Instruction Manual

Model: 72805690

1. Important Safety Instructions

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local mains voltage before connecting. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Hot Surfaces:** The appliance surfaces become hot during use. Always use oven mitts when handling hot components. Do not touch hot surfaces directly.
- **Ventilation:** Place the air fryer on a stable, heat-resistant surface, ensuring adequate space (at least 10 cm) around all sides for proper air circulation. Do not cover the air inlet or outlet vents.
- **Children and Supervision:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Power Cord:** Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces. Do not operate any appliance with a damaged cord or plug.
- **Unplugging:** Always unplug the appliance from the power outlet when not in use and before cleaning. Allow it to cool down completely before handling or storing.
- **Intended Use:** This appliance is for household use only. Do not use it outdoors or for commercial purposes.

2. Product Overview

The UFESA 72805690 Air Fryer is designed for healthy cooking with minimal to no oil. It features a touch control panel, 8 pre-set programs, and an interior light with a viewing window for monitoring your food.



Image 1: Front view of the UFESA 72805690 Air Fryer. This image displays the appliance with its digital touch control panel clearly visible, along with the viewing window on the front. The cooking basket is slightly ajar, providing a glimpse into the interior.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Cooking Basket/Drawer:** Removable for food placement and cleaning.
- **Control Panel:** Digital touch interface for setting time, temperature, and selecting programs.
- **Viewing Window:** Allows monitoring of food during cooking without opening the basket.
- **Interior Light:** Illuminates the cooking chamber for better visibility through the window.
- **Air Inlet/Outlet Vents:** For proper air circulation during operation.

3. Setup

1. **Unpacking:** Carefully remove the air fryer and all packaging materials from the box. Retain the packaging for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, clean the cooking basket and any removable accessories with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth.

3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface. Ensure there is at least 10 cm of clear space around the back and sides of the appliance, and above it, to allow for proper ventilation. Do not place it near flammable materials or heat sources.
4. **Power Connection:** Plug the European plug into a grounded electrical outlet. The appliance is now ready for use.

4. Operating Instructions

4.1 Before First Use

It is recommended to run the air fryer empty for about 10-15 minutes at 180°C (350°F) before cooking food for the first time. This helps to burn off any manufacturing residues and eliminate initial odors. A slight smell or smoke may occur, which is normal. Ensure the area is well-ventilated.

4.2 Control Panel Overview

The digital touch control panel allows you to adjust cooking settings. It typically includes:

- **Power Button:** To turn the appliance on/off.
- **Temperature Control:** Buttons to increase or decrease temperature.
- **Time Control:** Buttons to increase or decrease cooking time.
- **Program Selection:** Icons or buttons to choose from 8 pre-set cooking programs.
- **Start/Pause Button:** To begin or temporarily stop cooking.
- **Light Button:** To turn the interior light on/off.

4.3 General Cooking Steps

1. **Prepare Food:** Place your ingredients into the cooking basket. Do not overfill the basket to ensure even cooking. For best results, lightly toss food with a small amount of oil (optional).
2. **Insert Basket:** Slide the cooking basket firmly back into the main unit until it clicks into place.
3. **Power On:** Press the Power button to turn on the air fryer.
4. **Select Settings:**
    - **Manual Mode:** Use the temperature and time control buttons to set your desired cooking temperature and time.
    - **Pre-set Program:** Select one of the 8 pre-set programs. The appliance will automatically set a recommended temperature and time, which can usually be adjusted manually if needed.
5. **Start Cooking:** Press the Start button to begin the cooking cycle.
6. **Monitor Food:** Use the viewing window and interior light to check on your food. For even cooking, some foods may require shaking or turning halfway through the cooking time. The appliance may beep to remind you.
7. **Finish Cooking:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket using the handle.
8. **Serve:** Remove food from the basket using non-scratch utensils. Be cautious of hot steam.

4.4 Using the Viewing Window and Interior Light

The UFESA 72805690 Air Fryer is equipped with a transparent viewing window and an interior light. Press the dedicated light button on the control panel to illuminate the cooking chamber, allowing you to monitor the cooking progress without interrupting the cycle or losing heat by opening the basket. Press the button again to turn off the light.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Accessories:** The cooking basket and any removable accessories are dishwasher safe. Alternatively, wash them with warm water and a mild dishwashing detergent. Use a non-abrasive sponge to prevent damage to the non-stick coating. Rinse

thoroughly and dry completely.

3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residues, use a mild detergent and a soft brush. Ensure the interior is completely dry before next use.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads, as they can damage the finish.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store it in a cool, dry place.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; power button not pressed.	Check power cord connection; try a different outlet; press the power button firmly.
Food is not cooked evenly.	Basket is overfilled; food not shaken/turned; incorrect temperature/time.	Do not overfill the basket; shake or turn food halfway through cooking; adjust temperature and time as needed.
White smoke coming from the appliance.	Fat/oil residue from previous use; cooking fatty food.	Clean the basket and interior thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the drawer to prevent smoke.
Food is not crispy.	Too much moisture in food; not enough oil (optional); basket overfilled.	Pat food dry before cooking; lightly toss with oil; cook in smaller batches.

7. Specifications

Brand:	Ufesa
Model Number:	72805690
Power:	1700 Watts
Capacity:	65 Liters *(Note: Please verify actual cooking capacity as this value may refer to total internal volume.)*
Material:	Steel
Control Method:	Touch
Special Features:	Viewing Window, Interior Light, 8 Pre-set Programs, Dishwasher Safe Basket
Weight:	6.2 Kilograms
Dimensions (L x W x H):	Refer to product packaging for accurate dimensions. *(Note: Provided data for dimensions was inconsistent/placeholder.)*
Plug Type:	European Plug

8. Warranty and Support

For warranty information, technical assistance, or customer support, please refer to the warranty card included with your product or visit the official UFESA website. Keep your proof of purchase for any warranty claims.
Visit UFESA Official Website

© 2023 Ufesa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question