Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Karcher KB 5

Kärcher KB 5 Electric Floor Sweeper Broom User Manual

1. Introduction

The Kärcher KB 5 Electric Floor Sweeper Broom is designed for quick and efficient cleaning of various hard floors and low-pile carpets. This lightweight, cordless device offers convenient operation and easy maintenance, making it suitable for everyday cleanups.
Key features include multi-surface cleaning capability, quiet operation, simple maintenance, a flexible double joint for maneuverability, and a lightweight, transportable design.

2. Safety Instructions

- Read all instructions before using the appliance.
- Do not use the appliance on wet surfaces or to pick up liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Exercise extreme care when cleaning on stairs.
- Unplug from outlet when not in use and before servicing.

3. Package Contents

Verify that all items are present in the package:

- KB 5 Electric Floor Sweeper
- Charging Cable
- Docking Station

4. Setup

4.1 Assembly

The Kärcher KB 5 is designed for quick assembly. Simply connect the handle sections until they click into place. The handle features a flexible double joint for easy maneuverability.

4.2 Initial Charging

Before first use, fully charge the KB 5. Connect the charging cable to the docking station and plug it into a power outlet. Place the sweeper on the docking station. The charging indicator light will show the charging status. A full charge takes approximately 3 hours.

Video demonstrating the assembly and automatic start feature of the Kärcher KB 5 Electric Floor Sweeper.

5. Operating Instructions

5.1 Turning On/Off

The KB 5 features an automatic on/off function. Simply pull the handle back into the operating position to activate the sweeper. To turn it off, return the handle to the upright, central position.

5.2 Cleaning Surfaces

The KB 5 is suitable for various hard floors (wood, laminate, LVT, vinyl, tile) and low-pile carpets/rugs. Guide the sweeper across the desired surface to pick up dirt, dust, pet hair, and debris. The 8-inch rotating brush roll provides edge-to-edge cleaning.



Image: The Kärcher KB 5 Electric Floor Sweeper effectively cleaning a patterned carpet, demonstrating its multi-surface capability.



Image: The Kärcher KB 5 Electric Floor Sweeper easily reaching and cleaning under a piece of furniture, highlighting its flexible design.

Video showcasing the Kärcher KB 5 Electric Floor Sweeper in various cleaning scenarios, demonstrating its ease of use and effectiveness.

6. Maintenance

6.1 Emptying the Debris Cup

The debris cup is located on the side of the sweeper. To empty, simply slide it out, discard the collected dirt, and slide it back into place. This design ensures quick and easy emptying without direct contact with dirt.

6.2 Cleaning the Brushroll

The brushroll can be easily removed for cleaning. After removing the debris cup, the brushroll can be accessed and detached. Remove any tangled hair or debris, then reinsert the brushroll and debris cup.



Image: A hand demonstrating the easy removal and emptying of the debris container from the Kärcher KB 5 Electric Floor Sweeper.

Video illustrating the process of emptying the dust container and cleaning the brush of the Kärcher KB 5 Electric Floor Sweeper.

7. Troubleshooting

Problem	Possible Cause	Solution
Sweeper does not turn on	Battery is discharged; Handle not in operating position	Charge the battery; Tilt the handle back to activate
Poor cleaning performance	Debris cup full; Brushroll clogged; Battery low	Empty debris cup; Clean brushroll; Charge battery
Unusual noise during operation	Obstruction in brushroll; Damaged brushroll	Remove obstruction; Replace brushroll if damaged

8. Specifications

- **Brand:** Karcher
- **Model Name:** KB 5
- **Item Model Number:** 1.258-053.0
- **Power Source:** Battery Powered (Lithium-Ion)
- **Battery Life:** Up to 30 minutes
- **Charging Time:** 3 Hours
- **Item Weight:** 2.6 pounds
- **Product Dimensions:** 8.5"L x 9.1"W x 44.1"H
- **Noise Level:** 55 Decibels
- **Recommended Uses:** Floor Cleaning, Hard Floor Cleaning, Low Pile Carpet, Low Pile Rugs
- **Special Features:** Cordless, Edge-to-Edge Cleaning, Fold-Flat Handle, Handle Auto-Start, Pivoting Handle

9. Warranty and Support

The Kärcher KB 5 Electric Floor Sweeper Broom is backed by a 1-year limited warranty and an industry-leading rapid exchange program. For warranty claims, technical support, or further assistance, please refer to the official Kärcher support channels or visit the Kärcher Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN1NJ28K

More documents and user manuals: **https://manuals.plus/**