Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM FPSC5DRSC-SWT

T4TREAM Fluted 5-Drawer Dresser User Manual

Model: FPSC5DRSC-SWT

Brand: T4TREAM

Introduction

Welcome to your new T4TREAM Fluted 5-Drawer Dresser. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your furniture. Please read all instructions carefully before beginning assembly.

Safety Information

To prevent tipping, it is highly recommended to secure the dresser to a wall using the included anti-tip hardware. Always ensure the dresser is placed on a level surface. Keep small parts away from children during assembly.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact T4TREAM customer support.

- All wooden panels (labeled with serial numbers)
- 5 Drawer boxes
- Drawer slides
- Metal handles
- Splayed legs
- Anti-tip hardware
- Assembly hardware (screws, dowels, etc.)
- Spare parts pack

Assembly Instructions

Assembly typically requires two adults. A power screwdriver is recommended for efficiency. Follow the step-by-step instructions provided in the included assembly guide. Each component is meticulously labeled.

Tools Required

- Phillips Head Screwdriver (manual or power)
- Hammer (optional, for dowels)

Step-by-Step Assembly Overview

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify all parts using the provided labels.
2. Assemble the main frame of the dresser according to the diagrams. Ensure all connections are secure.
3. Attach the splayed legs to the base of the dresser. The innovative steel support at the base reinforces stability.
4. Install the drawer slides onto the dresser frame and the drawer boxes. Ensure smooth operation.
5. Assemble each of the five drawers. Insert the bottom panel and secure the sides.
6. Attach the chic metal handles to the front of each drawer.
7. Carefully insert the assembled drawers into the dresser frame.
8. Secure the dresser to the wall using the anti-tip hardware provided. This is a crucial safety step.



Figure 1: Product Dimensions and Drawer Capacity. This diagram illustrates the overall dimensions of the dresser (31.5"W x 15.75"D x 48"H) and the internal dimensions of each drawer (27.2"W x 12"D x 8"H). It also highlights the inclusion of feet metal plates for anti-tipping.



Figure 2: Drawer Storage Capacity. This image shows an open drawer, demonstrating its capacity to store items like folded T-shirts (20-25) or jeans (15-20). The faux marble top is also visible.

Operating Instructions

Your T4TREAM dresser is designed for ease of use and durability.

Drawer Operation

The five drawers feature smooth-glide mechanisms for effortless opening and closing. To open a drawer, gently pull the metal handle. To close, push the drawer firmly until it is fully seated. Avoid forcing drawers if they feel stiff; check for obstructions.



Figure 3: Smooth Sliding Drawers and Waterproof Top. This image highlights the smooth sliding mechanism of the drawers and the waterproof, easy-to-clean nature of the wide thickened tabletop.



Figure 4: Design and Structural Details. This image provides a closer look at the fluted panel design, the chic metal handles, the stable splayed support legs, and the steel reinforcement at the bottom for enhanced durability.

Maintenance

Proper care will extend the life and appearance of your dresser.

Cleaning

- Wipe the surface with a dry cloth to remove dust and light spills.
- For stubborn marks on the faux marble top, use a damp cloth with a mild, non-abrasive cleaner, then dry immediately.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.

General Care

- Avoid placing hot items directly on the faux marble top without a protective coaster.
- Do not expose the dresser to direct sunlight or extreme temperature changes, as this may cause warping or discoloration.
- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned slides, obstructions, or loose screws.	Check that drawer slides are correctly installed and aligned. Remove any obstructions. Tighten all screws on the slides and drawer boxes.
Dresser feels wobbly.	Uneven floor, loose connections, or anti-tip hardware not installed.	Ensure the dresser is on a level surface. Tighten all assembly screws. Install the anti-tip hardware to secure the dresser to the wall.
Parts missing or damaged upon arrival.	Shipping damage or packing error.	Do not proceed with assembly. Contact T4TREAM customer support immediately with your purchase details and a description of the issue.

Specifications

- **Brand:** T4TREAM
- **Model Name:** FPSC5DRSC-SWT
- **Product Dimensions:** 16"D x 32"W x 48"H
- **Drawer Internal Dimensions:** 27.2"W x 12"D x 8"H (approximate)
- **Color:** Solid White
- **Mounting Type:** Floor Mount
- **Room Type:** Bedroom, Living Room, Hallway, Entryway, Home Office
- **Special Features:** Fluted Panel Design, Faux Marble Top, Curved Profile, Blister Molding Surface, 5-Drawers Storage, Wood Splayed Legs, Steel Reinforced Base, 48" Tall
- **Furniture Finish:** White
- **Product Care Instructions:** Wipe with Dry Cloth
- **Assembly Required:** Yes
- **Materials:** FSC-Certified wood, optimal MDF, P2 engineered wood, melamine veneer

Warranty and Support

T4TREAM is committed to providing high-quality products. For any questions, concerns, or assistance with your dresser, please contact our customer support team.

While specific warranty details are not provided in this manual, please refer to your purchase documentation or the T4TREAM official website for warranty information.

For support, visit the official T4TREAM Store: T4TREAM Furniture Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN2SLGRB

More documents and user manuals: **https://manuals.plus/**