Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BWA18SB001

ZdalaMit Replacement Remote Control User Manual

For Blackweb Soundbar Model BWA18SB001

Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed specifically for the Blackweb Soundbar model BWA18SB001. This remote control requires no programming and is ready for use after battery installation. It is not a universal remote and is only compatible with the specified soundbar model.

Product Overview

The image below illustrates the layout and functions of the ZdalaMit Replacement Remote Control.





Image: ZdalaMit Replacement Remote Control. This image displays the full remote control with all its buttons clearly visible, including power, mute, input selections, playback controls, sound modes, and volume adjustments.

Button Functions:

- **Power ( )**: Turns the soundbar on or off.
- **Mute ( )**: Mutes or unmutes the soundbar audio.
- **AUX**: Selects the Auxiliary input source.
- **OPTICAL**: Selects the Optical input source.
- **Bluetooth ( )**: Selects the Bluetooth input source for wireless audio streaming.
- **LINE IN**: Selects the Line In input source.
- **COAXIAL**: Selects the Coaxial input source.
- **Input/Source ( )**: Cycles through available input sources.
- **Previous Track ( )**: Skips to the beginning of the current track or the previous track during playback.

- **Play/Pause ( )**: Plays or pauses audio playback.
- **Next Track ( )**: Skips to the next track during playback.
- **STANDARD**: Activates the standard sound mode.
- **TALK**: Activates the talk/dialogue enhancement sound mode.
- **MOVIE**: Activates the movie sound mode.
- **MUSIC**: Activates the music sound mode.
- **Volume Up (+)**: Increases the soundbar volume.
- **Volume Down (-)**: Decreases the soundbar volume.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery compartment cover securely.

The remote control is now ready for use with your Blackweb Soundbar BWA18SB001. No additional pairing or programming is required.

Operating Instructions

To operate your Blackweb Soundbar BWA18SB001 using this replacement remote control:

- **Power On/Off**: Press the **Power** button to turn the soundbar on or off.
- **Adjust Volume**: Use the **Volume Up (+)** and **Volume Down (-)** buttons to control the audio level.
- **Mute Audio**: Press the **Mute** button to temporarily silence the soundbar. Press it again to restore audio.
- **Select Input Source**: Press the dedicated input buttons (**AUX**, **OPTICAL**, **Bluetooth**, **LINE IN**, **COAXIAL**) to switch directly to the desired source. Alternatively, press the **Input/Source** button to cycle through available inputs.
- **Playback Control**: When using compatible input sources (e.g., Bluetooth), use the**Previous Track**, **Play/Pause**, and **Next Track** buttons to manage media playback.
- **Sound Modes**: Select a preferred audio profile by pressing the **STANDARD**, **TALK**, **MOVIE**, or **MUSIC** buttons.

Maintenance

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Solution

Problem	Solution
Remote control is not responding.	1. Ensure batteries are inserted correctly with the correct polarity. 2. Replace old batteries with new AAA batteries. 3. Ensure there are no obstructions between the remote and the soundbar's IR receiver. 4. Verify that the soundbar is powered on.
Remote control does not work with my soundbar.	This remote control is specifically designed for the **Blackweb Soundbar model BWA18SB001**. It is not a universal remote. Please confirm your soundbar model number matches BWA18SB001. If your model is different, this remote will not be compatible.
Buttons are not functioning correctly.	1. Check for low battery power and replace batteries if necessary. 2. Ensure no debris is lodged under the buttons.

Specifications

Brand	ZdalaMit
Model Number	BWA18SB001 (Compatible Soundbar Model)
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	0.634 ounces
Color	Black
Special Feature	Ergonomic
Max Number of Supported Devices	1 (Blackweb Soundbar BWA18SB001)
Compatible Devices	Blackweb Soundbar BWA18SB001 (Home Theater)

Support

For any questions or assistance regarding this replacement remote control, please contact the seller directly. Refer to your purchase documentation for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CN68KW72

More documents and user manuals: **https://manuals.plus/**