IRONMAX 10041

IRONMAX 15 Amp 20-Inch Corded Electric Snow Blower (Model 10041) User Manual

Your guide to safe and efficient snow removal.

Introduction

Thank you for choosing the IRONMAX 15 Amp 20-Inch Corded Electric Snow Blower. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new snow blower. Please read it thoroughly before first use and keep it for future reference.



The IRONMAX Corded Electric Snow Blower efficiently clears snow without the need for gas or batteries.

Safety Information

WARNING: This product is an electric snow blower. To reduce the risk of electric shock, do not use it with wet hands or in wet conditions. This snow blower is not a toy and should be kept out of reach of children. Always wear appropriate safety gear, including eye protection and sturdy footwear, when operating the machine. Ensure the power cord is always clear of the rotating auger and discharge chute.

Product Features

- **Powerful 15 Amp Motor:** Equipped with a 15A motor, rotating at 3,000 RPM, capable of clearing a 20-inch width and 10-inch depth of snow, throwing it up to 30 feet away.



The 15-Amp motor provides high efficiency, clearing snow effectively.

- **Integrated LED Lights:** Two LED lights enable snow removal in low-light conditions, such as dawn, dusk, or nighttime, enhancing visibility and safety.



Dual LED lights ensure visibility during nighttime snow clearing operations.

- **Adjustable Directional Chute:** The discharge chute offers a vertical adjustment range of 15°-60° and a horizontal adjustment of 0°-180°, allowing precise control over snow throwing direction.



Adjust the chute to direct snow precisely where needed.

- **Easy Start & Safety Switch:** Features a safety switch to prevent accidental startup. The machine starts quickly by holding the bail lever after engaging the safety switch.
- **User-Friendly Design:** Equipped with two 7-inch smooth wheels and a foam-wrapped handle for comfortable pushing and efficient operation, reducing physical strain.



Key design details like LED lights, durable wheels, and a comfortable handle enhance usability.

Assembly Instructions

The IRONMAX snow blower is designed for straightforward assembly. Follow these steps to prepare your unit for operation:

1. **Attach Handle Sections:** Connect the two sections of the handle using the provided knobs. Ensure they are securely fastened.
2. **Fix the Crank:** Install the crank mechanism for the directional chute. Refer to the diagram for proper placement and secure attachment.

3. **Check Connections:** Verify all electrical connections and ensure the power cord is properly routed and secured with the cord holder.



Follow these three steps for easy assembly of your snow blower.

Operating Instructions

Starting the Snow Blower

1. Ensure the snow blower is on a stable surface and the area is clear of debris.
2. Connect the power cord to a suitable outdoor-rated extension cord, then plug into a grounded outlet.
3. Press and hold the safety switch button.
4. While holding the safety switch, pull the bail lever towards the handle to start the motor. Release the safety switch button once the motor is running.




The 2-step quick start mechanism ensures safe operation.

Adjusting the Chute

To adjust the direction and angle of snow discharge:

- **Horizontal Adjustment:** Use the crank or lever to rotate the chute horizontally from 0° to 180° to direct snow left or right.
- **Vertical Adjustment:** Use the handle or lever to adjust the chute's deflector vertically from 15° to 60° to control the throwing distance.



The adjustable chute allows precise control over snow discharge direction and distance.

Clearing Snow

Push the snow blower forward at a steady pace. Overloading the machine by pushing too fast into deep or heavy snow can cause it to stall. If the machine stalls, release the bail lever, clear any obstructions, and restart. Always work away from the power cord to prevent accidental damage.



The snow blower is suitable for clearing snow from various surfaces around your home.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your snow blower.

- **After Each Use:** Disconnect from power. Clear any snow or ice from the auger housing and chute. Inspect the auger blades for wear or damage.
- **Cord Inspection:** Regularly check the power cord and extension cord for cuts, fraying, or damage. Replace damaged cords immediately.
- **Storage:** Store the snow blower in a dry, protected area when not in use. Ensure it is clean and free of moisture to prevent corrosion.


Troubleshooting

If you encounter issues with your snow blower, refer to the following common troubleshooting tips:

- **Snow Blower Does Not Start:**
  - Ensure the power cord is securely plugged into a working outlet and the machine.
  - Verify the safety switch is pressed and the bail lever is fully engaged.
  - Check for tripped circuit breakers or blown fuses in your electrical supply.
- **Snow Blower Stalls During Operation:**
  - You may be pushing too fast or attempting to clear too much snow at once. Reduce your pace.
  - Disconnect power and check the auger housing and chute for blockages. Clear any obstructions carefully using a non-metallic tool.
- **Snow Not Throwing Far Enough:**
  - Adjust the vertical angle of the discharge chute to a higher setting.
  - Ensure the chute is not clogged with wet or heavy snow. Disconnect power and clear any blockages.

For issues not covered here, please contact customer support.

Specifications



Detailed specifications for the IRONMAX 15 Amp 20-Inch Corded Electric Snow Blower.

Feature	Specification
Brand	IRONMAX
Model Number	10041
Power Source	Corded Electric
Motor	15 Amp
Voltage	120 Volts

Feature	Specification
Rotation Speed	3,000 RPM
Clearing Width	20 inches (50.8 cm)
Ideal Snow Depth	10 inches (25.4 cm)
Maximum Throw Distance	30 feet (9 meters)
Product Dimensions (D x W x H)	118D x 51W x 96H centimetres
Item Weight	13.61 kg (30 lbs)
Wheel Size	7 inches
Colour	Blue

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact IRONMAX customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer Contact Information: IRONMAX

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question