Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECONTROLLY RM-S441

ECONTROLLY RM-S441 Replacement Remote Control User Manual

For Sony Audio System Models: R4400, R4420, RMS441, SAW441, GDM20G10, HCD441, NCD441

Introduction

This manual provides instructions for the ECONTROLLY RM-S441 replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of various Sony Audio System models, ensuring compatibility and ease of use without requiring any programming.



Figure 1: Front view of the RM-S441 Remote Control

Setup

Battery Installation

The RM-S441 remote control requires two (2) AA alkaline batteries (not included) for operation. No programming or setup is required; simply insert the batteries to begin use.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two (2) AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 2: Battery compartment with cover removed

Operating Instructions

Basic Operation

Once batteries are installed, the remote control is ready for immediate use. Point the remote control directly at your Sony Audio System. The remote utilizes infrared technology for signal transmission.

Compatible Models

This replacement remote control is compatible with the following Sony Audio System models:

- R4400
- R4420
- RMS441
- SAW441
- GDM20G10
- HCD441
- NCD441

The remote provides full functionality for these models, including power, volume, input selection, and playback controls.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes inconsistent or stops functioning. Always use new alkaline AA batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the remote's finish or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure that new, fresh alkaline AA batteries are correctly installed with the proper polarity (+/-). Rechargeable batteries may not provide sufficient power.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the infrared receiver on your Sony Audio System. The remote requires a clear line of sight to transmit signals.
- **Remote Sensor:** Ensure the infrared sensor on your audio system is clean and not covered.
- **Test Functionality:** If possible, test the remote with another compatible device or try replacing the batteries with a different set of new alkaline batteries.

Further Assistance

If issues persist after following the troubleshooting steps, please contact ECONTROLLY customer support for further assistance. We are committed to helping you resolve any problems and ensure your satisfaction.

Specifications

Feature	Detail
Model Number	RM-S441
Brand	ECONTROLLY
Compatible Devices	Sony Audio Systems (R4400, R4420, RMS441, SAW441, GDM20G10, HCD441, NCD441)
Power Source	2 x AA Alkaline Batteries (not included)
Material	ABS
Color	Black
Product Dimensions	6 x 3 x 0.5 inches (approximately)
Item Weight	2 ounces (approximately)

Warranty and Support

Quality Assurance

All ECONTROLLY products undergo testing before shipment to ensure optimal functionality. This remote control is designed for durability and reliable performance.

Customer Support

Should you encounter any issues or have questions regarding the RM-S441 remote control, please contact ECONTROLLY customer service. Our team is available to provide assistance and ensure a satisfactory resolution. For support, please refer to the contact information provided with your purchase or visit the official ECONTROLLY website.

© 2023 ECONTROLLY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNCDZ9DD

More documents and user manuals: **https://manuals.plus/**