Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 20012

Beurer HK Limited Edition 2023 Heated Cushion Instruction Manual

1. Introduction

The Beurer HK Limited Edition 2023 Heated Cushion provides gentle, beneficial warmth for relaxation and muscle pain relief. This cushion is designed with a particularly soft and fluffy material that is breathable and pleasant to the touch. It features three individually adjustable temperature settings and an automatic shut-off function for safety. The removable controller allows for easy machine washing, ensuring hygienic cleanliness.



Image 1.1: The Beurer HK Limited Edition 2023 Heated Cushion, presented in its retail packaging.

2. Important Safety Instructions

Please read these safety instructions carefully before using the heated cushion and keep them for future reference. Failure to observe the following information may result in personal injury or material damage.

- **Automatic Shut-off:** The device is equipped with a safety system that prevents overheating and automatically switches off after approximately 90 minutes. This provides additional safety if you forget to turn off the heating pad.
- Do not use the heated cushion while sleeping.
- Do not fold or crease the cushion during operation.
- Ensure the cushion is completely dry before connecting it to the power supply.
- Keep the control unit dry and do not immerse it in water.
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- Do not use for very young children (0-3 years old) or persons insensitive to heat.



Image 2.1: The heated cushion controller, illustrating the safety system with automatic shut-off after 90 minutes.

3. Setup

1. Unpack the heated cushion and check for any signs of damage.
2. Ensure the control unit is securely connected to the heated cushion. The connector should click into place.
3. Place the heated cushion on a flat, dry surface where you intend to use it. Ensure there are no sharp objects that could damage the cushion.
4. Plug the power cord into a suitable electrical outlet (230 Volts).

4. Operating Instructions

The heated cushion is easy to operate using the manual switch located on the cable. The selected temperature level is indicated by a light.

1. **Turning On:** Slide the switch to the '1', '2', or '3' position to turn on the cushion and select a temperature level.
2. **Temperature Settings:**
    - **Level 1:** Minimum warmth

- **Level 2:** Medium warmth
- **Level 3:** Maximum warmth

3. **Rapid Heating:** The integrated rapid heating function warms the cushion quickly, making it ready for use almost immediately.
4. **Turning Off:** Slide the switch to the '0' position to turn off the heated cushion. Always unplug the device from the mains after use.



Image 4.1: User enjoying the heated cushion, demonstrating the three temperature settings and rapid heating.

5. Maintenance and Care

The Beurer HK Limited Edition 2023 Heated Cushion is designed for easy maintenance, ensuring hygienic use.

- **Cleaning:** The cushion is made from a soft, fluffy, breathable, and skin-friendly Oeko-Tex certified material. It is machine washable.

- **Washing Instructions:** Before washing, always disconnect the control unit from the cushion. The cushion can be machine washed at a maximum temperature of 30 °C on a gentle cycle.
- **Drying:** After washing, reshape the cushion and allow it to air dry completely before reattaching the control unit and using it again. Do not tumble dry.
- **Storage:** When not in use, store the cushion in a clean, dry place, away from direct sunlight and moisture.



Image 5.1: The heated cushion is machine washable up to 30 °C, with a removable manual switch for convenience.



Image 5.2: The cushion's material is Oeko-Tex certified, ensuring quality and skin-friendliness.

6. Troubleshooting

If you encounter any issues with your Beurer HK Limited Edition 2023 Heated Cushion, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cushion does not heat up.	Not plugged in, controller not connected, or automatic shut-off activated.	Check power connection. Ensure controller is securely attached. Turn off and on again to reset automatic shut-off.
Cushion heats unevenly.	Cushion may be folded or creased.	Ensure the cushion is laid flat and not folded during use.

Problem	Possible Cause	Solution
Controller light is off.	No power, or device is off.	Check power supply. Ensure the switch is set to a temperature level (1, 2, or 3).

If the problem persists after trying these solutions, please contact Beurer customer support.

7. Specifications

- **Model Number:** 20012
- **Dimensions (L x W x H):** 28.2 x 18.7 x 5.5 cm (Product dimensions as listed in specifications, note: packaging states 44 x 33 cm)
- **Weight:** 530 Grams
- **Voltage:** 230 Volts
- **Power:** 60 Watts
- **Number of Temperature Settings:** 3
- **Material:** Oeko-Tex certified material
- **Special Feature:** Machine washable, Automatic shut-off after 90 minutes
- **Color:** White/Grey



Image 7.1: The heated cushion's dimensions are approximately 44 cm x 33 cm, made from soft, breathable material.



Image 7.2: Key features of the heated cushion including its size, temperature settings, and safety features.

8. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please visit the official Beurer website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Beurer Customer Service: Please refer to the contact information provided in your product packaging or on the official Beurer website for your region.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNCW6BRF

More documents and user manuals: **https://manuals.plus/**