Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kärcher 1.055-733.0

Kärcher FC 7 Electric Floor Cleaner User Manual

Brand: Kärcher | Model: 1.055-733.0

Introduction

The Kärcher FC 7 Electric Floor Cleaner is designed to simplify hard floor cleaning by combining dry and wet dirt collection in a single step. This cordless device features a four-roller technology for efficient cleaning and is suitable for various hard floor types including laminate, wood, tile, LVT, vinyl, and stone flooring. Its dual tank system ensures cleaning with fresh water, and the integrated self-cleaning function makes maintenance convenient.

Key Features

- **Outstanding Performance:** Innovative 4-roller design with counter-rotation for effortless cleaning up to 530 RPM. Lithium-ion battery provides 45 minutes of cleaning time.
- **Edge to Edge Cleaning:** Cleans effectively along walls, stairs, corners, and baseboards. Flexible hinge allows cleaning under furniture.
- **Dual Tank System:** Separates fresh water and detergent from dirty water, ensuring continuous cleaning with clean water.
- **Easy Device Cleaning:** Features an integrated self-cleaning function in the charging station. Wastewater tray can be emptied without direct contact, and the floor head cover is removable and washable.
- **Kärcher Promise - Cleaner. Quicker:** Directly picks up dirt, small debris, and hair while mopping. Floors dry within 2 minutes due to minimal cleaning solution usage.

Setup

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all included components (FC 7 unit, charging dock, concentrate) are present.
2. **Assemble Handle:** Attach the handle to the main unit. Ensure it clicks securely into place.
3. **Charge Battery:** Place the FC 7 unit on the charging dock. Allow the battery to fully charge before first use. The battery indicator lights will show charging status.
4. **Fill Fresh Water Tank:** Locate the fresh water tank. Fill it with clean tap water up to the MAX line. For optimal cleaning, add the recommended amount of Kärcher floor cleaning concentrate.

5. **Attach Rollers:** Ensure the four microfiber rollers are properly attached to the cleaning head. They should snap into place.



Image: The Kärcher FC 7 Electric Floor Cleaner, showing its main components and sleek design.



Image: Diagram highlighting key features of the FC 7 Cordless, including the Power & Cleaning Mode Selector, Self-standing Aluminium Handle Tube, Clean Water Tank, Fold-flat Handle, 4 Machine Washable Rollers, and Clean & Storage Station.

Operating Instructions

1. **Power On:** Press the power button to turn on the device.
2. **Select Cleaning Mode:** Choose between two cleaning modes based on the floor type and dirt level. A boost function is available for stubborn dirt.
3. **Begin Cleaning:** Gently push the cleaner forward. The counter-rotating rollers will propel the device, making it easy to maneuver.
4. **Clean Edges and Under Furniture:** Utilize the flexible hinge and design to clean close to edges and under low-lying furniture.
5. **Monitor Water Tanks:** The dual tank system ensures fresh water is always applied. The dirty water is collected in a separate tray.



Image: A man effortlessly cleaning a tiled kitchen floor with the Kärcher FC 7 Cordless, demonstrating its ease of use.

FC 7 CORDLESS FEATURES



Image: The Kärcher FC 7 in action, effectively picking up both dry debris and wet spills from a hard floor surface.



Image: The Kärcher FC 7 demonstrating its edge-to-edge cleaning capability, reaching close to a baseboard.



Image: A close-up view of the Kärcher FC 7's dual tank system, illustrating how fresh and dirty water are kept separate for hygienic cleaning.

Your browser does not support the video tag.

Video: This official Kärcher video showcases the FC 7 Electric Floor Cleaner's ability to efficiently clean various types of dry and wet everyday dirt on hard floors.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Kärcher FC 7.

1. **Self-Cleaning Function:** After each use, place the FC 7 on its charging station. Activate the self-cleaning function to clean the rollers and internal components.
2. **Empty Dirty Water Tray:** Remove and empty the dirty water tray. Rinse it thoroughly with clean water.
3. **Clean Floor Head Cover:** The floor head cover can be easily removed and rinsed under running water to remove any accumulated debris.
4. **Roller Care:** The microfiber rollers are machine washable. For deeper cleaning, remove them and wash according to instructions

(e.g., on a gentle cycle).

Troubleshooting

Problem	Possible Cause	Solution
Device not turning on.	Battery is not charged.	Place the device on the charging dock and allow it to fully charge.
Poor cleaning performance / streaks.	Dirty rollers or dirty water tank is full.	Clean the rollers and empty/rinse the dirty water tank. Ensure fresh water tank is filled with clean water and appropriate concentrate.
Rollers not spinning or getting stuck.	Debris caught in rollers or rollers not properly attached.	Remove rollers and clear any obstructions. Re-attach rollers securely. Check if rollers are worn and need replacement.
Water not dispensing.	Fresh water tank is empty or clogged.	Refill the fresh water tank. Check for any blockages in the water dispensing nozzles.

Specifications

Feature	Detail
Brand	Kärcher
Model Name	FC 7 Cordless Mop
Item Model Number	1.055-733.0
Special Feature	4 Rollers, Dual Tank, Cordless
Surface Recommendation	Floor (Laminate, Wood, Tile, LVT, Vinyl, Stone)
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Run Time	Up to 45 minutes
Cleaning Area per Charge	Around 1450 ft²
Fresh Water Tank Volume	0.8 Gallons (approx. 3 liters)
Item Weight	17.25 Pounds
Product Dimensions	12.2 x 9.1 x 47.7 inches
Country of Origin	Italy

Warranty and Support

For detailed warranty information and customer support, please refer to the official Kärcher website or the warranty card included with your product. You can also contact Kärcher customer service for assistance with product registration, troubleshooting, and spare parts.
For additional resources and product information, visit the Kärcher Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNDC7NLX

More documents and user manuals: **https://manuals.plus/**