Supersonic SC-6025QI

Supersonic SC-6025QI Dual Alarm Clock User Manual

Model: SC-6025QI

Introduction

This manual provides detailed instructions for the operation and maintenance of your Supersonic SC-6025QI Dual Alarm Clock. This device combines a digital alarm clock with a wireless charging pad and a USB charging port, offering convenience for your bedside or desk. It also features a calendar display and room temperature monitoring.



Image: The Supersonic SC-6025QI Dual Alarm Clock, showcasing its large LED display and a smartphone actively charging on its integrated wireless charging pad.

Setup

1. **Unpacking:** Carefully remove the alarm clock from its packaging. Ensure all components are present: the alarm clock unit and the power adapter.
2. **Power Connection:** Connect the provided power adapter to the DC input port on the back of the alarm clock. Plug the adapter into a standard wall outlet. The display will illuminate, indicating the device is powered on.
3. **Initial Time Setting:** Upon first power-up, the clock may display a default time. Refer to the "Setting Time and Date" section under Operating Instructions to set the correct time and date.
4. **Placement:** Place the alarm clock on a stable, flat surface, such as a nightstand or desk, ensuring adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight.



Image: The alarm clock positioned on a nightstand, demonstrating its compact size and suitability for bedside use.

Operating Instructions

Setting Time and Date

- Press and hold the **TIME SET** button (location may vary, typically on the back or side) until the hour digits flash.
- Use the **+/-** buttons to adjust the hour. Press **TIME SET** again to confirm and move to minutes.
- Repeat for minutes, year, month, and day.
- Press **TIME SET** one last time to exit the setting mode.

Setting Alarms

The SC-6025QI supports dual alarms.

1. Press the **ALARM 1** button (or **ALARM 2**) once. The alarm time will flash.
2. Use the **+/-** buttons to set the desired alarm hour. Press the **ALARM** button again to confirm and move to minutes.
3. Repeat for minutes. Press the **ALARM** button again to save.
4. To activate/deactivate an alarm, press the corresponding **ALARM** button briefly. An alarm icon will appear/disappear on the display.
5. When the alarm sounds, press the **SNOOZE** button to temporarily silence it for approximately 9 minutes. To turn off the alarm completely, press any other button.



Image: Visual representation of the alarm clock's snooze and dual alarm capabilities, highlighting its function for managing wake-up times.

Adjusting Display Brightness

The LED display has 4 levels of brightness: High, Medium, Low, and Off.

- Press the **DIMMER** button (or similar brightness control button) repeatedly to cycle through the brightness levels.
- Select the level that best suits your environment and preference.



Image: A demonstration of the four adjustable brightness levels for the LED display, from completely off to high illumination, allowing customization for day or night use.

Using the Wireless Charger

- Place your Qi-enabled smartphone directly onto the wireless charging pad located on the base of the alarm clock.
- Ensure the phone is centered on the charging pad for optimal charging. A charging indicator (usually an LED light) on the clock will illuminate when charging begins.
- Remove any thick cases or metallic objects from your phone that may interfere with wireless charging.

Using the USB Charging Port

- Connect your device's USB charging cable to the USB output port located on the side of the alarm clock.
- Connect the other end of the cable to your device (e.g., smartwatch, secondary phone).
- The clock provides power for charging a second device simultaneously.



Image: The alarm clock demonstrating its dual charging capabilities, with a smartphone on the wireless pad and a smartwatch connected to the USB port, illustrating simultaneous device charging.

Room Temperature Display

- The clock automatically displays the current room temperature in either Celsius or Fahrenheit.
- To switch between Celsius and Fahrenheit, locate the **°C/°F** button (often near the temperature display or on the back) and press it briefly.

Maintenance

- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Power Disconnection:** Always unplug the power adapter from the wall outlet before cleaning or if the unit will not be used for an extended period.
- **Environment:** Keep the device away from excessive heat, humidity, dust, and direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Clock display is off or not working.	Power adapter not connected or faulty.	Ensure the power adapter is securely plugged into the clock and a working wall outlet. Try a different outlet.
Alarm sound is too soft or not audible.	Alarm volume set too low or a specific sound profile.	Check if there is a dedicated volume control for the alarm. Ensure the alarm is set to a suitable sound. Some models may have a fixed alarm sound.
Phone gets hot during wireless charging.	Misalignment on charging pad, thick phone case, or foreign objects.	Ensure your phone is perfectly centered on the charging pad. Remove any thick phone cases or metallic objects. Overheating can also occur if the phone is not Qi-compatible or if there's an issue with the phone's battery. Discontinue use if overheating persists.
Display is too bright even on the lowest setting.	Environmental light conditions or user preference.	Ensure you have cycled through all brightness levels using the DIMMER button, including the "Off" setting if desired. If the lowest setting is still too bright for your preference, consider placing the clock in a less direct line of sight or using a light-blocking film.
Temperature display is stuck or inaccurate.	Sensor malfunction or environmental factors.	Ensure the clock is not placed near heat sources (e.g., lamps, direct sunlight, vents) that could affect the sensor. Try unplugging the unit for a few minutes and then plugging it back in to reset the sensor. If the issue persists, contact customer support.
Wireless charging not working for certain devices (e.g., Android phones).	Device not Qi-enabled or compatibility issue.	Verify that your device supports Qi wireless charging. Some older or specific models may not be compatible. Ensure the device is placed correctly on the charging pad.

Specifications

- **Model Number:** SC-6025QI
- **Product Dimensions:** 5.8 x 5.6 x 2.3 inches
- **Item Weight:** 8.6 ounces
- **Manufacturer:** Supersonic, Inc
- **Power Input:** DC (via included adapter)
- **Wireless Charging Output:** Up to 15W (Qi-compatible)
- **USB Charging Output:** Standard USB-A port
- **Display:** LED with 4 brightness levels (High, Medium, Low, Off)
- **Temperature Display:** Celsius (°C) / Fahrenheit (°F) switchable

Warranty and Support

Supersonic, Inc. products are designed for reliability and performance. For warranty information or technical support, please contact Supersonic customer service. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the official Supersonic Store on Amazon or refer to the contact information provided with your product packaging.

© 2025 Supersonic, Inc. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I change the Supersonic SC-6025QI from military time to standard time and fix the incorrect day of the week?

To resolve the issues with your Supersonic SC-6025QI, you will need to enter the time and date setting mode. The day of the week is automatically calculated based on the year, month, and day...

Read full answer