Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MKJ32022835

ALLIMITY MKJ32022835 Replacement Remote Control User Manual

Model: MKJ32022835

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY MKJ32022835 Replacement Remote Control. It is designed to be compatible with various LG 4K OLED Smart TV models. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

2. Safety Information

- Keep the remote control away from water and excessive moisture.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not expose the remote control to direct sunlight or high temperatures for extended periods.
- Do not attempt to disassemble or modify the remote control. This will void the warranty.
- Dispose of used batteries responsibly according to local regulations.

3. Package Contents

The package contains the following item:

- 1 x ALLIMITY MKJ32022835 Replacement Remote Control





Image 1: Front view of the ALLIMITY MKJ32022835 Replacement Remote Control, showing all buttons and layout.



Image 2: Angled view of the ALLIMITY MKJ32022835 Replacement Remote Control, highlighting its ergonomic design.

4. Setup

4.1 Battery Installation

The ALLIMITY MKJ32022835 remote control requires two AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: This remote control does not require any setup or programming. Once batteries are installed, it is ready for use with compatible LG TV models.





Image 3: Rear view of the remote control with the battery compartment open, showing the correct orientation for AAA battery insertion.

5. Operating Instructions

This remote control functions identically to the original LG remote control it replaces. Point the remote control directly at your LG TV and press the desired buttons.

5.1 Key Functions Overview

Below is a general overview of common button functions. Specific functionality may vary slightly depending on your LG TV model.

- **POWER:** Turns the TV on or off.
- **INPUT D/A / INPUT:** Selects input sources (HDMI, AV, Component, etc.).
- **TV/RADIO:** Switches between TV and Radio modes.
- **MODE TV / DVD / VCR:** Selects the device to control (if applicable).
- **BRIGHT (+/-):** Adjusts screen brightness.
- **TEXT:** Activates/deactivates Teletext.
- **RATIO:** Changes the aspect ratio of the screen.
- **I/II:** Selects audio language or stereo/mono.
- **Colored Buttons (Red, Green, Yellow, Blue):** Function keys for specific features, often context-dependent.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Controls media playback.
- **BACK / EXIT:** Returns to the previous menu or exits the current menu.
- **MENU:** Opens the main menu.
- **INFO / GUIDE:** Displays program information or the electronic program guide.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **VOL (+/-):** Adjusts volume level.
- **MUTE:** Mutes or unmutes the sound.
- **FAV:** Accesses favorite channels.
- **PR (+/-):** Changes channels.
- **Number Buttons (0-9):** Direct channel selection.
- **LIST:** Displays a list of channels.
- **Q.VIEW:** Returns to the previously viewed channel.
- **UPDATE / INDEX / TIME / REVEAL:** Teletext or advanced functions.
- **SLEEP:** Sets the sleep timer.
- **HOLD:** Holds the current Teletext page.
- **SUBTITLE:** Activates/deactivates subtitles.



Image 4: Illustrative image of the remote control being used to operate a television.

6. Compatible LG TV Models

This ALLIMITY MKJ32022835 replacement remote control is compatible with a wide range of LG TV models, including but not limited to:

- 42PG3500, 37LG3500, 37LG5300, 37LG5500, 37LG7500
- 50PG7500, 50PS3000, 50PS6000, 50PS7000-ZA, 52LG5500, 52LG7500
- 60PS6000-ZC, 26LB75-ZE, 47LF65, 47LF66, 47LG5500, 47LG7500
- 50PC55, 50PC56, 50PG2500, 26LC56-ZC, 37LC41-ZA, 37LC42-ZC
- 37LC45-ZA, 37LC46-ZC, 37LC55-ZA, 37LC56-ZC, 37LF65-ZC, 37LF66-ZE
- 37LF75-ZD, 37LF76-ZF, 37LG3500-ZA, 37LG5300-ZB, 37LG5500-ZB
- 37LG7500-ZB, 42PC55-ZB, 42PC56-ZD, 42PG2500-ZA, 42PG3500-ZA
- 42PG6500-ZA, 42PG6900-ZF, 47LF65-ZC, 26LB76-ZF, 26LC41-ZA

- 47LG5500-ZB, 47LG7500-ZB, 50PC55-ZB, 50PC56-ZD, 50PG2500-ZA
- 50PG3500-ZA, 50PG7500-ZA, 50PS3000-ZA, 50PS7000, 50PS8000
- 52LG5500-ZB, 52LG7500-ZB, 26LB76, 26LB75, 26LC41, 26LC42
- 26LC45, 26LC46, 26LC55, 26LC56, 37LC41, 37LC42, 37LC45, 37LC46
- 42PC55, 42PC56, 42PG2500, 50PG3500, 50PG4500, 50PG6500, 50PG6900
- 37LC55, 37LC56, 37LF65, 37LF66, 37LF75, 26LC42-ZB, 26LC45-ZA
- 26LC46-ZC, 26LC55-ZA, 50PG4500-ZA, 50PG6500-ZA, 50PG6900-ZF
- 42PG6500, 42PG6900, 47LF66-ZD, 37LF76

If your LG TV model is not listed, but uses an original remote control with a similar button layout or the model number MKJ32022835, this replacement remote may still be compatible.

7. Maintenance

7.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

7.2 Storage

When not in use for extended periods, store the remote control in a cool, dry place. If storing for several weeks or months, it is recommended to remove the batteries to prevent leakage and potential damage to the remote.

8. Troubleshooting

- **Remote control is not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Some buttons are not working:**
  - This may indicate low battery power. Try replacing the batteries.
  - Ensure the button is clean and not stuck.
  - Verify that the button's function is supported by your specific LG TV model.
- **Remote control works intermittently:**
  - This often points to weak batteries. Replace them.
  - Ensure there is no strong light source (e.g., direct sunlight, fluorescent lights) interfering with the infrared signal.

If you continue to experience issues after following these troubleshooting steps, please refer to the support information provided.

9. Specifications

Brand	ALLIMITY

Model Number	MKJ32022835
Compatible Devices	Various LG 4K OLED Smart TVs (see Section 6 for details)
Power Source	2 x AAA Alkaline Batteries (not included)
Special Feature	No Programming Required
Color	Black
Product Dimensions	6 x 2 x 0.6 inches (approximately)
Item Weight	2 ounces (without batteries)

10. Warranty and Support

For any questions, concerns, or issues regarding your ALLIMITY MKJ32022835 Replacement Remote Control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific warranty terms and contact information.

The manufacturer strives for customer satisfaction. If anything is unclear or if you require assistance, please reach out to the support team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNH2GV2N

More documents and user manuals: **https://manuals.plus/**