Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Acer TMB311R-33-C872

Acer TravelMate Spin B3 B311R-33 User Manual

Model: TMB311R-33-C872

Introduction | What's in the Box | Product Overview | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides essential information for the safe and efficient use of your Acer TravelMate Spin B3 B311R-33 convertible notebook. Please read this guide thoroughly before operating your device to ensure proper setup, operation, and maintenance. Keep this manual for future reference.

2. What's in the Box

Verify that all items listed below are included in your product packaging:

- Acer TravelMate Spin B3 11 TMB311R-33-C872 2-in-1 Notebook
- Lithium Ion Battery (integrated)
- AC Adapter
- Power Cord

3. Product Overview

Familiarize yourself with the components and features of your Acer TravelMate Spin B3 notebook.

3.1 Front and Top View



Figure 3.1: The Acer TravelMate Spin B3 notebook displayed with its screen open, revealing the keyboard and touchpad. This image provides a general view of the device in laptop mode.



Figure 3.2: A direct front view of the Acer TravelMate Spin B3 notebook with the lid open, showcasing the display and keyboard layout.



Figure 3.3: Top-down view of the closed Acer TravelMate Spin B3 notebook, highlighting the textured finish and Acer logo on the lid.

3.2 Left Side Ports



Figure 3.4: Close-up of the left side of the notebook, showing the power input, USB-C port, HDMI port, and a USB 3.0 port.

3.3 Right Side Ports



Figure 3.5: Close-up of the right side of the notebook, featuring a microSD card slot, audio jack, USB 3.0 port, and a Kensington lock slot.

4. Setup

4.1 Initial Power-On and Charging

1. **Connect the AC Adapter:** Plug the AC adapter into the power input port on the left side of the notebook and then into a power outlet.
2. **Charge the Battery:** Allow the notebook to charge for at least 30 minutes before initial use, or until the battery indicator shows a sufficient charge.

3. **Power On:** Open the lid and press the power button, typically located on the side or keyboard deck.
4. **Initial Windows Setup:** Follow the on-screen instructions to complete the Windows 11 Pro Education setup, including language selection, network connection, and user account creation.

4.2 Connecting to a Network

After initial setup, you can connect to a Wi-Fi network:

- Click the Wi-Fi icon in the system tray (bottom right of the screen).
- Select your desired network from the list.
- Enter the network security key (password) if prompted.
- Click **Connect**.

5. Operating Instructions

5.1 Convertible Modes

Your TravelMate Spin B3 is a 2-in-1 convertible notebook, offering multiple usage modes:

- **Laptop Mode:** Standard notebook configuration for typing and productivity.
- **Tent Mode:** Fold the screen back to form an inverted "V" shape, ideal for presentations or watching videos in confined spaces.
- **Stand Mode:** Fold the screen back further, resting the keyboard face down, suitable for touch-based interaction or media consumption.
- **Tablet Mode:** Fold the screen completely back against the base, transforming the device into a tablet for maximum portability and touch interaction.

5.2 Using the Touchscreen

The 11.6-inch HD touchscreen supports multi-touch gestures. Use your fingers to navigate, tap, swipe, pinch-to-zoom, and interact with applications. The operating system will automatically adjust to tablet mode when the screen is folded beyond a certain angle.

5.3 Keyboard and Touchpad

The integrated keyboard and touchpad provide traditional input methods. Refer to the Windows operating system documentation for specific gesture controls on the touchpad.

6. Maintenance

6.1 Cleaning the Device

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner specifically designed for electronics. Avoid harsh chemicals.
- **Keyboard and Casing:** Wipe with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, ensuring no liquid enters openings.
- **Ports:** Use compressed air to gently clear dust from ports. Do not insert objects into ports.

6.2 Software Updates

Regularly check for and install operating system updates and driver updates to ensure optimal performance and security. These can typically be found in the Windows Settings menu under "Windows Update" or on the official Acer support website.

6.3 Battery Care

To prolong battery life, avoid extreme temperatures and fully discharging the battery frequently. For long-term storage, charge the battery to approximately 50-70% and store the device in a cool, dry place.

7. Troubleshooting

Problem	Possible Solution
Device does not power on.	Ensure the AC adapter is securely connected and the power outlet is functional. The battery may be fully discharged; allow it to charge for a period before attempting to power on again.
Screen is blank or black.	Check if the device is powered on. Try connecting an external monitor to determine if the issue is with the internal display. Restart the device.
Wi-Fi connection issues.	Verify that Wi-Fi is enabled. Restart your router and modem. Ensure you are entering the correct network password. Try connecting to a different network if available.
Touchscreen not responding.	Restart the notebook. Ensure the screen is clean and free of debris. Check for any pending system updates that might include touchscreen driver fixes.
Slow performance.	Close unnecessary applications. Check for background processes consuming resources. Ensure sufficient free space on the SSD. Run a system scan for malware.

8. Specifications

Key technical specifications for the Acer TravelMate Spin B3 B311R-33 TMB311R-33-C872:

Feature	Detail
Model Name	TravelMate Spin B3 B311R-33 (TMB311R-33-C872)
Display	11.6 inches, 1366 x 768 pixels (HD), Touchscreen
Processor	Intel N100 Quad-core (4 Core)
RAM	8 GB LPDDR5
Storage	128 GB SSD
Graphics	Intel UHD Graphics
Operating System	Windows 11 Pro Education
Wireless Connectivity	802.11ax, Bluetooth
Battery Life	Up to 10 Hours (Average)
Dimensions (LxWxH)	8.3 x 11.4 x 0.82 inches
Weight	4.93 pounds

9. Warranty and Support

9.1 Product Warranty

Your Acer TravelMate Spin B3 notebook is covered by a limited warranty. The specific terms and duration of the warranty may vary by region and purchase date. Please refer to the warranty card included with your product or visit the official Acer support website for detailed warranty information.

9.2 Technical Support

For technical assistance, driver downloads, or further support, please visit the official Acer support website at www.acer.com/support. You may need your product's serial number, which is typically located on a sticker on the bottom of the device.

© 2025 Acer Inc. All rights reserved. Information in this document is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNH3TZRM

More documents and user manuals: **https://manuals.plus/**