Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KJDEYT CGD-A970S

Anysecu A970s A420 4G Network Radio Desktop Charger User Manual

Model: CGD-A970S

1. Introduction

This manual provides essential instructions for the safe and efficient use of your KJDEYT Anysecu A970s A420 4G Network Radio Desktop Charger (Model: CGD-A970S). Please read this manual thoroughly before operating the device and retain it for future reference.

2. Important Safety Information

To prevent damage to the charger or injury to yourself or others, observe the following safety precautions:

- **Battery Compatibility:** This charger is only suitable for Li-Ion batteries. Do not attempt to charge other battery types.
- **Radio Power:** Always turn off the radio during charging to ensure proper and safe operation.
- **Power Source:** Use only a DC 5V 2A power source for input. Using an incorrect power source may damage the charger and radio.
- **Environment:** Do not expose the charger to water, moisture, or extreme temperatures. Use in a dry, well-ventilated area.
- **Damage:** Do not use the charger if it appears damaged. Contact customer support for assistance.
- **Disassembly:** Do not attempt to disassemble or modify the charger. This will void the warranty and may cause harm.



Image 2.1: Bottom label of the charger indicating it is only suitable for Li-Ion batteries and specifying input/output voltage.

3. Package Contents

Verify that all items are present in the package:

- 1 x Desktop Charger (Model: CGD-A970S)
- *(Note: Power adapter and USB cable are typically sold separately or included with the radio.)*

4. Product Overview

The KJDEYT Anysecu Desktop Charger is designed to provide a convenient charging solution for your Anysecu A970S and A420 4G Network Radios. It features a dedicated slot for the radio and an input port for power.



Image 4.1: Top view of the desktop charger, highlighting the charging slot and basic electrical specifications.



Image 4.2: Side view of the desktop charger, illustrating the micro-USB input port for power connection.

Key Features:

- Dedicated charging dock for Anysecu A970S and A420 radios.
- Input: DC 5V 2A
- Output: DC 5V 2A
- Compact and stable design for desktop use.

5. Setup Instructions

1. **Unpack:** Carefully remove the desktop charger from its packaging.
2. **Connect Power:** Connect a compatible USB cable (not included) to the micro-USB input port on the side of the charger (refer to Image 4.2).
3. **Power Source:** Connect the other end of the USB cable to a DC 5V 2A power adapter (not included) and plug it into a standard wall outlet.
4. **Placement:** Place the charger on a stable, flat, and dry surface.

6. Operating Instructions

Follow these steps to charge your Anysecu 4G Network Radio:

1. **Power Off Radio:** Ensure your Anysecu A970S or A420 4G Network Radio is turned**OFF** before placing it in the charger. This is crucial for safe and effective charging.
2. **Insert Radio:** Carefully place the radio into the charging slot of the desktop charger, ensuring the charging contacts align

properly.

3. **Charging Indicator:** The charger typically features an indicator light. A **red light** usually indicates that the radio is charging. A **green light** indicates that charging is complete. (Refer to the bottom label in Image 2.1 for visual indicators).
4. **Remove Radio:** Once the charging is complete (green light), carefully remove the radio from the charging dock.

Important: Only charge Li-Ion batteries with this device. Charging other battery types may cause damage or fire.

7. Maintenance and Care

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the exterior of the charger. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the charger in a cool, dry place away from direct sunlight and moisture.
- **Contacts:** Periodically check the charging contacts for any dust or debris and clean them gently with a dry cotton swab if necessary.

8. Troubleshooting

Problem	Possible Cause	Solution
Radio not charging.	Charger not powered. Radio not properly seated. Radio is turned on. Damaged charger or cable.	Ensure power adapter is connected and plugged in. Re-seat the radio, ensuring contacts align. Turn off the radio before charging. Inspect charger and cable for damage. Replace if necessary.
Charging indicator light not working.	No power to charger. Faulty indicator light.	Check power connection. If power is confirmed, contact customer support.

9. Specifications

Model:	CGD-A970S
Input:	DC 5V 2A
Output:	DC 5V 2A
Compatible Radios:	Anysecu A970S, Anysecu A420 4G Network Radios
Compatible Battery Type:	Li-Ion Battery
Product Dimensions:	Approximately 4 x 1 x 2 inches
Item Weight:	Approximately 0.141 ounces

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the retailer where the product was purchased. You may also visit the manufacturer's official website for further assistance.
Manufacturer: Anysecu
Brand: KJDEYT

© 2023 KJDEYT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNJSRMW9

More documents and user manuals: **https://manuals.plus/**