Bellemave AGUO-LT000259AAB

Bellemave Full XL Over Queen Metal Bunk Bed with Trundle Instruction Manual

Introduction

Thank you for choosing the Bellemave Full XL Over Queen Metal Bunk Bed with Trundle. This manual provides comprehensive instructions for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Your safety is our top priority. Please adhere to the following safety guidelines:

- This bed frame is designed for use with mattresses of specific thicknesses: 6 inches for the upper bed, 8 inches for the bottom bed, and 6 inches for the trundle bed.
- The weight capacity is 250 lbs for the upper bed, 350 lbs for the lower bed, and 250 lbs for the trundle bed. Do not exceed these limits.
- Always follow the provided assembly instructions to ensure proper and safe installation.
- The ladder and high guardrail are designed for safe access and use of the upper bed. Ensure they are securely attached.
- Periodically check all connections and tighten hardware as needed to prevent wobbling or instability.
- The top bunk is not suitable for children under six years of age.
- Prohibit horseplay on or under the bed.
- Always use the ladder for entering and leaving the upper bunk.

Parts List

A detailed list of all components and hardware is included in the packaging. Please verify that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

Assembly Instructions

For a visual guide to assembly, please refer to the official installation video below. Follow the steps carefully to ensure correct and safe setup.

Your browser does not support the video tag.

Official Installation Manual: Full XL over Queen Metal Bunk Bed with Trundle. This video provides a step-by-step guide to assembling your bunk bed.

Step-by-Step Assembly Guide:

1. **Assemble Headboard and Footboard:** Begin by assembling the headboard and footboard components. Pay close attention to the labels to differentiate between upper and bottom bed parts. It is recommended to assemble the bottom bed first.
2. **Connect Headboard and Footboard:** Attach the headboard and footboard using the designated connectors. Apply foam tape (part M) to parts (9) to minimize noise.
3. **Connect Slatted Bed Base:** Secure the slatted bed base to the frame. Ensure the ends of parts (13) and (15) align with the holes on the side of the bed frame, as they have a nut structure.
4. **Secure Slatted Bed Base:** Be patient while installing parts (8) and (11) in sequence before fully tightening the screws on both sides.
5. **Connect Upper and Lower Beds:** With the assistance of another person, carefully connect and secure the upper and lower bed frames. If you intend to use them as two separate beds, install the caps at the bottom of the legs instead of connecting them vertically.
6. **Connect the Ladder:** Install the ladder. It is easier to install the upper part of the ladder first, followed by the lower part.
7. **Trundle Bed Assembly:** Assemble the trundle bed according to the instructions. Ensure all casters are securely attached.
8. **Completion:** Once all steps are completed, double-check all connections for tightness and stability.



Image: The Bellemave Full XL Over Queen Metal Bunk Bed with Trundle, showcasing its sturdy metal frame and integrated ladder.

Operating Instructions

Using the Trundle Bed:

The trundle bed is designed for easy access and storage. Simply pull the trundle frame out from under the lower bunk when an additional sleeping space is needed. When not in use, push it back in to save space. Ensure the trundle casters are locked if available, or positioned to prevent unwanted movement.



Image: The bunk bed with the trundle bed extended, providing an additional sleeping area.

Splitting the Bunk Bed:

This metal bunk bed can be converted into two individual beds. To split the beds, carefully disassemble the connecting components between the upper and lower bunks as instructed in the assembly guide. Once separated, install the provided caps at the bottom of the legs for each individual bed to ensure stability and prevent floor scratching.



Image: The bunk bed separated into two distinct bed frames, demonstrating its versatile design.

Maintenance

To ensure the longevity and safety of your Bellemave bunk bed, regular maintenance is recommended:

- **Tighten Hardware:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections. Tighten them as necessary to maintain structural integrity and prevent squeaking.
- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Inspect for Damage:** Regularly inspect the bed frame for any signs of wear, damage, or loose parts. Address any issues promptly.

Troubleshooting

If you encounter any issues with your bunk bed, please refer to the following common problems and solutions:

- **Squeaking Noises:** Squeaking often indicates loose connections. Re-tighten all bolts and screws on the frame. Ensure foam tape is properly applied to parts (9) as mentioned in assembly step 2.
- **Instability/Wobbling:** This is typically caused by loose hardware. Carefully re-tighten all connections. Ensure the bed is assembled on a flat, even surface.
- **Difficulty with Trundle Movement:** Check the trundle casters for any obstructions or damage. Ensure they are clean and functioning smoothly.

If problems persist after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	AGUO-LT000259AAB
Size	Full XL over Queen w/Trundle
Product Dimensions	83"L x 63"W x 65.3"H
Material	Iron
Color	Antique Black
Finish Type	Powder Coated
Special Feature	with Trundle
Included Components	Trundle
Compatible Mattress Size	Full XL, Queen, Twin
Upper Bed Weight Capacity	250 lbs
Lower Bed Weight Capacity	350 lbs
Trundle Bed Weight Capacity	250 lbs
Assembly Required	Yes
Ground To Item Distance	65.3 Inches
Storage Options	Under-bed storage



Image: Detailed dimensions of the Bellemave Full XL Over Queen Metal Bunk Bed with Trundle.

Warranty and Support

For warranty information or any further assistance, please contact Bellemave customer support through the retailer where you purchased the product. Please have your model number (AGUO-LT000259AAB) and purchase date available when contacting support.