Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood TFR-358SHD

Techwood TFR-358SHD 1200W Oil-Free Air Fryer Instruction Manual

Model: TFR-358SHD | Brand: Techwood

Safety Instructions Product Overview Setup Operating Instructions Cooking Guide Maintenance Troubleshooting Specifications Warranty & Support

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is equipped with overheat protection. If the internal temperature exceeds the set limit, the appliance will automatically shut down.

2. Product Overview

The Techwood TFR-358SHD is an oil-free air fryer designed for healthy, low-fat cooking. It features a digital touch panel and multiple pre-set programs for convenience.

Components:

- Main Unit
- Removable Non-Stick Drawer/Basket
- Digital Touch Control Panel
- Power Cord

Key Features:

- **Oil-Free Cooking:** For healthier meals with less fat.
- **3.5 L Capacity:** Suitable for preparing up to 1 kg of fries.
- **Digital Touch Panel:** Easy-to-use interface for settings and programs.
- **8 Pre-set Programs:** Including a keep-warm function.
- **Adjustable Thermostat:** Temperature range from 80°C to 200°C.
- **60-Minute Timer:** With cooking end alarm and automatic shut-off.
- **Power Indicator Light:** For operational status.
- **Overheat Protection:** Enhances safety during operation.
- **Non-Stick Coating:** Removable drawer for easy cleaning.



Figure 2.1: The Techwood TFR-358SHD air fryer with its basket securely closed, showcasing its sleek black design and digital control panel.



Figure 2.2: The air fryer with its removable non-stick basket pulled out, revealing the spacious cooking compartment. This design facilitates easy loading and cleaning.

3. Setup

1. **Unpack the Appliance:** Carefully remove all packaging materials, including any protective films or stickers. Ensure all components are present.
2. **Clean Before First Use:** Wash the removable drawer and basket with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.

3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to ensure proper air circulation. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance.
4. **Power Connection:** Plug the power cord into a grounded wall outlet. The appliance is now ready for use.

4. Operating Instructions

4.1 Basic Operation:

1. **Prepare Food:** Place the ingredients into the air fryer basket. Do not overfill the basket to allow for proper air circulation.
2. **Insert Basket:** Slide the drawer back into the main unit until it clicks into place.
3. **Power On:** Press the power button on the digital touch panel.
4. **Set Temperature and Time:**
    - Use the temperature control buttons to set the desired cooking temperature (80°C - 200°C).
    - Use the timer control buttons to set the desired cooking time (up to 60 minutes).
5. **Select Pre-set Program (Optional):** Alternatively, choose one of the 8 pre-set programs by tapping the corresponding icon on the digital panel. The appliance will automatically set the optimal temperature and time for that food type.
6. **Start Cooking:** Press the start/pause button to begin the cooking process. The power indicator light will illuminate.
7. **Shake Basket (Recommended):** For even cooking, especially for items like fries, pull out the drawer halfway through the cooking time, shake the contents, and then reinsert the drawer. The appliance will resume cooking automatically.
8. **Cooking End:** The timer will sound an alarm when the cooking time is complete, and the appliance will automatically shut off.
9. **Remove Food:** Carefully pull out the drawer. Use heat-resistant tongs to remove the cooked food from the basket.

4.2 Keep Warm Function:

The air fryer includes a keep-warm function. After cooking is complete, you can activate this function to keep your food warm for an extended period without overcooking.

5. Cooking Guide

The following table provides general guidelines for cooking various food types. Cooking times and temperatures may vary based on food quantity, thickness, and personal preference. Always ensure food is cooked thoroughly.

Food Item	Temperature	Time	Notes
Fresh Fries (1 kg)	180°C - 200°C	20 - 30 min	Shake basket 2-3 times.
Frozen Fries	180°C - 200°C	15 - 25 min	Shake basket 2-3 times.
Chicken Drumsticks	180°C	20 - 25 min	Flip halfway.
Steak/Meat	180°C - 200°C	10 - 20 min	Adjust for desired doneness.
Fish Fillets	160°C - 180°C	10 - 15 min	Check for flakiness.
Vegetables	160°C - 180°C	10 - 18 min	Toss halfway.



Figure 5.1: The air fryer basket filled with perfectly cooked, golden-brown fries, demonstrating the appliance's capability for crispy results.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool Down:** Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
2. **Clean the Drawer and Basket:**

- Remove the drawer and basket from the air fryer.
- Wash them in hot water with dish soap and a non-abrasive sponge. The non-stick coating makes cleaning easy.
- For stubborn food residues, soak the basket in hot water with some dish soap for about 10 minutes.
- Rinse thoroughly and dry completely before reassembling.

3. **Clean the Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or scouring pads.
4. **Clean the Exterior:** Wipe the exterior of the air fryer with a soft, damp cloth.
5. **Heating Element:** Gently clean the heating element with a cleaning brush to remove any food residues.

7. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake or toss food items halfway through cooking.
Food is not crispy.	Too much moisture; insufficient cooking time/temperature.	Pat food dry before cooking. Increase cooking time or temperature slightly. Ensure proper air circulation.
White smoke coming from appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and interior thoroughly after each use. For very fatty foods, a small amount of smoke is normal.
Appliance suddenly stops during operation.	Overheat protection activated.	Unplug the appliance and let it cool down for at least 30 minutes. Check for any blockages in air vents.

8. Specifications

- **Model:** TFR-358SHD
- **Brand:** Techwood
- **Color:** Black
- **Power:** 1200 Watts
- **Voltage:** 220-240V ~ 50-60Hz
- **Capacity:** 3.5 Liters (approx. 1 kg of fries)
- **Temperature Range:** 80°C - 200°C
- **Timer:** Up to 60 minutes with automatic shut-off
- **Material:** Stainless Steel (internal components), Plastic (exterior)
- **Dimensions (L x W x H):** 30.9 x 30.9 x 32.9 cm
- **Weight:** 3.6 kg

9. Warranty and Support

This Techwood air fryer comes with a warranty for spare parts availability for **5 years** from the date of purchase. For any support, warranty claims, or inquiries, please refer to your purchase documentation or contact Techwood customer service.
For more information about Techwood products, you may visit the official website: Techwood Product Catalogues

© 2023 Techwood. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CNTSTSJV

More documents and user manuals: **https://manuals.plus/**