ANCTOR HK-QBF-B016

ANCTOR Queen Bed Frame User Manual

Model: HK-QBF-B016

Introduction

Thank you for choosing the ANCTOR Queen Bed Frame. This manual provides essential information for the proper assembly, operation, and maintenance of your new bed frame. Designed for stability and convenience, this bed frame features a sturdy metal and wood construction, a storage headboard with integrated power outlets, and requires no box spring.



Figure 1: ANCTOR Queen Bed Frame, showcasing the rustic brown and black design with the integrated storage headboard.

Setup and Assembly

The ANCTOR Queen Bed Frame is designed for straightforward assembly. All necessary components and clear instructions are included. For optimal stability and alignment, it is recommended to loosely screw in all bolts during each step before fully tightening them at the end of that step or once the entire frame is assembled.

- Unpack all components and verify against the parts list provided in your assembly guide.
- Assemble the main frame components, ensuring all connections are aligned.
- Attach the headboard and footboard sections.
- Install the metal slats, ensuring they are securely fastened.
- For the power box on the headboard, note that pre-drilled holes may not be present. A drill or firm pressure may be required to secure it.
- Once all parts are in place, proceed to fully tighten all bolts for a sturdy and stable structure.



Figure 2: Illustration of key assembly points, including frame connections and wide leg design, highlighting the ease of assembly.



Figure 3: Detailed dimensions of the Queen bed frame, including length, width, and height, for proper space planning.

Operating Instructions

The ANCTOR Queen Bed Frame is designed for convenience and functionality, featuring a storage headboard with integrated power options.

Storage Headboard

The headboard includes a convenient shelf for storing small items such as glasses, mobile phones, and watches, keeping them easily accessible from your bed.

Integrated Power Outlets and USB Ports

The headboard is equipped with AC outlets and USB ports, providing a convenient charging station for your electronic devices. Simply plug the bed frame's power cord into a wall outlet to activate these features.



Figure 4: The storage headboard featuring 110V/12A AC outlets and 5V/2A USB ports, along with the 6.5-foot power cord for easy connectivity.

Maintenance

Regular maintenance will help preserve the condition and longevity of your ANCTOR Queen Bed Frame.

- **Cleaning:** Wipe down metal and wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish. For the PU upholstered headboard, use a mild cleaner suitable for faux leather.
- **Fastener Check:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain stability and prevent squeaking.
- **Weight Distribution:** Ensure weight is evenly distributed across the bed frame to prevent undue stress on any single point.
- **Headboard Shelf:** Do not overload the storage headboard shelf beyond its intended capacity.
- **Electrical Safety:** Use the integrated outlets and USB ports with caution. Always follow safety guidelines for electrical devices and avoid spilling liquids near the power unit.

Troubleshooting

This section addresses common issues you might encounter with your bed frame.

Problem	Possible Cause	Solution
Bed frame squeaks or feels unstable.	Loose bolts or improper assembly.	Ensure all bolts are fully tightened. Refer to the assembly instructions and re-tighten any loose connections.
Mattress slides on the frame.	Lack of friction between mattress and slats.	Some models include grippy strips on the slats to prevent sliding. If not present, consider adding a non-slip mat between the mattress and slats.
Power outlets/USB ports not working.	Power cord not properly connected or wall outlet issue.	Verify the bed frame's power cord is securely plugged into a functional wall outlet. Check the wall outlet with another device.
Gap between mattress and headboard.	Mattress size incompatibility or insufficient mattress depth.	Ensure your mattress is the correct Queen size (60 x 80 inches). A mattress depth of at least 10-12 inches is recommended to minimize gaps.

Specifications

Feature	Detail
Size	Queen (U.S. Standard)
Product Dimensions (L x W x H)	86.6"L x 62.2"W x 40.6"H
Color	Rustic Brown and Black
Material	P2 high-duty MDF board, Black metal, PU upholstered headboard
Special Features	Fade Resistant, No Box Spring Needed, Squeak Resistant, Storage Headboard, USB Port
Compatible Mattress Size	Queen -- 60 x 80 inches (or 153 x 203 cm)
Ground To Item Distance	10.6 Inches
Item Weight	67 pounds
Assembly Required	Yes

Warranty and Support

Specific warranty details for the ANCTOR Queen Bed Frame are not provided within this manual. For information regarding warranty coverage, claims, or technical support, please contact the manufacturer directly or refer to the product listing on the retailer's website where you purchased the item.
For further assistance or inquiries, please reach out to ANCTOR customer service through their official channels.

© 2024 ANCTOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question