RemotesReplaced RRS41

RemotesReplaced Remote Control User Manual

Compatible with SABA SB32HDS195

1. Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, designed to be fully compatible with the SABA SB32HDS195 television model. It offers all the functionalities of the original remote without requiring complex setup. Please read this manual carefully before using the remote control.

2. Product Overview

The RemotesReplaced remote control is an electronically identical replacement, ensuring seamless operation with your SABA SB32HDS195 TV. Its design and button layout are optimized for intuitive use.



Image: Front view of the RemotesReplaced remote control, showing all buttons and their labels. The remote is black with clearly marked white and colored buttons.

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA batteries (not included). No setup codes are required; the remote is ready for use immediately after battery installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, showing the battery compartment cover.



Image: Bottom view of the remote control, highlighting the battery compartment.

4. Operating Instructions

This remote control provides access to all functions of your SABA SB32HDS195 television. Point the remote control directly at the TV's infrared sensor for optimal performance.

4.1 Basic Functions

- **Power (Red Button):** Turns the TV on or off.
- **Mute:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Up/Down (V+/V-):** Adjusts the volume level.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Source:** Selects input sources (e.g., TV, SAT, DVD, AUX).
- **Menu:** Accesses the TV's main menu.
- **OK:** Confirms selections within menus.
- **Navigation Arrows (Up, Down, Left, Right):** Navigate through menus and options.

4.2 Advanced Functions

- **NET TV:** Accesses smart TV features or streaming services.
- **SMART:** Opens the smart TV interface.
- **EPG (Electronic Program Guide):** Displays program information.
- **INFO:** Shows current channel or program details.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the TV.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or smart TV applications, as indicated on screen.



Image: Top view of the remote control, highlighting the infrared (IR) emitter, which must be pointed towards the TV.

5. Maintenance

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the surface and markings.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

6. Troubleshooting

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace the batteries with new ones.
- Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- Point the remote directly at the TV's IR sensor.

- **Some buttons not working:**
  - This may indicate low battery power. Replace batteries.
  - Ensure the remote is compatible with your specific TV model (SABA SB32HDS195).
- **TV not turning on/off:**
  - Verify the TV is plugged into a power outlet and is not in standby mode due to a power outage.
  - Try using the power button on the TV itself.

If issues persist after following these steps, please contact customer support.

7. Specifications

Feature	Detail
Brand	RemotesReplaced
Compatible TV Model	SABA SB32HDS195
Remote Model	RRS41
Batteries Required	2 x AAA (not included)
Weight	120 Grams
Manufacturer	Linkwebb
ASIN	B0CP2F5Y44

8. Warranty and Support

This RemotesReplaced product comes with a 1-year warranty. For warranty claims or technical support, please contact the seller directly through your purchase platform.

For more information or assistance, please visit the RemotesReplaced brand store or contact customer service.

© 2023 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question