Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 0C463100AR0

Ariete 4631 Dual Air Fryer 9L - Instruction Manual

Model: 0C463100AR0

1. Introduction

Welcome to the instruction manual for your new Ariete 4631 Dual Air Fryer. This appliance is designed to provide a healthier way to cook your favorite fried foods, using significantly less oil. With its 9-liter total capacity across two independent baskets, 2400W power, and 11 pre-set programs, it offers versatility and convenience for preparing a wide range of dishes. Please read this manual thoroughly before first use to ensure safe and optimal operation of your air fryer.



Image: The Ariete 4631 Dual Air Fryer positioned on a wooden counter in a kitchen, surrounded by various cooked dishes such as french fries, onion rings, and shrimp, showcasing its use in preparing a meal.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Keep the appliance and its cord out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure adequate ventilation around the appliance during operation. Do not block any ventilation openings.
- Surfaces may become hot during use. Use oven mitts when handling hot components.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm of free space on the back and sides and 10 cm of free space above the appliance.
- This appliance is for household use only. Do not use outdoors.

3. Product Overview

Familiarize yourself with the components of your Ariete 4631 Dual Air Fryer.

Components:

- Main Unit with Control Panel
- Left Frying Basket (4.5L capacity)
- Right Frying Basket (4.5L capacity)
- Two Removable Crisper Plates



Image: A clear front view of the Ariete 4631 Dual Air Fryer, highlighting its sleek black design, the prominent digital control panel, and the two baskets with transparent fronts, allowing visibility of food during cooking.

Control Panel:

The intuitive touchscreen control panel allows you to manage cooking settings for both baskets independently or simultaneously.

- **Temperature Controls:** Adjust temperature up to 200°C.
- **Time Controls:** Set cooking time.
- **Pre-set Program Icons:** Select from 11 pre-programmed cooking modes.
- **DUAL COOK Button:** Apply the same settings to both baskets.
- **SYNC FINISH Button:** Synchronize cooking times so both baskets finish at the same time.
- **START/STOP Buttons:** Initiate or pause cooking.
- **SHAKE Reminder:** An icon may illuminate to remind you to shake the basket for even cooking.
- **MAX CRISP:** Dedicated function for achieving maximum crispiness.
- **GRILL:** Dedicated function for grilling.
- **DRYING:** Dedicated function for dehydrating.



Image: A close-up shot showing a hand pressing a button on the digital touchscreen control panel of the Ariete Dual Air Fryer, illustrating the user interface.

4. Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Check that all components listed in the "Product Overview" section are present and undamaged.

Before First Use:

1. Wash the frying baskets and crisper plates thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
2. Wipe the inside and outside of the main unit with a damp cloth. Do not immerse the main unit in water.
3. Place the crisper plates inside the baskets. Ensure they are securely seated.



Image: The two removable air fryer baskets and their corresponding crisper plates are shown detached from the main unit, illustrating their separate components for cleaning or preparation.

Placement:

- Place the air fryer on a stable, heat-resistant, and level surface.
- Ensure there is sufficient space (at least 10 cm) around the appliance for proper air circulation.

5. Operating Instructions

Basic Operation:

1. Plug the power cord into a grounded wall outlet. The control panel will illuminate.
2. Carefully pull out the desired frying basket(s) from the main unit.
3. Place your ingredients into the basket(s) on top of the crisper plate. Do not overfill. For best results, a small amount of oil (e.g., one spoon) can be added to some foods.

4. Slide the basket(s) back into the air fryer until they click into place.
5. On the control panel, select the basket you wish to program (1 or 2).
6. Adjust the temperature using the temperature controls (up to 200°C).
7. Set the cooking time using the time controls.
8. Press the **START** button to begin cooking.



Image: A spoon is shown pouring a minimal amount of cooking oil over a batch of french fries placed inside one of the Ariete Dual Air Fryer's baskets, demonstrating the low-oil cooking method.

Using Pre-set Programs:

The air fryer comes with 11 pre-set programs for common foods.

1. Load your ingredients into the basket(s).
2. Select the basket (1 or 2) you want to program.
3. Press the pre-set program icon corresponding to your food type. The air fryer will automatically set the optimal temperature and time.
4. You can manually adjust the pre-set temperature and time if desired.
5. Press **START**.

Special Functions:

- **DUAL COOK:** If you want both baskets to cook with the exact same settings, load both baskets, set the desired temperature and time for one basket, then press the **DUAL COOK** button. This will mirror the settings to the other basket. Press **START**.
- **SYNC FINISH:** This function allows two different foods, with different cooking times, to finish cooking simultaneously. Program each basket with its respective time and temperature. Then, press the **SYNC FINISH** button. The air fryer will automatically adjust the start time of the basket with the shorter cooking duration. Press **START**.
- **SHAKE Reminder:** For certain foods, the air fryer may beep and display a "SHAKE" icon to remind you to shake the basket for even cooking. Pull out the basket, shake the contents, and reinsert the basket to resume cooking.
- **MAX CRISP** / **GRILL** / **DRYING:** These dedicated buttons activate specific cooking modes optimized for crisping, grilling, or dehydrating. Select the basket, press the desired function button, adjust time/temperature if needed, and press **START**.



Image: The two separate baskets of the Ariete Dual Air Fryer are shown, with one basket holding crispy chicken nuggets and the other containing a saucy meatball dish, illustrating the appliance's ability to cook two different items simultaneously.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Baskets and Crisper Plates:** These parts are non-stick coated and can be washed in the dishwasher or by hand with hot water, dish soap, and a non-abrasive sponge. Do not use metal utensils or abrasive cleaning materials.
3. **Main Unit:** Wipe the exterior and interior of the main unit with a damp cloth. For stubborn stains, use a mild detergent. Never immerse the main unit in water or rinse it under running water.
4. Ensure all parts are completely dry before storing or using the appliance again.



Image: The two empty air fryer baskets are shown pulled out from the main unit, clearly displaying the removable crisper plates at the bottom of each basket, indicating they are ready for cleaning or preparation.

7. Troubleshooting

If you encounter issues with your air fryer, consult the following table for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push baskets fully into the unit until they click.
Food is not cooked evenly.	Basket overloaded; food not shaken or flipped.	Do not overload the basket. Shake or flip ingredients halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Greasy residue from previous use; high-fat food.	Clean the baskets and crisper plates thoroughly. For high-fat foods, drain excess fat during cooking.
Food is not crispy.	Not enough oil (for some foods); temperature too low; cooking time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time. Use the MAX CRISP function.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Model: 0C463100AR0

Brand: Ariete

Power: 2400 W

Total Capacity: 9 Liters (2 x 4.5L baskets)

Temperature Range: Up to 200°C

Dimensions (L x W x H): 40.5 x 33 x 35.5 cm

Weight: 3.6 kg

Material: Plastic

Color: Black

Programs: 11 pre-set programs

Special Features: Dual Cook, Sync Finish, Max Crisp, Grill, Shake, Drying functions, Touchscreen control panel.

9. Warranty and Support

Specific warranty details for the Ariete 4631 Dual Air Fryer are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product packaging or contact the retailer from whom you purchased the appliance.
For technical support, spare parts, or service inquiries, please visit the official Ariete website or contact their customer service department.
Ariete Official Website: www.ariete.net

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP3S92W3

More documents and user manuals: **https://manuals.plus/**