Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 4632

Ariete 4632 Vintage Air Fryer Oven

Instruction Manual

Model: 4632 | Brand: Ariete

1. Introduction

Thank you for purchasing the Ariete 4632 Vintage Air Fryer Oven. This appliance is designed to offer a versatile cooking experience, combining the functions of an air fryer and a compact oven. It allows for healthy cooking with minimal oil while delivering crispy and delicious results. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the appliance during operation.

3. Package Contents

Carefully unpack your Ariete 4632 Air Fryer Oven and ensure all items are present and in good condition. The package should include:

- Ariete 4632 Vintage Air Fryer Oven unit
- 3 x Perforated Stainless Steel Baskets
- 1 x Rotating Stainless Steel Basket
- 1 x Stainless Steel Grill
- 1 x Stainless Steel Rotisserie Set
- 1 x Drip Tray (for fat and crumbs)
- 1 x Handle (for removing hot accessories)



Image 3.1: The included accessories: 3 grids, drip tray for fat and crumbs, rotating basket, rotisserie spit, and handle.

4. Product Components and Controls

Familiarize yourself with the main parts and control dials of your appliance.



Image 4.1: Front view of the Ariete 4632 Air Fryer Oven, showing the control dials and viewing window.



Image 4.2: Close-up of the control panel, indicating cooking types, temperature, and timer settings.

Control Dials:

- **Function Dial (Left):** Selects the cooking mode (Oven or Air Fryer).
- **Temperature Dial (Middle):** Adjusts the cooking temperature up to 230°C.
- **Timer Dial (Right):** Sets the cooking time up to 60 minutes. The appliance will automatically switch off when the timer reaches zero.

5. Initial Setup

1. **Unpacking:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash all removable accessories (baskets, grill, drip tray, rotisserie set) with warm, soapy water. Rinse thoroughly and dry completely before use.
3. **Placement:** Place the appliance on a stable, heat-resistant, and level surface. Ensure there is at least 10 cm of clear space on all sides and above the appliance for proper ventilation. Do not place it near walls or under cabinets.
4. **First Use Pre-heating:** Before cooking food, it is recommended to run the appliance for about 15 minutes without

food to burn off any manufacturing residues. Set the function to 'Oven', temperature to 200°C, and timer to 15 minutes. A slight odor or smoke may be present during this initial use; this is normal.

6. Operating Instructions

The Ariete 4632 offers two primary cooking functions: Air Frying and Oven baking/roasting.

6.1. Air Frying Function

1. Place the desired perforated basket(s) or the rotating basket inside the oven.
2. Place your food inside the basket(s). For best results, do not overcrowd the baskets.
3. Close the oven door securely.
4. Turn the **Function Dial** to the 'Air Fryer' setting.
5. Turn the **Temperature Dial** to your desired cooking temperature (up to 230°C).
6. Turn the **Timer Dial** to the required cooking time (up to 60 minutes). The appliance will begin heating.
7. The indicator light will illuminate during operation.
8. When the timer reaches zero, the appliance will automatically switch off, and a bell will sound.
9. Carefully remove the cooked food using the handle or oven mitts.

6.2. Oven Function

1. Place your food on the stainless steel grill or in an oven-safe dish on the grill.
2. Insert the grill into the desired rack position inside the oven.
3. Close the oven door securely.
4. Turn the **Function Dial** to the 'Oven' setting.
5. Turn the **Temperature Dial** to your desired cooking temperature (up to 230°C).
6. Turn the **Timer Dial** to the required cooking time (up to 60 minutes). The appliance will begin heating.
7. The indicator light will illuminate during operation.
8. When the timer reaches zero, the appliance will automatically switch off, and a bell will sound.
9. Carefully remove the cooked food using oven mitts.

6.3. Rotisserie Function

The rotisserie function is ideal for roasting whole chickens or larger cuts of meat.

1. Assemble the rotisserie spit and forks, securing your food item firmly in the center.
2. Insert the rotisserie spit into the designated slots inside the oven.
3. Close the oven door securely.
4. Turn the **Function Dial** to the 'Oven' setting (the rotisserie motor operates in oven mode).
5. Turn the **Temperature Dial** to your desired cooking temperature.
6. Turn the **Timer Dial** to the required cooking time.
7. Monitor cooking through the viewing window.
8. Once cooking is complete, use the handle to carefully remove the hot rotisserie spit.



Image 6.1: The Ariete 4632 Air Fryer Oven demonstrating its versatility with rotisserie chicken, easy cleaning, and 16-liter capacity.

7. Cooking Guide and Tips

The Ariete 4632 Air Fryer Oven offers a wide range of cooking possibilities. Here are some examples of foods you can prepare:



Image 7.1: Examples of infinite possibilities for cooking with the Ariete 4632, including French fries, desserts, skewers, dehydration, fresh potatoes, fish, red meat, shellfish, croquettes, chicken, rotisserie chicken, and reheating.

- **French Fries:** Achieve crispy fries with minimal oil.
- **Desserts:** Bake cakes, cookies, and other sweet treats.
- **Skewers:** Cook meat and vegetable skewers evenly.
- **Dehydration:** Prepare dried fruits and vegetables.
- **Fish & Meat:** Roast or air fry various types of fish, red meat, and chicken.
- **Croquettes & Shellfish:** Cook breaded items to a perfect crisp.
- **Reheating:** Warm up leftovers without drying them out.

Tips for Best Results:

- For even cooking, shake or flip smaller food items halfway through the cooking time.
- Preheat the oven for a few minutes before adding food for better results.
- Do not overload the baskets or racks to allow hot air to circulate freely.
- A light spray of oil can enhance crispiness for some foods.



Image 7.2: The Ariete 4632 Air Fryer Oven effectively dehydrating various fruits.

8. Cleaning and Maintenance

Regular cleaning ensures the longevity and optimal performance of your appliance.

1. **Always unplug** the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive sponge can be used. Ensure the interior is dry before next use.
4. **Accessories:** All removable accessories (baskets, grill, drip tray, rotisserie set) can be washed in warm, soapy water or in a dishwasher. Rinse thoroughly and dry completely.
5. **Drip Tray:** Empty and clean the drip tray after each use to prevent grease buildup and smoke.
6. Do not immerse the main unit in water or any other liquid.

9. Troubleshooting

If you encounter any issues with your Ariete 4632 Air Fryer Oven, please refer to the following common problems and solutions:

- **Appliance does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the timer is set. The appliance will not operate if the timer is at zero.
- **Food is not cooked evenly:**
  - Do not overcrowd the baskets or racks. Cook in smaller batches if necessary.
  - Shake or flip food items halfway through cooking.
  - Ensure the correct temperature and cooking time are selected for the food type.
- **White smoke coming from the appliance:**
  - This may be due to grease residue from previous use. Clean the drip tray and interior thoroughly.
  - If cooking fatty foods, excess fat may drip onto the heating element. Use the drip tray.
- **Food is not crispy:**
  - Ensure food is not overcrowded.
  - A light spray of oil can help achieve crispiness.
  - Increase cooking time or temperature slightly.

If the problem persists after trying these solutions, please contact customer support.

10. Technical Specifications

Brand	Ariete
Model Number	4632/03
Capacity	16 Liters
Power	1400 Watts (Output Power: 1500 Watts)
Voltage	220 Volts (AC)
Material	Stainless Steel
Dimensions (L x W x H)	34 x 34 x 34 cm
Item Weight	6.5 Kilograms
Max Temperature	230°C
Max Timer	60 minutes
Special Feature	Multifunction (Air Fryer & Oven)



Image 10.1: Product dimensions: Length 34 cm x Depth 34 cm x Height 34 cm.

11. Warranty and Support

Your Ariete 4632 Vintage Air Fryer Oven is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, troubleshooting beyond this manual, or to inquire about spare parts, please contact Ariete customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP45V6CX

More documents and user manuals: **https://manuals.plus/**