Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 8003705122451

Ariete 4632 Vintage Air Fryer and Oven

User Manual

Model: 8003705122451 | Brand: Ariete

Introduction

Thank you for choosing the Ariete 4632 Vintage Air Fryer and Oven. This versatile 2-in-1 appliance combines the efficiency of an air fryer with the functionality of a compact oven, allowing you to prepare a wide variety of dishes with less oil and effort. Its vintage design adds a touch of retro style to any kitchen. Please read this manual carefully before using the appliance to ensure safe and optimal operation.



The Ariete 4632 Vintage Air Fryer and Oven, showcasing its elegant light blue finish and front controls.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure adequate ventilation around the appliance during operation.

Product Overview

Components and Controls

The Ariete 4632 features intuitive manual controls and a range of accessories to enhance your cooking experience.



Detailed view of the control panel, showing the temperature, function, and timer knobs.

- **Temperature Control Knob:** Adjusts cooking temperature up to 230°C.
- **Function Selector Knob:** Selects between oven and air fryer modes.
- **Timer Knob:** Sets cooking time up to 60 minutes.
- **Double Glass Door:** Provides insulation and allows viewing of food.

Included Accessories

Your Ariete 4632 comes with a comprehensive set of accessories for various cooking needs:



A complete set of accessories, including baskets, grill, rotisserie, and drip tray.

- **3 Stainless Steel Perforated Baskets:** Ideal for air frying smaller items like fries or vegetables.
- **Stainless Steel Rotating Basket:** Perfect for even cooking of items like popcorn or nuts.
- **Stainless Steel Grill:** For baking, roasting, or grilling.
- **Stainless Steel Rotisserie Set:** For roasting whole chickens or larger cuts of meat.
- **Drip Tray:** Collects excess oil and crumbs for easier cleaning.
- **Handle:** For safely removing hot accessories.

Setup

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash all removable accessories (baskets, grill, rotisserie, drip tray) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the air fryer oven on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 10-15 cm) around all sides of the appliance for proper ventilation. Do not place it near walls or under

cabinets that are sensitive to heat or steam.

4. **Power Connection:** Ensure the voltage of your power outlet matches the voltage specified on the appliance (220 Volts). Plug the power cord into a grounded wall outlet.

Operating Instructions

General Operation

The Ariete 4632 functions as both an air fryer and a compact oven, offering versatility for various cooking methods.



The appliance's versatility is demonstrated by its ability to cook a wide range of dishes, from fried foods to baked goods.

1. **Prepare Food:** Place your food inside the appropriate accessory (basket, grill, rotisserie) and insert it into the oven. Ensure the drip tray is in place at the bottom.
2. **Select Function:** Turn the Function Selector Knob to either "Air Fry" or "Oven" mode, depending on your desired cooking method.
3. **Set Temperature:** Turn the Temperature Control Knob to the desired cooking temperature (up to 230°C).
4. **Set Timer:** Turn the Timer Knob to the desired cooking time (up to 60 minutes). The appliance will begin heating and cooking. A light inside the oven will illuminate during operation.
5. **Monitoring:** You can open the double glass door to check on your food during cooking. The appliance will continue to operate when the door is open.
6. **Completion:** Once the timer reaches zero, a bell will sound, and the appliance will automatically turn off. Carefully

remove the cooked food using oven mitts and the provided handle for accessories.

Air Frying Tips

- For best results with air frying, toss food with a small amount of oil (e.g., 1 tablespoon) before placing it in the basket.
- Do not overcrowd the basket; cook in batches if necessary to ensure even crisping.
- Shake or flip food halfway through cooking for uniform results.
- The high temperature air circulation ensures quick cooking without excessive fat, minimizing smoke and odors.

Maintenance and Cleaning

Regular cleaning will prolong the life of your appliance and ensure hygienic operation.



The oven door opens wide, revealing an interior designed for easy cleaning.

1. **Always Unplug:** Before cleaning, always unplug the appliance from the power outlet and allow it to cool down

completely.

2. **Removable Accessories:** Wash all removable accessories (baskets, grill, rotisserie, drip tray) in warm, soapy water. They are generally dishwasher safe, but hand washing is recommended to preserve their finish. Rinse thoroughly and dry completely before storing or re-using.
3. **Interior Cleaning:** Wipe the interior surfaces of the oven with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Do not use abrasive cleaners or metal scouring pads.
4. **Exterior Cleaning:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Never Immerse:** Never immerse the main unit (housing with electrical components) in water or any other liquid.

Troubleshooting

If you encounter any issues with your Ariete 4632, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; timer not set.	Ensure plug is securely in a working outlet. Turn the timer knob to the desired cooking time.
Food is not cooked evenly.	Overcrowding; insufficient shaking/flipping.	Cook in smaller batches. Shake or flip food halfway through cooking.
White smoke coming from appliance.	Grease/oil residue; fatty food.	Clean the drip tray and interior thoroughly. For fatty foods, ensure proper ventilation and use less oil.
Food not crispy enough.	Too much moisture; not enough oil; temperature too low.	Pat food dry before cooking. Toss with a small amount of oil. Increase temperature slightly.

If the problem persists after trying these solutions, please contact Ariete customer support.

Specifications

Brand: Ariete

Model Number: 8003705122451

Color: Light Blue

Product Dimensions: 34 x 34 x 34 cm

Capacity: 16 Liters

Power / **Wattage:** 1400 watts

Voltage: 220 Volts

Material: Glass (door)

Item Weight: 6.5 Kilograms

Special Features: Temperature Control, Timer



Dimensional diagram of the Ariete 4632, indicating its compact size.

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Ariete website. Keep your proof of purchase for warranty claims.
You can also visit the Ariete Store on Amazon for more product information and support resources.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP47RZTB

More documents and user manuals: **https://manuals.plus/**