Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEEDECK TR-MNR601

BEEDECK Cordless Mini Chainsaw User Manual

Model: TR-MNR601

Important Safety Information

Always read and understand all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- **Eye Protection:** Always wear appropriate eye protection, such as the included splash glasses, when operating the chainsaw.
- **Hand Protection:** Use the provided protective gloves to ensure a secure grip and protect your hands.
- **Accidental Start Prevention:** Before operation, ensure the safety lock button is pressed before pulling the trigger. This prevents unintentional activation.
- **Clear Work Area:** Keep the work area clear of debris and bystanders.
- **Proper Grip:** Always maintain a firm, two-handed grip on the chainsaw during operation, even though it is designed for one-handed use for light tasks.
- **Chain Oil:** Ensure the chain is properly lubricated before each use. Chain oil is not included and must be purchased separately.
- **Battery Safety:** Use only the specified battery and charger. Do not expose the battery to extreme temperatures or moisture.

Package Contents

Verify that all items are present and in good condition upon opening the package:

- 1 x BEEDECK 6-Inch Mini Electric Chainsaw
- 1 x 20V Max Lithium-Ion Battery
- 1 x Wall Charger
- 1 x Quenched Chain
- 1 x Guide Plate Protection Case
- 1 x Protective Gloves
- 1 x Splash Glasses
- 1 x Screwdriver
- 1 x User Manual (this document)



Image: Contents of the BEEDECK Cordless Mini Chainsaw package, including the chainsaw, battery, charger, chain, guide plate cover, gloves, splash glasses, and screwdriver.

Setup

1. Battery Charging

Before first use, fully charge the 20V Lithium-Ion battery. Connect the wall charger to the battery and plug it into a standard electrical outlet. The charging indicator light on the charger will indicate the charging status.



Image: Close-up of the 20V Max Lithium-Ion battery, highlighting its capacity and protection features.

2. Chain and Guide Plate Installation

The BEEDECK mini chainsaw features a tool-free installation and tensioning system. Follow these steps to install the chain and guide plate:

1. Unscrew the button and open the lid of the sprocket cover. No wrench is needed.
2. Carefully place the chain around the guide plate, ensuring the cutting direction of the chain is correct. Do not install it in the opposite direction.
3. Align the guide plate and chain with the chainsaw's drive sprocket.
4. Tighten the tensioning knob to adjust the chain tension. The chain should be snug but still able to move freely around the guide bar.
5. Close the lid and tighten the knob securely.



Image: Visual guide showing the four steps for tool-free chain and guide plate installation on the mini chainsaw.

3. Attaching the Battery

Slide the charged battery pack into the base of the chainsaw handle until it clicks securely into place.

4. Installing the Trigger Guard

Attach the trigger guard to the designated slot near the trigger for added safety during operation.

Your browser does not support the video tag.

Video: An unboxing and initial setup guide for the 6-inch mini chainsaw, demonstrating the components and basic assembly.

Operating Instructions

The BEEDECK Cordless Mini Chainsaw is designed for efficient cutting of wood, trimming, and woodworking tasks. Always prioritize safety during operation.

Starting the Chainsaw

1. Ensure the battery is fully charged and securely attached.
2. Hold the chainsaw firmly with one hand on the ergonomic, non-slip handle.
3. To activate the chainsaw, first press the safety lock button (located near the trigger) and then pull the variable speed trigger switch. The chain will begin to move.

Cutting Techniques

- Apply light pressure when cutting. The chainsaw's high-efficiency copper wire motor provides strong power and fast chain speed (19.2 ft/s) for quick cuts.
- For optimal performance and to prevent overheating, avoid continuous heavy cutting. Allow the motor to cool down periodically.
- The 6-inch blade is ideal for pruning trees, home improvement tasks, and general wood cutting.



Image: Diagram illustrating the main components of the mini chainsaw, including the guide plate, chain saw, sprocket cover, protective board, variable speed trigger switch, battery release button, battery pack, security lock button, tensioning knob, and cover plate.



Image: Demonstrates the chainsaw's high-efficient cutting capability with a chain speed of 19.2 feet per second, capable of cutting a 6-inch log in approximately 4 seconds.

Maintenance

- **Chain Lubrication:** Regularly apply chain oil to the guide bar and chain to ensure smooth operation and extend the life of the chain. Chain oil is not included.
- **Chain Tension:** Periodically check and adjust the chain tension. A properly tensioned chain should not sag but should still be able to be pulled freely by hand.
- **Cleaning:** After each use, remove the battery and clean the chainsaw. Use a brush or compressed air to remove sawdust and debris from the chain, guide bar, and motor vents. The chainsaw features fast heat dissipation to prevent overheating.
- **Storage:** Store the chainsaw in a dry, secure place, out of reach of children. Always attach the guide plate protection case when storing.



Image: Illustrates the fast heat dissipation design of the chainsaw's motor, showing airflow arrows for cooling.

Troubleshooting

Problem	Possible Cause	Solution
Chainsaw does not start.	Battery not charged or not properly inserted. Safety lock not engaged.	Ensure battery is fully charged and securely clicked into place. Press the safety lock button before pulling the trigger.
Chain is not moving smoothly.	Insufficient chain lubrication. Incorrect chain tension.	Apply chain oil. Adjust chain tension using the tensioning knob.
Reduced cutting performance.	Dull chain. Overheating.	Replace or sharpen the chain. Allow the chainsaw to cool down.

Problem	Possible Cause	Solution
Battery drains quickly.	Battery not fully charged. Old or damaged battery.	Ensure battery is fully charged before use. Consider replacing the battery if it's old or damaged.

Specifications

Feature	Detail
Brand	BEEDECK
Model Number	TR-MNR601
Power Source	Battery Powered
Voltage	20 Volts (DC)
Wattage	650 watts
Horsepower	750 Watts
Item Weight	2.3 Pounds
Product Dimensions	6"L x 3.2"W x 15.8"H
Chain Length	6 Inches
Material	Plastic
Color	Red
UPC	763967741668

Warranty and Support

BEEDECK offers a 12-month warranty for the motor and battery of this product. For any questions or concerns, please contact BEEDECK customer service. They provide 24-hour friendly customer service to assist with any after-sales inquiries.

For further assistance, you may refer to the official Instructions for Use (IFU) PDF document available here.

© 2025 BEEDECK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP61F1BD

More documents and user manuals: **https://manuals.plus/**