Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Allparts Equipment & Accessories 0.584.040

Allparts Equipment & Accessories Sit Proflame 2 Remote Transmitter 0.584.040 User Manual

Model: 0.584.040

Introduction | Setup | Operation | Features | Specifications | Troubleshooting | Warranty & Support

1. Introduction

The Allparts Equipment & Accessories Sit Proflame 2 Remote Transmitter, model 0.584.040, is designed to provide comprehensive control over Proflame 2 IFC Electronic Ignition Control modules used in various hearth products. This updated version seamlessly replaces all previous Proflame 2 transmitter versions (0.584.040) with a simple programming process. It offers advanced features for managing your fireplace experience with ease and precision.



Image: Overview banner for the Proflame 2 Fireplace Remote Transmitter.

2. Setup and Installation

2.1 Unboxing the Remote Transmitter

Upon receiving your Sit Proflame 2 Remote Transmitter, carefully unbox the unit. Ensure all components are present and inspect for any damage. Refer to the enclosed instructions for detailed setup procedures.

Video: An unboxing of the 0.584.040 Proflame 2 Remote, showing the contents of the package.



Image: The Proflame 2 Remote Transmitter being unboxed, revealing the remote and instruction manual.

2.2 Battery Installation

The Sit Proflame 2 transmitter (0.584.040) requires 3 AAA batteries for operation. Batteries are not included with the remote. To install, open the battery compartment on the back of the remote and insert the batteries, ensuring correct polarity. Close the compartment securely.



©Allparts Equipment & Accesories Inc

Image: The back of the Proflame 2 Remote Transmitter, illustrating the battery compartment where 3 AAA batteries are inserted.

2.3 Pairing with IFC Control Module

This remote is designed for seamless replacement and pairing with your Proflame 2 IFC Electronic Ignition Control module. Follow the specific programming instructions provided in the manual included with your remote to establish a connection. Typically, this involves a simple button-push sequence on both the remote and the IFC module.

Setup of the Proflame 2 Remote Transmitter to your IFC Control Module

See the Enclosed Instructions for further details.



©Allparts Equipment & Accesories Inc

0.584.040 will replace the following:

All Proflame 1 Remotes (0.584.021 – 0.584.028)

Proflame 2 Remotes (0.584.040, 0.584.041, and 0.584.042)

Image: The Proflame 2 Remote Transmitter shown alongside its battery compartment, highlighting the model number 0.584.040.

3. Operation

The Proflame 2 Remote Transmitter provides comprehensive control over your fireplace's functions. Its ergonomic design ensures comfortable and intuitive use.

Video: Demonstration of basic operation of a Fireplace Remote Transmitter, showing how to turn the fireplace on and off.

3.1 Basic Controls

- **Power On/Off:** Use the dedicated power button to activate or deactivate your fireplace.
- **Temperature Control:** Adjust the desired room temperature using the up/down arrows. The remote features a Smart Sense room management system.
- **Flame Height Adjustment:** Control the intensity of the flame to suit your preference.
- **Fan Speed:** Regulate the speed of the fireplace fan for optimal heat distribution.



Image: The remote control with labels indicating the functions of its buttons, including On/Off, Temperature Control, Selector, and Modes.

3.2 Advanced Functions

- **Accent Lights:** Control any integrated accent lighting features of your hearth product.
- **Split Flow Valve:** Manage the split flow valve for specific burner operations.
- **CPI/IPI Ignition:** Switch between Continuous Pilot Ignition (CPI) and Intermittent Pilot Ignition (IPI) modes for burner operation.
- **Accessories:** Control other compatible accessories connected to your IFC module.

Video: A user demonstrating the functions of the 0.584.040 Fireplace Remote Transmitter, including turning the fireplace on and adjusting settings.

4. Key Features

- **Seamless Replacement:** Designed to replace all previous versions of the Proflame 2 transmitter 0.584.040 with a simple programming button push.
- **Comprehensive Control:** Manages temperature, flame height, fan speed, accent lights, split flow valve, accessories, Smart Sense room management, and CPI/IPI ignition.
- **Ergonomic Design:** Provides all functionality in an attractive and comfortable-to-hold design.
- **Backlit Display:** Clear and easy-to-read display for all settings and feedback.



Image: Close-up of the Proflame 2 Remote Transmitter's backlit display, showing temperature and other operational icons for clear visibility.

5. Specifications

Feature	Detail
Model Number	0.584.040
Brand	Allparts Equipment & Accessories
Power Source	3 AAA batteries (not included)
Compatible Devices	Hearth Products (Fireplace, Gas Log Set, Pedestal Stoves) with Proflame 2 IFC modules
Special Features	Smart Sense, Adjustable Flame, Fan Control, Accent Lights, Split Flow, CPI/IPI Pilot, AUX
Color	Black
Item Weight	10.4 ounces
Package Dimensions	8 x 5 x 2 inches

6. Troubleshooting

6.1 Remote Not Responding

- **Check Batteries:** Ensure fresh AAA batteries are correctly installed in the remote. Low batteries can cause intermittent or no response.
- **Re-pair Remote:** If the remote was previously working and stopped, try re-pairing it with your IFC module according to the setup instructions.
- **Obstruction:** Ensure there are no physical obstructions between the remote and the fireplace's receiver.

6.2 Fireplace Not Igniting

- **Verify Model Number:** As a caution, ensure the remote transmitter model number 0.584.040 exactly matches the one you are replacing. Other numbers may have different features and may not be compatible.
- **Gas Supply:** Confirm that the gas supply to your fireplace is open and functioning correctly.
- **IFC Module Status:** Check the status of your Proflame 2 IFC module for any error indicators.

7. Warranty and Support

7.1 Warranty Information

Specific warranty details are typically provided with your product packaging or can be obtained from the manufacturer, Sit Controls Group, or your retailer. Please retain your proof of purchase for warranty claims.

7.2 Technical Support

Allparts Equipment & Accessories offers USA-based technical support with over 50 combined years of experience. For any questions or issues regarding your Sit Proflame 2 Remote Transmitter, please contact our support team for assistance.

© 2026 Allparts Equipment & Accessories. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP65ZKY9

More documents and user manuals: **https://manuals.plus/**