Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hatteker 612

Hatteker Professional Pet Clipper User Manual

Model: 612

1. Introduction

Thank you for choosing the Hatteker Professional Pet Clipper. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new pet grooming tool. Please read this manual thoroughly before first use and keep it for future reference.
This clipper is designed for professional and home use, offering precise and safe grooming for various pet hair types, including dogs and cats. Its advanced features ensure a comfortable and efficient grooming experience for both you and your pet.

2. Important Safety Instructions

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions when using electrical appliances:

- Read all instructions before using this appliance.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning, putting on or taking off parts.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use this appliance with a damaged or broken comb, as facial injury may occur.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to "off" then remove plug from

outlet.

- Ensure the pet's fur is clean and dry before grooming to prevent blade clogging and ensure optimal performance.
- Be cautious around sensitive areas of the pet, such as ears, eyes, and paws.

3. Package Contents

Upon opening the package, please verify that all the following items are included:

- Hatteker Professional Pet Clipper (Model 612)
- 6 Guide Combs (3mm, 6mm, 9mm, 12mm, 16mm, 19mm)
- Stainless Steel Scissors
- Stainless Steel Pet Comb
- USB-C Charging Cable
- Cleaning Brush
- Lubricating Oil Bottle
- User Manual



Image: Contents of the Hatteker Professional Pet Clipper package.

4. Product Features

The Hatteker Professional Pet Clipper is equipped with several features designed for optimal grooming performance:

- **Durable Metal Blades:** Self-sharpening, hypoallergenic blades provide precise and safe grooming, remaining cool and gentle on your pet's skin.
- **Smart LED Display:** An intelligent display shows remaining power, current speed (RPM), and reminders for oiling/charging.
- **Auxiliary Illumination Light:** A built-in light on the clipper head assists in grooming even in dimly lit areas.
- **Powerful Motor:** Delivers consistent performance with three adjustable speeds.

- **High Energy Lithium Battery:** Provides up to 180 minutes of cordless operation on a full charge.
- **Corded/Cordless Use:** The clipper can be used wirelessly or while plugged in for continuous operation.
- **Three-Speed Adjustment:** Select from 6500 RPM, 7000 RPM, or 7500 RPM to suit different grooming needs and hair types.
- **Low Noise Operation:** Engineered for quiet performance (approx. 55dB), minimizing stress for sensitive pets.
- **Removable Cutterhead:** The blade assembly can be easily detached for thorough cleaning.
- **USB-C Charging:** Convenient and universal charging interface.



Image: Overview of the clipper's main features.



Image: Detailed view of the LED display and power specifications.



Image: Low noise operation for pet comfort.

5. Setup

5.1. Charging the Clipper

1. Before first use, fully charge the clipper.
2. Connect the USB-C charging cable to the port at the bottom of the clipper.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
4. The LED display will indicate the charging status. A full charge typically takes approximately 3 hours.
5. Once fully charged, the display will show 100% power. Unplug the clipper.

5.2. Attaching Guide Combs

1. Ensure the clipper is turned off before attaching or removing guide combs.
2. Select the desired guide comb length (3mm, 6mm, 9mm, 12mm, 16mm, or 19mm).

3. Align the guide comb with the clipper blade and slide it on until it clicks securely into place.
4. To remove, gently push the comb upwards from the back while holding the clipper firmly.

6. Operating Instructions

6.1. Preparing Your Pet

- Bathe and dry your pet thoroughly before grooming. Clean fur is easier to cut and helps prevent blade dulling.
- Brush your pet's fur to remove any tangles or mats. This ensures a smooth and even cut.
- Familiarize your pet with the clipper's sound and vibration before starting. Turn it on briefly near them to help them get accustomed.

6.2. Turning On/Off and Adjusting Speed

- To turn on the clipper, press the power button. The LED display will illuminate.
- To cycle through the three speeds (6500 RPM, 7000 RPM, 7500 RPM), press the power button repeatedly. The RPM will be shown on the LED display.
- To turn off the clipper, press and hold the power button for a few seconds.
- The auxiliary illumination light can be toggled on/off by a separate button, usually located near the power button.

6.3. Grooming Techniques

- Always use a guide comb for consistent hair length. Start with a longer comb if unsure, and you can always go shorter.
- Hold the clipper firmly and move it in the direction of hair growth for a smooth finish. For a closer cut, move against the direction of hair growth.
- Use the lower speed (6500 RPM) for sensitive areas like the belly, face, and paws.
- Use higher speeds (7000 RPM, 7500 RPM) for thicker fur or larger body areas like the back and shoulders.
- Take frequent breaks to check your pet's comfort and to clean the blades if necessary.
- For detailed work or shaping, you may use the included scissors.



Image: Guide combs for different hair lengths.



Image: Corded and cordless operation.

7. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your clipper and ensure optimal performance.

7.1. Cleaning the Blade

1. Turn off the clipper and unplug it if connected to power.
2. Remove the guide comb.
3. To remove the cutterhead: Push the blade assembly in the opposite direction from the front of the machine until it detaches.
4. Use the cleaning brush to remove any trapped hair from the blades and the clipper body.
5. The removable cutterhead can be rinsed directly under running water. Ensure it is completely dry before reattaching.
6. To reattach the cutterhead: Align the lock of the cutterhead with the slot on the clipper body and press inwards until it clicks into place.

7.2. Lubricating the Blades

- After each cleaning or before each use, apply a few drops of the provided lubricating oil to the blades.
- Turn on the clipper for a few seconds to allow the oil to distribute evenly across the blades.
- Wipe off any excess oil with a soft cloth.
- The LED display will show an oil reminder when lubrication is needed.

7.3. Storage

- Store the clipper in a cool, dry place, away from direct sunlight and moisture.
- Keep out of reach of children and pets.



Image: Removable cutterhead for easy cleaning.

8. Troubleshooting

If you encounter any issues with your Hatteker Pet Clipper, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully.
Clipper pulls hair or cuts unevenly.	Blades are dull or clogged with hair. Pet's fur is tangled or dirty.	Clean and lubricate the blades. Ensure pet's fur is clean, dry, and brushed before grooming.
Clipper makes unusual noise.	Blades need lubrication. Foreign object caught in blades.	Apply lubricating oil to blades. Turn off, remove blade, and inspect for debris.
Battery life is shorter than expected.	Battery not fully charged. Old battery.	Ensure full charge cycle. Battery performance may degrade over time.
LED display not working.	Device malfunction.	Contact customer support.

If the problem persists after trying these solutions, please contact Hatteker customer support for further assistance.

9. Specifications

Brand	Hatteker
Model Number	612
Dimensions (L x W x H)	22.5 x 14.4 x 55 cm
Item Weight	550 Grams
Blade Material	Metal
Power Source	Battery Powered, Corded Electric
Battery Type	1 AAA (included) - *Note: This might be a typo in source data, likely Li-ion for 180min run time.*
Run Time	Up to 180 minutes (cordless)
Motor Speeds	6500 RPM, 7000 RPM, 7500 RPM
Noise Level	Approx. 55dB (Super Quiet)
Charging Interface	USB-C
Recommended Use	Pet grooming, hair cutting for cats and dogs

10. Warranty and Support

Hatteker products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Hatteker website.
If you require technical support, have questions about product operation, or need assistance with troubleshooting beyond what is covered in this manual, please contact Hatteker customer service. Contact details can typically be found on the

product packaging or the official brand website.
Please have your product model number (612) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP98NXYM

More documents and user manuals: **https://manuals.plus/**