Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CV-N2QAYB001198-SH

ALLIMITY N2QAYB001198 Replacement Remote Control User Manual

For Panasonic Home Audio Systems

1. Introduction

This manual provides instructions for the ALLIMITY N2QAYB001198 replacement remote control. This remote is designed to function as a direct replacement for your original Panasonic Home Audio System remote, requiring no complex setup or programming.

Package Contents

- 1 x ALLIMITY N2QAYB001198 Replacement Remote Control
- *Note: Batteries are not included.*

2. Setup: Battery Installation

To begin using your remote control, you must first install the batteries.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two (2) 1.5V AA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.







Figure 2.1: Battery compartment with polarity indicators. Insert two AA batteries as shown.

3. Operation

This replacement remote control is pre-programmed to work with compatible Panasonic Home Audio Systems. No additional programming is required. Simply point the remote at your audio system and press the desired function button.

Remote Control Layout





Figure 3.1: Front view of the remote control with various function buttons.

The remote features standard controls for power, volume, input selection, playback controls (play, pause, stop, skip), numerical keys, and specific functions for Panasonic Home Audio Systems such as DJ, Karaoke, Jukebox, Illumination, and various menu navigation buttons.

Compatible Panasonic Home Audio System Models

This remote control is compatible with the following Panasonic Home Audio System models:

- SA-AKX710
- SA-AKX910
- SA-MAX6500
- SC-UA70
- SC-UA90
- SA-MAX3500
- SC-AKX710
- SC-AKX910
- N2QAYB001198 (Original Remote Model)

Note: Model numbers may appear with or without hyphens or spaces depending on regional variations.

4. Specifications

Model Number	CV-N2QAYB001198-SH
Brand	ALLIMITY
Power Supply	2 x 1.5V AA Alkaline Batteries
Product Dimensions	6.5 x 1.38 x 0.72 inches (16.5 x 3.5 x 1.8 cm)
Item Weight	1.59 ounces (45 grams)
Color	Black
Special Feature	Wireless Infrared (IR)
Max Number of Supported Devices	1 (Specific Panasonic Home Audio System)

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AA alkaline batteries.
  - Check for any obstructions between the remote control and the audio system's infrared receiver.
  - Ensure you are within the effective range and line of sight of the audio system.
- **Specific Buttons Not Working:**
  - This remote is a direct replacement. If certain functions are not responding, verify that your audio system model is listed in the "Compatible Models" section.
  - Clean the remote control buttons and surface to ensure no debris is interfering with button presses.

6. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or solvents.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

7. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the retailer or the manufacturer's official website where the product was purchased. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact the seller directly through the platform where you made your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPFCHMNJ

More documents and user manuals: **https://manuals.plus/**