Accutime SPD4753AZ

Accutime Marvel Spider-Man Digital Learning Watch User Manual

Model: SPD4753AZ

Introduction

This manual provides instructions for the Accutime Marvel Spider-Man Educational Learning Digital Watch, model SPD4753AZ. Please read this manual thoroughly before using the watch to ensure proper operation and to understand all its features.



Figure 1: Front view of the Accutime Marvel Spider-Man Digital Learning Watch. The watch features a blue casing with a Spider-Man mask design on the cover and a red silicone strap.

Product Features

- Digital Time Display (12/24 hour format)
- Multiple Changeable Watch Faces
- Timer Function
- Stopwatch Function
- Alarm Function
- Built-in Educational Games
- Durable Construction with Silicone Strap
- Officially Licensed Marvel Product



Figure 2: The watch display showcasing key features including 10 changeable watch faces, a snug silicone strap, and a kid-tough design for durability.

Setup

1. Initial Power On and Battery

The watch typically comes with a pre-installed battery. If the display is not active, press any button to wake it up. If the watch does not power on, the battery may need replacement. Refer to the "Maintenance" section for battery replacement instructions.

2. Setting Time and Date

1. Press and hold the **SET** button (usually located on the side or bottom of the watch face) until the time display begins to flash.
2. Use the **MODE** or **ADJUST** button to cycle through hours, minutes, month, day, and year.
3. Use the **SET** button to adjust the flashing value (e.g., increase hour, minute).
4. Once all settings are correct, press the **SET** button again to confirm and exit the setting mode.


SPIDER-MAN



Figure 3: The watch comfortably worn on a child's wrist, demonstrating its size and fit. Ensure the strap is adjusted for a secure fit.

Operating Instructions

1. Basic Time Display and Watch Faces

The watch defaults to displaying the current time. To change the watch face:

1. Press the **MODE** button repeatedly until the watch face selection screen appears.
2. Use the **SET** or **ADJUST** button to cycle through the available watch face designs.
3. Once your desired watch face is displayed, press the**MODE** button to return to the main time display, or wait a few seconds for it to automatically set.



Figure 4: A close-up of the watch display illustrating the variety of Spider-Man themed watch faces available for selection.

2. Using the Timer

1. Press the **MODE** button until the Timer function is displayed.
2. Use the **SET** button to adjust the desired countdown time (hours, minutes, seconds).
3. Press the **START/STOP** button to begin the countdown.
4. Press **START/STOP** again to pause, and once more to resume.
5. When the timer reaches zero, an alert will sound. Press any button to stop the alert.

3. Using the Stopwatch

1. Press the **MODE** button until the Stopwatch function is displayed.
2. Press the **START/STOP** button to begin timing.
3. Press **START/STOP** again to pause.
4. Press the **RESET** button (often the same as **SET** or **MODE** when paused) to clear the stopwatch to zero.

4. Setting an Alarm

1. Press the **MODE** button until the Alarm setting screen appears.
2. Use the **SET** button to adjust the alarm hour and minute.
3. Press the **MODE** button to toggle the alarm ON/OFF. An alarm icon will typically appear on the display when activated.
4. Press the **MODE** button again to exit the alarm setting.

5. Playing Games

The watch includes several built-in educational games. To access them:

1. Press the **MODE** button until the Games menu is displayed.
2. Use the **SET** or **ADJUST** button to select a game.
3. Press the **START/OK** button to begin the selected game.
4. Follow the on-screen instructions to play.

Maintenance

1. Cleaning

To clean the watch, wipe it gently with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners, as these can damage the watch's finish or internal components. Ensure the watch is dry before storage.

2. Water Resistance

This watch is designed for everyday wear and is splash-resistant. It is not suitable for swimming, showering, or submersion in water. Avoid exposing the watch to excessive moisture.

3. Battery Replacement

The watch uses a standard watch battery (e.g., CR2032, specific type may vary, check watch back for details). Battery replacement should ideally be performed by an adult or a qualified technician. Improper replacement can damage the watch or compromise its water resistance.

1. Using a small screwdriver, carefully remove the screws on the back cover of the watch.
2. Gently lift the back cover.
3. Note the orientation of the existing battery. Carefully remove the old battery.
4. Insert the new battery with the correct polarity.
5. Replace the back cover and secure it with the screws, ensuring a snug fit to maintain splash resistance.

Troubleshooting

Problem	Possible Cause	Solution
Watch display is blank or dim.	Low or dead battery.	Replace the battery as per "Battery Replacement" instructions.
Buttons are unresponsive.	Temporary software glitch or low battery.	Try pressing all buttons firmly. If unresponsive, replace battery. If issue persists, contact support.
Time is incorrect.	Time not set correctly or battery low.	Re-set the time and date. If it frequently loses time, replace the battery.

Problem	Possible Cause	Solution
Alarm does not sound.	Alarm not activated or volume too low (if adjustable).	Ensure the alarm is set and activated (check for alarm icon).

Specifications

Model Number: SPD4753AZ

Brand: Accutime

Product Type: Digital Learning Watch

Recommended Age: 3+ years

Strap Material: Silicone

Display Type: Digital

Features: Time, Date, Timer, Stopwatch, Alarm, Multiple Watch Faces, Educational Games

Dimensions (Package): 6.93 x 3.86 x 2.4 inches

Weight (Package): 4.16 ounces

Manufacturer: Accutime Watch Corp.

Warranty and Support

Specific warranty information is not provided in the product data. For details regarding warranty coverage or technical support, please refer to the product packaging or contact Accutime customer service directly. You may also visit the official Accutime website for further assistance.

Accutime Store Link: Visit the Accutime Store on Amazon

© 2025 Accutime Watch Corp. All rights reserved. Marvel and Spider-Man are trademarks of Marvel Characters, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question