Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-LED325HDSMART-NP

ALLIMITY Replacement Remote Control User Manual

MODEL: MM-LED325HDSMART-NP

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY replacement remote control, designed to be fully compatible with various METZ, ENGEL, and AIWA TV models. This remote offers a seamless replacement experience, replicating all functions of your original remote without the need for complex programming or setup.

Compatible TV models include, but are not limited to: LED325HDSMART, LED405FHDSMART, LE3280SM, LE2481SM, LE5580SM, LE3281SM, LE4081SM, 55U2X42C, LE4080SM, LE3282SM, 40E6X22A, H0F19A075GPD10, 32E6X22, and 40MTB4000.





Figure 1: Front view of the ALLIMITY replacement remote control, showing all buttons.

2. Setup

The ALLIMITY replacement remote control is designed for immediate use without any programming or complex installation steps. Simply insert the batteries, and it is ready to operate your compatible TV.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA alkaline batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.







Figure 2: Back view of the remote control, showing the battery compartment area.

3. Operating Instructions

This remote control is designed to replicate the functionality of your original TV remote. Point the remote directly at your TV's infrared receiver for optimal performance.

3.1 Key Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **LIST:** Accesses the channel list.
- **INFO:** Displays information about the current program.
- **HOME:** Navigates to the TV's home screen or smart hub.
- **MENU:** Opens the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right) & OK:** Used for navigating menus and confirming selections.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **NETFLIX:** Direct access button for the Netflix application.
- **VOL +/-:** Adjusts the volume level.
- **Mute ( ):** Mutes or unmutes the TV sound.
- **P ^/v:** Changes channels up or down.
- **GUIDE:** Opens the electronic program guide.
- **SOURCE:** Selects the input source (HDMI, AV, etc.).
- **Media Control Buttons (Play/Pause, Stop, Rewind, Fast Forward):** Controls media playback.
- **SUBTITLE:** Toggles subtitles on or off.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or applications, as indicated on screen.
- **TEXT:** Accesses teletext.
- **FAV:** Accesses favorite channels.
- **AD:** Audio Description toggle.
- **I/II:** Audio language selection.



Figure 3: Angled view of the remote control, highlighting its ergonomic design.

4. Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, high temperatures, humidity, or water.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

- **Remote is not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Certain buttons are not working:**
  - Verify that the button is clean and not stuck.
  - Ensure your TV model is listed as compatible. While this remote is designed for broad compatibility, some specific TV functions might vary.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	MM-LED325HDSMART-NP
Compatible Devices	METZ, ENGEL, AIWA TVs (Models: LED325HDSMART, LED405FHDSMART, LE3280SM, LE2481SM, LE5580SM, LE3281SM, LE4081SM, 55U2X42C, LE4080SM, LE3282SM, 40E6X22A, H0F19A075GPD10, 32E6X22A, 40MTB4000)
Special Features	Ergonomic, Lightweight, No programming required
Battery Type	Alkaline (AAA, not included)
Connectivity Technology	Infrared
Maximum Range	10 Meters
Product Dimensions	17 x 5 x 1 cm
Product Weight	59 Grams

7. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPPBXFR6

More documents and user manuals: **https://manuals.plus/**