Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Just Play 28128

furReal Peanut The Playful Monkey Interactive Toy User Manual

Model: 28128 | Brand: Just Play

Introduction

The furReal Peanut the Playful Monkey interactive plush toy offers an engaging play experience with over 100 different reactions. This 15-inch tall plush toy is designed to simulate realistic monkey behaviors, providing interactive companionship for children.



Figure 1: furReal Peanut the Playful Monkey interactive toy with its included banana bottle.

What's Included

- 1 Interactive Toy Monkey (Peanut)
- 1 Banana Bottle Accessory

Safety Information

Warning: May contain small pieces. Not suitable for children under 3 years due to potential choking hazards. Battery Safety: Requires 6 x AA batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries from the toy. Remove batteries if the product is not to be used for an extended period. Do not short-circuit the supply terminals.

Setup

Battery Installation

1. Locate the battery compartments on the underside of Peanut's feet.
2. Using a Phillips head screwdriver, open the battery compartment covers.
3. Insert 3 AA batteries into each foot, ensuring correct polarity (+/-).
4. Securely close the battery compartment covers with the screws.



Figure 2: Battery compartments located on the underside of Peanut's feet.

Powering On/Off

To activate Peanut, locate the power switch on one of her feet and slide it to the "ON" position. To turn off the toy, slide the switch to the "OFF" position.

Operating Instructions

Peanut the Playful Monkey features over 100 unique reactions. Interact with her in various ways to discover all her responses.

General Interactions

- **Tickling:** Tickle Peanut to hear sweet giggles, chatters, and sounds.
- **Feeding:** Place the banana bottle near Peanut's mouth to hear adorable drinking sounds.
- **Walking:** Peanut can walk on her own. You can also hold her hands to guide her as she walks.
- **Flipping:** Hold one or both of Peanut's hands and watch her perform somersaults.
- **Sitting and Standing:** Peanut can sit and stand on her own. Sometimes she may need a little assistance.
- **Rocking to Sleep:** Gently rock Peanut to encourage her to fall asleep.
- **Picking Up:** Peanut senses when she is being picked up and will react accordingly after waking from a nap.



Figure 3: Various ways to interact with Peanut, such as feeding her with the banana bottle, holding her hands to walk, and tickling her belly.



Figure 4: Peanut demonstrating her ability to stand up independently.



Figure 5: Peanut performing a somersault when her hands are held.



Figure 6: Peanut walking while being guided by holding her hands.

Maintenance

- **Cleaning:** Surface clean only. Do not immerse the toy in water. Use a damp cloth to wipe away dirt.
- **Storage:** Store Peanut in a dry, cool place away from direct sunlight when not in use.
- **Battery Care:** Always remove batteries if the toy will not be used for an extended period to prevent battery leakage and corrosion.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Peanut is not responding or moving.	Batteries are low or incorrectly installed. Power switch is off.	Ensure the power switch is in the "ON" position. Replace all 6 AA batteries with new ones, ensuring correct polarity.
Unusual sounds or odors from the toy.	Internal malfunction or battery issue.	Immediately turn off the toy and remove all batteries. Discontinue use and contact customer support.
Peanut is not performing actions consistently (e.g., flipping, standing).	Interaction method may not be precise.	Refer to the "Operating Instructions" section and ensure you are interacting with Peanut as described. Some actions may require specific positioning or timing.

Specifications

- **Product Dimensions:** 13.5 x 6.7 x 17 inches
- **Item Weight:** 3.8 pounds
- **Model Number:** 28128
- **Manufacturer Recommended Age:** 4 - 8 years
- **Batteries:** 6 AA batteries required (not included)
- **Language:** English
- **Manufacturer:** Just Play



Figure 7: Peanut's approximate height of 15 inches.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Just Play website. Keep your purchase receipt as proof of purchase.

© 2025 Just Play. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPQ4GL2D

More documents and user manuals: **https://manuals.plus/**