Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

besrey KSE05

besrey Toddler Tricycle User Manual

Model: KSE05

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your besrey Toddler Tricycle, Model KSE05. Designed for children aged 18 months to 5 years, this tricycle aims to support the development of steering skills and coordination in young riders. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The besrey Toddler Tricycle, Model KSE05, in its assembled state.

2. Safety Information

Your child's safety is paramount. Adhere to all safety guidelines to prevent injury.

- **Age and Weight Limits:** This tricycle is suitable for children aged 18 months to 5 years, with a maximum weight capacity of 55 lbs (approximately 25 kg). Recommended child height is 30-40 inches with an inseam of 10 inches or more.
- **Adult Supervision:** Always ensure an adult supervises the child during use.
- **Protective Gear:** Always ensure the child wears a helmet and appropriate safety gear (e.g., knee and elbow pads) while riding.
- **Safe Riding Environment:** Use the tricycle on flat, even surfaces away from traffic, steep inclines, stairs, swimming pools, or other hazards.
- **Pre-Ride Check:** Before each use, inspect all parts to ensure they are securely fastened and in good working condition.

Check for any loose screws, sharp edges, or damaged components.

- **Rollover Prevention:** The tricycle features a robust triangular structure and wider rear wheels designed to minimize the risk of tipping. However, avoid sharp turns at high speeds or riding on uneven terrain that could compromise stability.
- **Material Safety:** All materials and designs used in the besrey tricycle have passed rigorous safety tests to ensure they are child-safe.



Image 2.1: Recommended age, height, and maximum weight for tricycle users.



Image 2.2: Illustration of the stable triangular structure designed to prevent rollover.

3. Product Overview

3.1 Components (What's in the Box)

Carefully unpack all components and verify against the list below. If any parts are missing or damaged, please contact customer support.

- Main Body Frame
- Front Wheel
- Rear Wheels x 2
- Handlebar & Bell
- Seat
- Pedals x 2
- Pedal Locks x 2
- Front Wheel Frame
- Rear Wheel Frame
- Protective Covers x 2 (for rear wheels)
- Rear Basket & Fastener
- Small Hex Key
- Large Hex Key
- Wrench



Image 3.1: Visual representation of all parts included in the package.

3.2 Key Features

- **2-in-1 Design:** Easily transitions between riding and folding modes for convenience.
- **Adjustable Seat:** 4-level adjustable seat to accommodate growing children.
- **EVA Foam Wheels:** Rugged, non-slip, and wear-resistant wheels suitable for various terrains.
- **Storage Basket:** Removable rear basket with a lid for carrying small items.
- **Ergonomic Backrest:** Provides enhanced comfort and support.
- **Non-Slip Handlebar:** Comfortable grip for secure handling.
- **Integrated Bell:** Adds an element of fun and helps attract attention.



Image 3.2: The tricycle's 2-in-1 design, showing both riding and folding configurations.



Image 3.3: Overview of the tricycle's core features.

4. Assembly Instructions

Follow these steps carefully to assemble your besrey Toddler Tricycle. It is recommended to perform assembly on a soft, clean surface to prevent damage to components.

1. **Attach Front Wheel to Front Wheel Frame:** Insert the front wheel into the front wheel frame. Ensure it is securely seated.
2. **Connect Front Assembly to Main Body Frame:** Slide the front wheel frame assembly into the main body frame. Secure it using the provided fasteners and tools (e.g., hex key).
3. **Install Handlebar:** Insert the handlebar into the top of the main body frame. Ensure the bell is correctly positioned and the handlebar is firmly secured.
4. **Attach Rear Wheel Frame:** Connect the rear wheel frame to the main body frame at the designated points.
5. **Install Rear Wheels:** Attach the two rear wheels to the rear wheel frame. Secure them with the protective covers and fasteners.
6. **Mount Seat:** Place the seat onto the main body frame. Ensure it clicks into place or is secured with the provided mechanism.
7. **Attach Pedals:** Insert the pedals into the front wheel assembly. Use the pedal locks to secure them. Ensure they rotate freely.
8. **Install Rear Basket:** Attach the rear storage basket to the back of the tricycle using its fastener.
9. **Final Check:** Review all connections and fasteners to ensure they are tight and secure before allowing a child to use the tricycle.

5. Operating Instructions

5.1 Adjusting the Seat

The tricycle features a 4-level adjustable seat to accommodate your child's growth and ensure optimal riding comfort.

- Locate the seat adjustment mechanism beneath the seat.
- Press the release button or lever and slide the seat forward or backward to the desired position.
- Ensure the seat locks securely into one of the four positions before use.



Image 5.1: The 4-level adjustable seat for customized comfort.

5.2 Folding and Unfolding

The tricycle's foldable design allows for easy storage and transport.

- **Folding:** Locate the folding buttons/levers on the frame and handlebar. Follow the instructions to release the locking mechanisms and fold the tricycle into its compact form. Ensure all parts are securely latched in the folded position.

- **Unfolding:** Reverse the folding process. Ensure all locking mechanisms are engaged and the tricycle is stable before use.



Image 5.2: The tricycle's portable, foldable design for easy carrying.

5.3 Using the Bell

The integrated bell can be used to alert others to the child's presence. Simply press the button on the bell to activate it.

5.4 Riding Tips

- Encourage your child to place their feet on the pedals and push forward to propel the tricycle.
- Guide them in steering by turning the handlebars left and right.
- Start with short rides in a safe, open area, gradually increasing duration as the child gains confidence and skill.



Image 5.3: A child learning to ride with parental assistance.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your tricycle.

- **Cleaning:** Wipe down the tricycle with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Dry thoroughly after cleaning.
- **Inspection:** Periodically check all bolts, nuts, and fasteners to ensure they are tight. Inspect wheels, pedals, and handlebars for any signs of wear or damage.
- **Storage:** Store the tricycle in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation. The foldable design makes storage convenient.
- **Lubrication:** If any moving parts (e.g., wheel axles) become stiff, apply a small amount of silicone-based lubricant. Avoid over-lubrication.



Image 6.1: The durable EVA foam wheels are designed for various terrains and require minimal maintenance.

7. Troubleshooting

If you encounter any issues with your tricycle, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Tricycle feels unstable or wobbly.	Loose fasteners; uneven assembly.	Check all bolts and nuts, especially on the wheels and frame, and tighten them securely. Ensure all parts are correctly assembled as per instructions.
Pedals do not turn smoothly.	Debris in pedal mechanism; lack of lubrication.	Inspect pedals for any obstructions and remove them. Apply a small amount of silicone lubricant to the pedal axles if necessary.
Handlebar is loose.	Handlebar locking mechanism not engaged or loose.	Ensure the handlebar is fully inserted and its locking mechanism is engaged. Tighten any associated screws or clamps.
Tricycle does not fold correctly.	Folding mechanisms obstructed or not fully released.	Check for any obstructions. Ensure all folding release buttons/levers are fully pressed or pulled before attempting to fold.

If the problem persists after attempting these solutions, please contact besrey customer support for further assistance.

8. Specifications

Detailed specifications for the besrey Toddler Tricycle, Model KSE05.

Feature	Detail
Model Number	KSE05
Product Dimensions (L x W x H)	13.39 x 7.48 x 17.32 inches (34 x 19 x 44 cm)
Item Weight	10.2 pounds (4.6 kg)
Recommended Age	18 months - 5 years
Maximum Weight Capacity	55 lbs (25 kg)
Recommended Child Height	30-40 inches (76-102 cm)
Recommended Child Inseam	10 inches+ (25 cm+)
Wheel Material	EVA Foam
Manufacturer	besrey

9. Warranty and Support

besrey is committed to providing high-quality products and customer satisfaction.

- **Warranty:** This product comes with a LIFETIME warranty, covering manufacturing defects under normal use.
- **Return Policy:** A 24-month hassle-free return policy is provided for your peace of mind.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact besrey customer support through the retailer where the product was purchased or visit the official besrey website for contact information.

© 2023 besrey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPSG9HX7

More documents and user manuals: **https://manuals.plus/**