Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Morphy Richards 640129

Morphy Richards Juicer Model 640129 User Manual

500 Watt Centrifugal Juicer

Introduction

Thank you for choosing the Morphy Richards 500 Watt Centrifugal Juicer, Model 640129. This appliance is designed to extract fresh juice from fruits and vegetables efficiently. Please read this manual carefully before operating the juicer to ensure safe and optimal performance. Keep this manual for future reference.

Key Features:

- 500 Watt Powerful Motor
- Indicator Light for operational status
- Durable Stainless Steel Blade
- Compact design with dimensions of 24D x 28.5W x 30H Centimeters

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not immerse the motor unit in water or other liquids.
- Ensure the appliance is switched off and unplugged before assembling, disassembling, or cleaning.
- Keep hands and utensils out of the feed chute during operation to prevent injury.
- Always use the food pusher provided. Never push food with your fingers or other objects.
- Do not operate the juicer if any part is damaged or if the cord or plug is damaged.
- This appliance is for household use only.
- Supervise children closely when the appliance is in use.
- Place the juicer on a stable, flat, and dry surface.

Product Components

Familiarize yourself with the parts of your Morphy Richards Juicer:

1. **Motor Unit:** The main body containing the 500 Watt motor and control knob.



Image: The main motor unit of the juicer, featuring the control knob and power indicator.

2. **Juicer Cover/Lid:** Transparent cover that fits over the juicing mechanism.



Image: The transparent lid of the juicer, which secures the pulp container and feeding chute.

3. **Pulp Container:** Collects the discarded pulp during juicing.



Image: The black pulp container, designed to collect fruit and vegetable fiber.

4. **Feeding Chute and Pusher:** For inserting fruits and vegetables.



Image: The feeding chute component, where produce is inserted, and the food pusher.

5. **Juice Spout:** Where the extracted juice flows out.
6. **Stainless Steel Filter/Blade:** The component that grates and separates juice from pulp.

Setup and Assembly

Before first use, wash all removable parts (except the motor unit) in warm soapy water, rinse thoroughly, and dry. Ensure all parts are completely dry before assembly.

1. Place the motor unit on a stable, flat, and dry surface.
2. Insert the pulp container into its designated slot on the motor unit.
3. Place the stainless steel filter/blade assembly securely onto the motor unit's shaft. Ensure it clicks into place.
4. Position the juicer cover over the filter/blade and pulp container, aligning the locking tabs.
5. Secure the cover by engaging the safety locking arms (if present) or rotating until it locks firmly. The juicer will not operate if the cover is not correctly secured.
6. Place a juice collecting glass or pitcher under the juice spout.

Operating Instructions

Follow these steps to operate your juicer:

1. Ensure the juicer is correctly assembled and a juice collecting container is in place.
2. Wash fruits and vegetables thoroughly. Peel citrus fruits and remove large seeds/pits from fruits like peaches or

plums. Cut larger produce into pieces that fit the feeding chute.

3. Plug the power cord into a suitable electrical outlet.
4. Turn the control knob to the 'ON' position. The indicator light will illuminate, and the motor will start.
5. Gradually feed the prepared fruits and vegetables into the feeding chute. Use the food pusher to gently guide them down. Do not force food into the chute.
6. Once juicing is complete, turn the control knob to the 'OFF' position and unplug the appliance.
7. Allow the motor to stop completely before disassembling for cleaning.

Note: The juicer is equipped with an indicator light to show when the unit is powered on and operating.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your juicer.

1. **Before Cleaning:** Always switch off the juicer and unplug it from the power outlet.
2. **Disassembly:** Disassemble the juicer by removing the food pusher, cover, filter/blade, and pulp container.
3. **Cleaning Removable Parts:** Wash all removable parts (pulp container, cover, filter/blade, food pusher) immediately after use under running water. Use a brush to clean the filter mesh thoroughly to remove any pulp residue.
    - **Hand Wash Only:** These parts are not dishwasher safe.
4. **Cleaning Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
5. **Drying and Storage:** Dry all parts thoroughly before reassembling or storing. Store the juicer in a dry place.

Troubleshooting

Problem	Possible Cause	Solution
Juicer does not start.	• Not plugged in. • Lid/safety arms not properly secured. • Power outage.	• Ensure power cord is securely plugged into an active outlet. • Check that the lid is correctly locked into place. • Verify power supply to the outlet.
Motor stops during operation.	• Overload protection activated. • Too much pulp buildup.	• Turn off, unplug, and allow to cool for 15-20 minutes. Reduce load when restarting. • Turn off, unplug, disassemble, and clean the filter and pulp container.
Excessive vibration or noise.	• Filter basket not properly seated. • Uneven surface.	• Turn off, unplug, and re-seat the filter basket correctly. • Ensure the juicer is on a flat, stable surface.
Poor juice extraction.	• Filter mesh clogged. • Feeding produce too quickly.	• Clean the filter mesh thoroughly. • Feed produce slowly and steadily.

Specifications

- **Brand:** Morphy Richards
- **Model:** 640129 (Maximo DLX)
- **Type:** Centrifugal Juicer
- **Maximum Power:** 500 Watts
- **Power Source Type:** DC
- **Material:** Plastic body, Stainless Steel Blade
- **Colour:** Sand Colour
- **Product Dimensions (D x W x H):** 24D x 28.5W x 30H Centimeters
- **Item Weight:** 2.4 Kilograms
- **Special Feature:** Indicator Light
- **Product Care Instructions:** Hand Wash Only
- **Dishwasher Safe:** No



Image: Visual representation of key specifications including dimensions, wattage, and material.

Warranty and Support

Your Morphy Richards Juicer Model 640129 comes with a warranty. Please refer to the included Warranty Card for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, service, or spare parts, please contact the manufacturer:

- **Manufacturer:** BAJAJ ELECTRICALS
- **Contact Information:** Refer to the contact details provided on your Warranty Card or visit the official Morphy

Richards website.

Always have your model number (640129) and purchase date ready when contacting support.

© 2026 Morphy Richards. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPVPG6P5

More documents and user manuals: **https://manuals.plus/**