**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**ALLIMITY N2QAYA000205 N2QAYA000217**

# ALLIMITY N2QAYA000205 / N2QAYA000217 Replacement Remote Control User Manual

For Panasonic Blu-ray Disc Players DP-UB820, DP-UB824, DP-UB450, DP-UB159, DP-UB150

## 1. Introduction

This manual provides instructions for the ALLIMITY N2QAYA000205 / N2QAYA000217 replacement remote control. This remote is designed to function as a direct replacement for original Panasonic Blu-ray Disc Player remotes, specifically for models DP-UB820, DP-UB824, DP-UB450, DP-UB159, and DP-UB150. No programming or setup is required; simply insert batteries to begin operation.

## 2. Package Contents

- 1 x ALLIMITY Replacement Remote Control (batteries not included)

## 3. Setup and Battery Installation

### Battery Installation

The remote control requires two (2) AAA alkaline batteries for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.






Image showing the back of the remote control with the battery compartment open, illustrating where to insert two AAA batteries.

## 4. Operating Instructions

### Basic Operation

This replacement remote control is designed to work immediately with compatible Panasonic Blu-ray Disc Players without any additional setup.

### Compatibility

- Panasonic DP-UB820
- Panasonic DP-UB824
- Panasonic DP-UB450
- Panasonic DP-UB159
- Panasonic DP-UB150

### Key Functions Overview

The remote features standard Blu-ray player controls. Refer to your Blu-ray player's original manual for specific functions of each button if needed. Common buttons include:

- **Power Button**: Turns the Blu-ray player on or off.
- **Number Buttons (0-9)**: For direct track selection or input.
- **Navigation Pad (Up, Down, Left, Right, OK)**: For menu navigation and selection.
- **Play, Pause, Stop, Fast Forward, Rewind**: Media playback controls.
- **Open/Close**: Ejects or closes the disc tray.
- **Top Menu** / **Pop-Up Menu**: Accesses disc menus.
- **Home**: Returns to the player's home screen.
- **Return**: Goes back to the previous screen or menu.






Front view of the ALLIMITY replacement remote control, displaying all buttons and their labels.

## 5. Maintenance

### Battery Replacement

Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or solvents, as these can damage the remote's surface or internal components.

## 6. Troubleshooting

### Remote Control Not Responding

- **Check Batteries**: Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries.
- **Line of Sight**: Make sure there is a clear line of sight between the remote control and the Blu-ray player's infrared sensor. Obstructions can block the signal.
- **Distance**: Operate the remote within a reasonable distance from the Blu-ray player.
- **Interference**: Strong light sources (like direct sunlight or fluorescent lights) can interfere with the infrared signal. Try operating the remote in a different lighting condition.

### Specific Buttons Not Working

- This remote is a replacement and may not have all the exact functions of an original remote if your original had unique features. Verify the button's function in your Blu-ray player's manual.
- Ensure the remote is clean and there is no debris obstructing the buttons.

## 7. Specifications

- **Brand**: ALLIMITY
- **Model Numbers**: N2QAYA000205, N2QAYA000217
- **Compatible Devices**: Panasonic Blu-ray Disc Players (DP-UB820, DP-UB824, DP-UB450, DP-UB159, DP-UB150)
- **Power Source**: 2 x AAA Alkaline Batteries (not included)
- **Dimensions**: Approximately 6 x 1.9 x 0.5 inches (15.24 x 4.83 x 1.27 cm)
- **Item Weight**: Approximately 1.61 ounces (45.64 grams)
- **Color**: Black
- **Special Feature**: Ergonomic design

## 8. Warranty and Support

For warranty information or technical support, please refer to the seller's policies or contact the retailer where the product was purchased. Keep your purchase receipt for proof of purchase.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0CPY2LRYP**

More documents and user manuals: **https://manuals.plus/**