Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cassia YSBCG2 SST

Cassia Electric Stainless Steel Burr Coffee Grinder

Model: YSBCG2 SST

Important Safety Instructions

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the motor base in water or other liquids.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Avoid contact with moving parts.
- Always ensure the bean container lid is securely in place before operating the grinder.

Product Overview

The Cassia Electric Stainless Steel Burr Coffee Grinder is designed to provide consistent and precise grinding for various coffee brewing methods. It features durable flat metal burrs, adjustable grind settings, and a convenient quantity selector.



Image: Front view of the Cassia Electric Stainless Steel Burr Coffee Grinder, showcasing its sleek design and controls.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wipe the exterior of the grinder with a damp cloth. Wash the removable grind container and its lid with warm, soapy water, then rinse and dry thoroughly. Ensure all parts are completely dry before assembly.
3. **Assemble:** Place the grind container into its designated slot on the base. Ensure the bean container is properly seated on top of the grinder body.
4. **Placement:** Position the grinder on a stable, flat, and dry surface, away from water sources and heat.

Operating Instructions

1. **Add Coffee Beans:** Open the lid of the bean container and pour whole coffee beans into the hopper. Do not overfill. Ensure the lid is securely closed before operation.



Image: Coffee beans being poured into the top hopper of the Cassia coffee grinder.

2. **Select Grind Setting:** Rotate the grind selector dial to choose your desired fineness. The grinder offers 14 settings, ranging from coarse for French press to fine for espresso. Refer to the guide below for common brewing methods.



Image: Visual guide showing coarse, medium, and fine grind settings suitable for French Press, Pour Over, and Espresso, respectively.

3. **Adjust Quantity:** Use the quantity selector dial to choose the number of cups you wish to grind, from 2 to 12 cups. This ensures you grind only the amount needed, preserving freshness.



Image: Close-up top view of the grinder, highlighting the power button and the dial for selecting the number of cups to grind.

4. **Start Grinding:** Plug the grinder into a suitable power outlet. Press the power button to begin grinding. The grinder will automatically stop once the selected quantity has been processed.
5. **Collect Ground Coffee:** Once grinding is complete, carefully remove the grind container from the base.



Image: The removable container filled with freshly ground coffee, with its lid placed beside it.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Unplug:** Always unplug the grinder from the power outlet before cleaning.
2. **Empty Grind Container:** Remove the grind container and discard any remaining ground coffee. Wash the container and its lid with warm, soapy water. Rinse thoroughly and dry completely.
3. **Clean Burr Assembly:** Use a small brush (often included with grinders, or a stiff brush) to remove any coffee grounds from the burrs and the grinding chamber. You can also use a vacuum cleaner with a narrow attachment to remove stubborn grounds.
4. **Wipe Exterior:** Wipe the exterior of the grinder body with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor base in water.
5. **Reassemble:** Ensure all parts are dry before reassembling the grinder.

Troubleshooting

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; Bean container lid not securely closed; Power button not pressed.	Ensure the grinder is plugged in. Check that the bean container lid is properly seated and locked. Press the power button firmly.
Inconsistent grind.	Burrs are dirty or clogged; Incorrect grind setting for bean type.	Clean the burr assembly thoroughly. Adjust the grind setting to a finer or coarser option as needed for your beans and brewing method.
Grinder stops during operation.	Overheating; Selected quantity reached.	If the selected quantity is reached, this is normal. If not, unplug and let the unit cool down for 30 minutes before restarting. Ensure proper ventilation.
Ground coffee not dispensing properly.	Dispensing chute clogged.	Unplug the grinder. Use a small brush to clear any blockages in the dispensing chute.

Specifications

Model: YSBCG2 SST

Brand: Cassia

Material: Stainless Steel

Wattage: 150 watts

Grind Settings: 14 precision settings

Quantity Selector: 2-12 cups

Ground Coffee Capacity: 100g

Product Dimensions (L x W x H): 7.75" x 5.5" x 9.25"

UPC: 192598249494



Image: Diagram illustrating the length, width, and height dimensions of the Cassia Electric Stainless Steel Burr Coffee Grinder.

Warranty and Support

Specific warranty information is not provided in this manual. For warranty details, product support, or service inquiries, please refer to the documentation included with your purchase or contact Cassia customer service directly. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPYM4BRR

More documents and user manuals: **https://manuals.plus/**