TIMEURE TU2308

TIMEURE Pedometer Watch TU2308 Instruction Manual

Brand: TIMEURE | Model: TU2308

1. Introduction

This manual provides detailed instructions for the TIMEURE Pedometer Watch TU2308. This standalone digital watch is designed for fitness enthusiasts and seniors seeking a simple, practical, and mobile-free way to track daily activity. It features step counting, calorie tracking, distance measurement, time, date, alarm, stopwatch, and a countdown timer, all without requiring smartphone connectivity or frequent charging.

2. Key Features

- **Independent Pedometer:** Tracks steps, calories burned, and distance (switchable between kilometers and miles) without any app or smartphone connection.
- **Large Display with EL Backlight:** Ensures effortless readability in all lighting conditions, including dimly lit environments.
- **50M Water Resistance:** Suitable for handwashing, swimming, and cold showers.
- **Multiple Functions:** Includes time, date, week display, alarm, hourly chime, stopwatch, and countdown timer.
- **Comfortable Design:** Crafted with a sleek stainless steel ring and a soft, comfortable PU strap, adjustable for wrist sizes from 6.29 to 9.44 inches.
- **Long Battery Life:** Operates on a CR2430 battery, providing extended usage without the need for frequent recharging.



Figure 2.1: Overview of key features displayed on the watch face.

3. Setup

3.1. Initial Inspection

Upon unboxing, ensure all components are present: the TIMEURE Pedometer Watch and the Quick Start Guide. This model does not require charging or app installation for its core functions.

3.2. Button Functions

Familiarize yourself with the watch buttons:

- **LIGHT:** Activates the EL backlight.
- **MODE:** Cycles through different display modes (Time, Pedometer, Stopwatch, Countdown, Alarm).
- **START:** Used to start/stop functions in Stopwatch mode, or adjust settings.
- **RESET:** Used to reset values in Pedometer/Stopwatch mode, or confirm settings.



Figure 3.1: Watch button layout and functions.

3.3. Setting Time and Date

1. In Time mode, press and hold the **MODE** button until the display flashes.
2. Use the **START** button to adjust the flashing value (e.g., hour, minute, year, month, day).
3. Press the **MODE** button to move to the next setting.
4. Press **RESET** to confirm and exit setting mode.



Figure 3.2: Watch display showing time, date, and steps, and how to switch display focus.

4. Operating Instructions

4.1. Navigating Modes

Press the **MODE** button repeatedly to cycle through the following modes:

- Time/Date Display
- Pedometer (Steps, Calories, Distance)
- Stopwatch
- Countdown Timer
- Alarm

4.2. Pedometer Function

In Pedometer mode, the watch displays your current step count, calories burned, and distance traveled. The watch automatically tracks these metrics throughout the day.

- **Viewing Yesterday's Steps:** The watch stores the previous day's step count, which can be accessed in Pedometer mode.
- **Resetting Pedometer:** To reset your daily step count, press and hold the **RESET** button in Pedometer mode.

4.3. Stopwatch

1. Navigate to Stopwatch mode using the **MODE** button.
2. Press **START** to begin timing.
3. Press **START** again to pause.
4. Press **RESET** to clear the stopwatch.

4.4. Countdown Timer

1. Navigate to Countdown Timer mode using the **MODE** button.
2. Press and hold **START** to set the countdown duration.
3. Use **START** to adjust values and **MODE** to switch between hours, minutes, and seconds.
4. Press **RESET** to confirm the setting.
5. Press **START** to begin the countdown.

4.5. Alarm

1. Navigate to Alarm mode using the **MODE** button.
2. Press and hold **START** to set the alarm time.
3. Use **START** to adjust values and **MODE** to switch between hours and minutes.
4. Press **RESET** to confirm the setting.
5. Press **START** to toggle the alarm ON/OFF.

4.6. EL Backlight

Press the **LIGHT** button to illuminate the display for approximately 5 seconds, enhancing visibility in dark conditions.

Your browser does not support the video tag.

Video 4.1: Demonstration of the TIMEURE Pedometer Watch features, including time display, step tracking, calorie count, and water resistance.

5. Maintenance

5.1. Water Resistance

The TIMEURE Pedometer Watch has a 50-meter water resistance rating. This means it is suitable for:

- Daily use, such as handwashing and splashes.
- Swimming in shallow water.
- Taking cold showers.

Note: Not suitable for hot water, diving, or prolonged submersion at depths exceeding 50 meters. Avoid pressing buttons underwater.



Figure 5.1: The watch demonstrating its 50M water resistance.

5.2. Battery Replacement

The watch operates on a CR2430 high-capacity battery, offering a long battery life of up to 15 months. When the display dims or functions become erratic, it may be time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure water resistance is maintained.

5.3. Cleaning and Care

Wipe the watch regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the watch face or strap. Store the watch in a cool, dry place when not in use.

6. Troubleshooting

- **Display is blank or dim:** The battery may be low. Replace the CR2430 battery.
- **Steps are not counting accurately:** Ensure the watch is worn snugly on your wrist. Movement patterns can affect accuracy.
- **Time/Date is incorrect:** Refer to Section 3.3 for instructions on how to set the time and date.

- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, refer to the Quick Start Guide for specific lock features). If issues persist, a battery replacement might be needed.

7. Specifications

Feature	Specification
Model Name	Pedometer Watch
Part Number	TU2308
Brand	TIMEURE
Color	Blue
Material	Stainless Steel
Item Weight	50 Grams
Water Resistance	50 Meters
Screen Size	40 Millimeters
Wrist Size Compatibility	6.29 inches to 9.44 inches (160mm to 240mm)
Battery Type	CR2430 Lithium Metal
Special Feature	Pedometer, EL Backlight

8. Warranty and Support

TIMEURE is committed to providing quality products and customer satisfaction.

- **Warranty:** 1-Year after-sales warranty.
- **Returns:** 30-Day no-reason return policy.
- **Customer Service:** 12-Hour online customer service available for inquiries and support.
- **Transparency:** Each item includes a unique code for verification before shipping.

Figure 8.1: TIMEURE after-sales and support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is the time showing up on the bottom instead of the middle of the screen on the TIMEURE Pedometer Watch TU2308?

The TIMEURE Pedometer Watch TU2308 manual does not specify how to change the position of the time display. The manual describes the watch's features and how to set the time and date, but it...

Read full answer