iDOO I-C-016

iDOO Air Mattress Full with Built-in Pump - Instruction Manual

Model: I-C-016 | Brand: iDOO

1. Introduction

This manual provides essential instructions for the safe and efficient use of your iDOO Full Air Mattress. Please read all instructions carefully before setup and operation. Retain this manual for future reference.

Important Safety Information

- Keep the air mattress away from heat sources, open flames, and sharp objects.
- Ensure the floor surface is flat and clean before inflation.
- Do not allow children or pets to play unsupervised on the mattress to prevent suffocation or damage.
- The PVC material will naturally expand and stretch over time. Regular re-inflation may be necessary to maintain desired firmness. This is normal and not indicative of a leak.
- Do not over-inflate the mattress.
- Unplug the pump when not in use.

2. Package Contents

Verify that all items are present in the package:

- iDOO Full Air Mattress with Built-in Electric Pump
- Carry Bag
- Repair Patch Kit
- User Manual (this document)

3. Specifications

Feature	Detail
Model Name	I-C-016
Size	Full
Inflated Dimensions	76"L x 54"W x 18"Th (193 x 137 x 46 cm)
Weight Capacity	650 lbs (295 kg)
Material	New PVC (K80 resin), Flocked Top
Pump Type	Built-in Electric Single Air Pump
Special Features	Four Chamber Structure, 28 Air Coils, Non-slip Bottom, Waterproof, Puncture-resistant

4. Setup & Inflation

1. **Unpack:** Remove the air mattress from its carry bag and unroll it on a clean, flat surface. Ensure there are no sharp objects underneath.
2. **Locate Pump:** Find the built-in electric pump on the side of the mattress. Open the cover to access the power cord.
3. **Plug In:** Plug the power cord into a standard electrical outlet (AC 110-120V).
4. **Inflate:** Turn the pump dial to the "INFLATE" position. The mattress will begin to inflate automatically.
5. **Monitor Inflation:** Allow the mattress to inflate to your desired firmness. This typically takes 2-3 minutes for a full size. Do not over-inflate.
6. **Turn Off:** Once inflated, turn the pump dial to the "OFF" position and close the pump cover. Unplug the power cord and store it neatly in its compartment.

Figure 1: Built-in electric pump for quick inflation. The dial allows selection between inflate, off, and deflate functions. The power cord is stored within a compartment next to the pump.

Figure 2: Visual guide for setting up the air mattress. Steps include unboxing from the carry bag, unfolding the mattress, and using the built-in pump for inflation, which takes approximately 2 minutes.

5. Operating Instructions

Inflation

As detailed in the setup section, simply plug in the mattress and turn the pump dial to "INFLATE". The mattress will automatically fill with air. Adjust firmness by stopping the pump when desired.

Deflation

1. **Prepare:** Ensure the mattress is clear of any items.
2. **Plug In:** Plug the power cord into a standard electrical outlet.
3. **Deflate:** Turn the pump dial to the "DEFLATE" position. The pump will begin to extract air from the mattress.
4. **Complete Deflation:** Allow the pump to run until all air is removed and the mattress is flat. This ensures easy folding and storage.
5. **Turn Off:** Turn the pump dial to the "OFF" position, close the pump cover, and unplug the power cord.

6. Maintenance

Cleaning

To clean the flocked top surface, use a damp cloth with mild soap. Wipe gently and allow to air dry completely before storing. Do not use harsh chemicals or abrasive cleaners.

Storage

1. Ensure the mattress is completely deflated and dry.
2. Fold or roll the mattress neatly to fit into the provided carry bag.
3. Store the mattress in a cool, dry place away from direct sunlight and extreme temperatures.

Figure 3: The iDOO air mattress is designed for space-efficient storage, folding down to a compact size (17.5"x7.5"x13") that fits easily into its carry bag and can be stored in small spaces like a closet.

Repair

In the event of an accidental puncture or tear, use the included repair patch kit. Clean the damaged area, apply the patch according to the kit's instructions, and allow sufficient time for it to cure before re-inflating.

7. Troubleshooting

Problem	Possible Cause	Solution
Mattress loses air overnight	Natural PVC stretching; minor leak; pump valve not fully closed.	Re-inflate regularly (normal for PVC). Check pump dial is firmly in "OFF" position and cover is sealed. Inspect for punctures and use repair kit if necessary.
Pump not working	Not plugged in; power outage; pump dial in wrong position.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker. Verify pump dial is set to "INFLATE" or "DEFLATE".
Mattress not inflating/deflating fully	Obstruction in pump; valve not fully open.	Check pump intake/exhaust for obstructions. Ensure pump dial is fully turned to the desired function.

8. Warranty & Support

iDOO air mattresses come with a 12-month warranty. For warranty claims, technical support, or any questions regarding your product, please contact iDOO customer service:

- **Email:** iDOO20123@outlook.com
- **Phone:** +1 (978)-209-0771
- **Service Hours:** 9am - 6pm EST, Monday - Friday

Please have your model number (I-C-016) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question