ALLIMITY BN59-01393C

User Manual for Allimity BN59-01393C Replacement Remote Control

Model: BN59-01393C

1. Product Overview

The Allimity BN59-01393C is a replacement infrared (IR) remote control designed for various Samsung Crystal UHD 4K HDR Smart TVs and S-series monitors. This remote provides essential functions for controlling your compatible Samsung display without the need for complex programming.





Figure 1: Front view of the Allimity BN59-01393C Replacement Remote Control, showing its buttons and layout.

2. Compatibility

This remote control is compatible with a wide range of Samsung CU7000 Crystal UHD 4K HDR Smart TVs and S-series monitors. Below is a list of known compatible models:

- **Samsung CU7000 Series:** UN43CU7000, UN50CU7000, UN55CU7000, UN58CU7000, UN65CU7000, UN70CU7000, UN75CU7000, UN85CU7000 (and their F, FXZA, B, BXZA, D, DXZA variants).
- **Samsung S-Series Monitors:** S32BM50, S32BM70, S43BM70, S32BM80, S27BM50 Series (including specific models like LS27BM501EE, LS32BM501EE, S32BM500EE, S32BM501EE, S32BM700UE, S32BM701UE, S43BM702UE, S32BM801UE, S32BM80BUE, S32BM80GUE, S32BM80PUE).

If your specific model is not listed, please refer to the product description or contact the manufacturer for compatibility verification.

3. Setup and Installation

3.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Image showing the open battery compartment of the remote control, indicating where to insert two AAA batteries.

3.2 Initial Setup

This replacement remote is an infrared (IR) remote and typically requires no programming. Once new alkaline batteries are installed, it should work directly with compatible Samsung TVs and monitors. Point the remote directly at your TV's IR receiver.

4. Operating Instructions

The remote control features a standard layout for easy navigation and control of your Samsung TV or monitor. Below are descriptions of key buttons and their functions:

Power Button: Located at the top, used to turn the TV/monitor on or off.

Number/Virtual Keyboard Button (123): Accesses the virtual number pad or keyboard for input.

Menu/Settings Button: Opens the TV's main menu or settings.

Directional Pad (Circular): Used for navigating menus and selecting options (Up, Down, Left, Right, and Enter/OK in the center).

Back Button: Returns to the previous screen or menu.

Home Button: Navigates to the Smart Hub or home screen of the TV.

Play/Pause/Fast Forward/Rewind (Media Control): Controls media playback.

Volume Up/Down (+/-): Adjusts the volume level.

Channel Up/Down (Up/Down Arrows): Changes TV channels.

Dedicated App Buttons: Direct access buttons for popular streaming services such as Netflix, Samsung TV Plus, Prime Video, and Disney+.



Figure 3: The remote control shown alongside a "VOICE CONTROL" icon, indicating potential voice command functionality if supported by the connected TV model.

Note: While the image suggests voice control, this specific remote model (BN59-01393C) is an IR remote and typically does not support voice commands directly. Voice control functionality would depend on the TV's built-in capabilities and its original remote.

5. Maintenance

5.1 Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in Section 3.1 to replace the two AAA alkaline batteries.

5.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Ensure new AAA alkaline batteries are correctly installed with proper polarity.
  - Point the remote directly at the TV's IR receiver.
  - Check for any obstructions between the remote and the TV.
  - Verify that the TV is powered on.
- **Specific buttons not working:**
  - This remote is an IR replacement. Some advanced functions or pairing features of original Smart Remotes (e.g., Bluetooth, voice control) may not be supported.
  - Ensure the button is not stuck.
- **Intermittent operation:**
  - Replace batteries with fresh ones.
  - Ensure there is no strong light source (like direct sunlight) interfering with the IR signal.

If issues persist after troubleshooting, please refer to the contact information provided by the seller or manufacturer.

7. Specifications

Feature	Detail
Model Number	BN59-01393C (AMT-MB1503-BN59-01393C-gx)
Brand	ALLIMITY
Product Material	Plastic
Power Source	2 x AAA Alkaline Batteries (not included)
Connectivity Technology	Infrared (IR)
Product Dimensions	5 x 1 x 0.6 inches (approx. 12.7 x 2.54 x 1.52 cm)
Item Weight	1 ounce (approx. 28.35 grams)
Color	Black
Compatible Devices	Samsung CU7000 Series TVs, S-Series Monitors





Figure 4: Diagram illustrating the approximate dimensions of the remote control: approximately 16 cm (6.3 inches) in length and 3.5 cm (1.38 inches) in width.

8. Warranty and Support

Specific warranty information for this replacement remote control is not detailed in the provided product information. For

warranty claims or technical support, please contact the seller, AllimityDirect-US, or the manufacturer, ALLIMITY INC, directly through their official channels or the platform where the product was purchased.
If you cannot find your specific model number listed under compatibility, or if you require further assistance, it is recommended to reach out to the seller via message for guidance on finding the correct remote control.

© 2024 Allimity. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question