Keyscaper Dallas Cowboys Color Block Digital Desk Clock

Keyscaper Dallas Cowboys Color Block Digital Desk Clock User Manual

Introduction

This manual provides instructions for the setup, operation, and maintenance of your Keyscaper Dallas Cowboys Color Block Digital Desk Clock. This digital clock displays the time, day of the week, month, date, and temperature, making it a functional and decorative item for your home or office.

Product Overview

The Keyscaper Digital Desk Clock is designed for indoor use and features a digital display. It is powered by batteries (not included) and can be placed on a tabletop using its integrated stand or mounted on a wall.



This image displays the back panel of the digital desk clock. Visible are the control buttons labeled 'TIME', 'AL' (Alarm), 'UP', 'SNZ' (Snooze), 'CH' (Channel/Mode), and 'DOWN'. Below the buttons, a compartment for batteries is present, along with a foldable stand for tabletop use and a hanging slot for wall mounting.

Setup

1. **Battery Installation:** Locate the battery compartment on the back of the clock. Insert the required batteries (typically AAA, not included) according to the polarity markings (+/-).
2. **Initial Power-On:** Once batteries are inserted, the clock display should activate.
3. **Placement:** Place the clock on a flat surface using the foldable stand or hang it on a wall using the integrated hanging slot.

Operating Instructions

Setting Time and Date

1. Press the **TIME** button to enter time setting mode. The hour digits will flash.
2. Use the **UP** and **DOWN** buttons to adjust the hour.
3. Press **TIME** again to move to minute setting. Adjust with **UP** and **DOWN**.
4. Continue pressing **TIME** to cycle through setting the year, month, and date. Adjust each value using the **UP** and **DOWN** buttons.
5. Press **TIME** one last time to exit setting mode.

Setting Alarm

1. Press the **AL** (Alarm) button to enter alarm setting mode. The alarm hour digits will flash.
2. Use the **UP** and **DOWN** buttons to adjust the alarm hour.
3. Press **AL** again to move to alarm minute setting. Adjust with **UP** and **DOWN**.
4. Press **AL** one last time to exit alarm setting mode.
5. To activate/deactivate the alarm, press the **CH** (Channel/Mode) button while in normal display mode until the alarm icon appears/disappears.
6. To silence a sounding alarm, press the **SNZ** (Snooze) button for a temporary snooze, or any other button to turn off the alarm for the day.

Temperature Display

The clock automatically displays the ambient temperature. No specific setting is required for this feature.

Maintenance

- **Cleaning:** Wipe the clock surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the display dims or the clock stops functioning correctly. Ensure correct polarity during installation.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Solution
Clock does not turn on or display is dim.	Check battery installation. Ensure batteries are new and correctly inserted with proper polarity. Replace old batteries.

Problem	Solution
Time or date is incorrect.	Follow the 'Setting Time and Date' instructions to reset the current time, year, month, and date.
Alarm does not sound or cannot be turned off.	Ensure the alarm is activated (alarm icon visible on display). Follow 'Setting Alarm' instructions to verify alarm time. If alarm cannot be turned off, try removing and reinserting batteries to reset the clock.
Temperature reading seems inaccurate.	Ensure the clock is placed in an area with stable ambient temperature, away from direct sunlight or heat sources.

Specifications

- **Brand:** Keyscaper
- **Model:** Dallas Cowboys Color Block Digital Desk Clock
- **Display Type:** Digital
- **Special Feature:** Temperature Display
- **Power Source:** Battery Powered (Batteries not included)
- **Material:** 80% Plastic/20% Chipboard
- **Indoor/Outdoor Usage:** Indoor
- **Mounting Type:** Tabletop
- **Item Weight:** 12 ounces

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Keyscaper customer service directly. Keep your purchase receipt for warranty claims.