Toputure TP2

User Manual

Toputure 2-in-1 Electric Treadmill with Incline

Model: TP2

Toputure

Your guide to safe and effective use.

Important Safety Information

Please read this manual thoroughly before operating the treadmill. Keep this manual for future reference.

- Always place the treadmill on a solid, level surface with adequate clearance around it.
- Keep children and pets away from the treadmill during operation.
- Ensure the safety key is properly attached to both the treadmill and your clothing before starting. In case of emergency, the safety key will stop the machine.
- Do not exceed the maximum user weight capacity of 130 kg (286 lbs).
- Use only the provided power cord and connect to a properly grounded outlet.
- If you experience pain, dizziness, or shortness of breath, stop exercising immediately and consult a physician.
- Do not attempt to service the treadmill beyond the maintenance instructions in this manual. Contact customer support for assistance.

Product Overview

The Toputure 2-in-1 Electric Treadmill is designed for both walking and running, offering a versatile fitness solution for your home or office. Its foldable design and integrated wheels ensure easy storage and portability.



The treadmill features a foldable handlebar for upright running and can be folded flat for under-desk walking.



Easily switch between walking mode (1-6 km/h) and running mode (6-12 km/h) to suit your workout intensity.



The integrated LED display shows key workout metrics, and the magnetic remote control allows for easy speed adjustments.

Setup

The Toputure TP2 treadmill is designed for minimal setup, allowing you to start your workout quickly.

1. **Unpacking:** Carefully remove the treadmill from its packaging. Retain all packaging materials for potential future transport or returns.

2. **Placement:** Choose a flat, stable surface for the treadmill. Ensure there is at least 2 meters (6.5 feet) of clear space behind the treadmill and 0.6 meters (2 feet) on each side.
3. **Unfolding (if applicable):** If the handlebar is folded, gently lift it into the upright position until it locks securely.
4. **Power Connection:** Plug the power cord into the treadmill's power input and then into a grounded electrical outlet.
5. **Safety Key:** Attach the safety key clip to your clothing and place the magnetic end onto the designated area on the treadmill's console. The treadmill will not operate without the safety key in place.



The treadmill is lightweight (23 kg) and features front wheels for easy movement and storage.

Operating Instructions

Familiarize yourself with the controls and features for an optimal workout experience.

- **Power On/Off:** Press the power button on the treadmill or remote control to turn the unit on or off.
- **Starting a Workout:** With the safety key in place, press the START button. The treadmill will begin at a low speed.
- **Speed Adjustment:** Use the '+' and '-' buttons on the remote control or the console to increase or decrease speed. The speed range is 1-12 km/h.
- **Pause Function:** Press the PAUSE button on the remote control to temporarily stop your workout while retaining your data. Press again to resume.
- **LED Display:** The integrated LED display shows real-time data including time, distance, speed, and calories burned.
- **Incline Feature:** This treadmill features a 7% fixed incline option. Adjust the support bolt at the center to engage the incline, simulating an uphill walk or run. This feature helps burn more calories.



The 7% incline feature simulates uphill training, enhancing calorie burn.



Connect to popular fitness apps like Fitshow, Kinomap, and Zwift for personalized workouts and data tracking.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Lubrication:** The treadmill features a unique lubrication hole for convenient maintenance. Apply silicone oil (not included) as per the instructions in the detailed manual to the running belt every 30-50 hours of use or every 1-2

months, depending on usage frequency.

- **Cleaning:** Wipe down the treadmill with a damp cloth after each use to remove sweat and dust. Do not use abrasive cleaners.
- **Belt Tension and Alignment:** Periodically check the running belt for proper tension and alignment. Refer to the full manual for detailed instructions on how to adjust if necessary.
- **Storage:** When not in use, the treadmill can be folded flat to save space. Its compact design (130*56*13.5 cm) allows it to be stored under a sofa or bed. Use the integrated wheels to easily move it.



The advanced 2.5HP silent motor operates at less than 45dB, ensuring a quiet workout.

Troubleshooting

If you encounter any issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Treadmill does not start.	Safety key not in place, power cord disconnected, power switch off.	Ensure safety key is properly attached. Check power cord connection and power switch.
Running belt slips.	Belt too loose, insufficient lubrication.	Adjust belt tension (refer to manual). Apply silicone oil to the running belt.
Unusual noise during operation.	Loose parts, lack of lubrication, uneven surface.	Check for and tighten any loose screws. Lubricate the running belt. Ensure treadmill is on a level surface.
Remote control not responding.	Low battery, interference.	Replace remote control battery. Ensure no obstructions between remote and treadmill.

For issues not listed here, or if solutions do not resolve the problem, please contact customer support.

Specifications

Feature	Specification
Brand	Toputure
Model Number	TP2
Product Dimensions (Unfolded)	120 x 52 x 12 cm (47.2 x 20.5 x 4.7 inches)
Folded Dimensions	136 x 15 x 61 cm (53.5 x 5.9 x 24 inches)
Item Weight	23 Kilograms (50.7 lbs)
Color	Black
Material	Steel Alloy
Motor Horsepower	2.5 HP
Speed Range	1-12 km/h (0.6-7.5 mph)
Max User Weight Capacity	130 kg (286 lbs)
Display Type	LCD
Number of Programs	12
Power Source	Corded Electric
Recommended Uses	Walking, Running, Jogging
Package Contents	Power cable, Safety key, Tool kit, User manual, Remote control

Warranty and Support

Warranty Information: This product typically comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact the seller for specific details regarding warranty duration and coverage.

Customer Support: For any questions, technical assistance, or service requests, please contact the seller or manufacturer directly. Keep your purchase receipt and product model number (TP2) ready when contacting support.

© 2024 Toputure. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question