TwoOases TC-SC-001

TwoOases 2500W High Pressure Handheld Steam Cleaner User Manual

Model: TC-SC-001

Brand: TwoOases

Introduction

This manual provides essential information for the safe and effective operation of your TwoOases 2500W High Pressure Handheld Steam Cleaner. This powerful 2500W unit delivers 221°F/105°C high-temperature, 3Bar high-pressure steam in just 15 seconds, making it ideal for melting and removing stubborn dirt, grime, and stains without harsh chemicals.

Important Safety Information

- Every steam cleaner is tested before leaving the factory, so water marks may be present on the water inlet hose. This is normal.
- There is no control unit on the spray gun. To stop steaming, turn off the main power switch on the machine's body.
- **Caution:** Do not touch the metal nozzle or the steam directly. Do not spray steam at humans, pets, or the device itself. High temperatures can cause burns.
- Ensure the gasket is correctly positioned to prevent air and water leakage.
- Always wear the provided gloves during operation.

Package Contents

Verify that all items are included in your package:

- 1 x Steam Cleaner Machine with Tank
- 1 x 2m Steam Pipe
- 1 x 1.5m Power Cord
- 1 x Extension Tube
- 2 x Steel Brush
- 2 x Plastic Brush

- 1 x Big Plastic Brush
- 1 x Glove
- 2 x Waterproof Ring
- 1 x User Manual



Image: All components included in the TwoOases steam cleaner package, laid out on a white surface. This includes the main unit, various brushes, hoses, power cord, and gloves.

Setup Instructions

1. **Fill Water Tank:** Pull out the top cover and fill the 1100ml water tank with clean water. The tank supports refilling

during operation.



Image: A hand pouring water into the top opening of the steam cleaner's water tank.

2. **Attach Accessories:** Select and install the appropriate brush head or extension tube for your cleaning task.



Image: A hand attaching a brush accessory to the end of the steam cleaner's spray gun.

3. **Connect Power:** Plug the 1.5m power cord into a suitable electrical outlet.

Operating Instructions

1. **Power On:** Start the steam cleaner by pressing the power switch. The unit will heat up in approximately 15 seconds.
2. **Adjust Steam Level:** Use the smart touch screen with '+' or '-' buttons to adjust the steam output and humidity across 6 different levels. The screen will display the real-time gear.



Image: The steam cleaner's control panel showing the 6-grade adjustable steam output and real-time gear display.

3. **Begin Cleaning:** Once ready, hold the steam spray gun and aim at the dirty surface. The 2m steam pipe and extension tube allow for deep cleaning in crevices and corners.



Image: The TwoOases steam cleaner in action, demonstrating high-pressure, high-temperature steam being applied to a kitchen surface.

4. **Stop Steaming:** To stop the steam, turn off the main power switch on the machine's body.

Cleaning Applications

This versatile steam cleaner is suitable for a wide range of surfaces and cleaning tasks:

- **Kitchen:** Stoves, walls, microwaves, refrigerators, countertops, sinks, and greasy surfaces.
- **Bathroom:** Tiles, grout, toilets, showers, and fixtures.
- **Living Areas:** Hard floors, upholstery, furniture, carpets, and windows.
- **Automotive:** Car interiors, wheels, and other vehicle surfaces.
- **Other:** Toys, BBQ grills.



Image: A "Before and After" comparison showing a dirty stove being cleaned effectively with the steam cleaner, highlighting its deep cleaning capabilities.

Your browser does not support the video tag.

Video: Demonstrates the 6-speed touch adjustable button and smart screen for efficient steam cleaning.

Maintenance

1. **Empty Water Tank:** After each use, pull out the stopper under the tank to empty all remaining water.
2. **Clean Nozzle:** Use the provided long needle to clean the brass tip of the spray gun to prevent blockages.
3. **Storage:** Store the unit and accessories in a dry, safe place.

Your browser does not support the video tag.

Video: Shows how to clean the brass tip with the provided needle and the non-slip handle for easy carrying.

Troubleshooting

- **No Steam/Cold Mist:** Ensure the unit is powered on and has had sufficient time (approx. 15 seconds) to heat up. Verify the water tank is filled. If the issue persists, check the power connection.
- **Water/Air Leakage:** Confirm that the waterproof rings and gaskets are correctly installed and sealed.
- **Difficulty Cleaning Stubborn Stains:** Increase the steam level using the touch adjustment buttons. For very tough grime, use the steel brush attachment.

Specifications

Feature	Specification
Model Name	Handheld Steam Cleaner (TC-SC-001)
Power	2500W
Voltage	120V (AC)
Max Temperature	221°F / 105°C
Steam Pressure	3 Bar
Heat Time	15 Seconds
Water Tank Volume	1100ml
Item Weight	3.8 lbs (1.7 kg)
Product Dimensions	5.7"D x 7.9"W x 5.2"H
Steam Pipe Length	2m
Power Cord Length	1.5m

Warranty and Support

If you find any parts damaged after receiving the product or have any other questions, please contact us. We will respond within 24 hours to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question