Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MEDION MD 11475

MEDION MD 11475 Microwave Oven User Manual

Model: MD 11475

1. Introduction

This user manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your MEDION MD 11475 Microwave Oven. Please read this manual thoroughly before using the appliance and keep it for future reference.
The MEDION MD 11475 is a compact and efficient microwave oven designed for quick and convenient heating, cooking, and defrosting of various food items. It features a 20-liter capacity and 700 watts of power, making it suitable for everyday use.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not operate the oven if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- Always ensure the turntable and turntable support are correctly placed before operation.
- Do not use corrosive chemicals or vapors in this appliance.
- Regularly inspect the oven for any signs of damage to the door, door seals, and oven cavity.

3. Setup and Installation

Follow these steps for proper setup of your microwave oven:

1. **Unpacking:** Carefully remove the microwave oven and all packing materials. Check for any damage. Do not remove the light brown mica sheet that is attached to the oven cavity to protect the magnetron.
2. **Placement:** Place the oven on a flat, stable surface that can support its weight. Ensure there is adequate ventilation space around the oven: at least 20 cm (7.9 inches) above, 10 cm (3.9 inches) at the back, and 5 cm (2 inches) on each side.

3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the appliance's requirements (230 Volts).
4. **Turntable Assembly:**
    - Place the turntable support ring in the center of the oven cavity.
    - Place the glass turntable plate on top of the support ring, ensuring it sits securely in the center hub.

Figure 3.1: The MEDION MD 11475 Microwave Oven with its door open, illustrating the interior cavity, glass turntable, and overall dimensions (Length: 430mm, Height: 240mm, Depth: 330mm). This image helps visualize the space required for installation.

4. Operating Instructions

Your MEDION MD 11475 microwave oven features two simple control dials for power level and cooking time.

4.1 Control Panel Overview

Figure 4.1: Front view of the MEDION MD 11475 Microwave Oven, highlighting the two rotary control dials on the right side. The top dial controls the power level, and the bottom dial sets the cooking time.

- **Top Dial (Power Level):** Used to select one of the 5 available power levels.
- **Bottom Dial (Timer):** Used to set the cooking time, up to 30 minutes.

4.2 Setting Power Levels

The oven offers 5 power levels to suit different cooking needs:

Power Level Symbol	Description	Typical Use
☀ (Snowflake)	Defrost	Defrosting frozen foods gently.
~ (Low Wave)	Low	Keeping food warm, softening butter.
~~ (Medium Wave)	Medium	Slow cooking, simmering.
~~ (High Wave)	Medium-High	Reheating, cooking vegetables.
~~ (Max Wave)	High (700W)	Fast cooking, boiling liquids.

Figure 4.2: This image visually represents the versatility of the microwave's 5 power levels, showing different types of meals that can be prepared or reheated, such as pasta and a salmon with vegetables dish.

4.3 Defrosting Function

The defrost setting (indicated by the snowflake symbol) allows for gentle and even thawing of frozen foods. To use:

1. Place the frozen food in a microwave-safe dish.
2. Turn the top dial to the "Defrost" (snowflake) setting.
3. Turn the bottom dial to set the desired defrosting time. Refer to food packaging for recommended times.
4. The oven will start automatically. Turn food over halfway through defrosting for best results.

Figure 4.3: A pile of frozen mixed vegetables, including broccoli, carrots, and peas, demonstrating the microwave's efficient defrosting capability for quick and gentle thawing.

4.4 General Cooking

1. Place food in a microwave-safe container.
2. Close the oven door securely.
3. Turn the top dial to select the desired power level.
4. Turn the bottom dial to set the cooking time. The oven will begin cooking immediately.
5. When the set time expires, the oven will automatically stop and a bell will sound.

5. Maintenance and Cleaning

Regular cleaning and proper maintenance will ensure the longevity and efficient operation of your microwave oven.

- **Cleaning the Interior:** After each use, wipe the inside of the oven with a damp cloth. For stubborn stains, a mild detergent can be used. The white lacquered interior is designed for easy cleaning.
- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or

solvents.

- **Turntable:** The glass turntable and turntable support can be removed and washed in warm soapy water or in a dishwasher.
- **Door Seals:** Keep the door seals clean to ensure a proper seal.
- **Odor Removal:** To remove odors, combine a cup of water with the juice of one lemon in a microwave-safe bowl. Microwave on high for 5 minutes, then let it sit in the oven for another 5 minutes before wiping clean.

Figure 5.1: A hand using a green sponge to clean the white lacquered interior of the MEDION MD 11475 Microwave Oven, demonstrating the ease of maintenance for the appliance.

6. Troubleshooting

If you encounter issues with your microwave oven, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start.	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure plug is firmly in outlet; Close door securely; Check household fuse/circuit breaker.

Problem	Possible Cause	Solution
Food not heating.	Incorrect power level or time set; Food not suitable for microwave.	Adjust power level and time; Ensure food is microwave-safe.
Turntable not rotating.	Turntable not correctly placed; Debris under turntable.	Re-position turntable and support; Clean under turntable.
Unusual noise during operation.	Food container touching oven walls; Turntable not centered.	Adjust food container; Re-center turntable.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Model Number	MD 11475
Capacity	20 Litres
Power Output	700 Watts
Voltage	230 Volts
Dimensions (L x W x H)	43 x 33 x 24 cm (approx. 16.9 x 13 x 9.4 inches)
Weight	6 Kilograms (approx. 13.2 lbs)
Number of Power Levels	5
Control Type	Rotary Dials

8. Warranty and Support

MEDION products are manufactured to the highest quality standards. In the unlikely event of a defect, please refer to your purchase documentation for warranty details. For technical support, spare parts, or service inquiries, please visit the official MEDION website or contact their customer service department.
Please have your model number (MD 11475) and purchase date ready when contacting support.

© 2025 MEDION. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQD4T5HJ

More documents and user manuals: **https://manuals.plus/**