Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-BC1

Joyroom JR-BC1 ANC True Wireless Earbuds User Manual

Model: JR-BC1

Introduction

Thank you for choosing the Joyroom JR-BC1 ANC True Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.

Safety Information

- Do not disassemble or modify the earbuds or charging case.
- Keep the device away from extreme temperatures, humidity, and corrosive substances.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Clean the earbuds and charging case with a soft, dry cloth. Do not use liquids or abrasive cleaners.
- Dispose of the device responsibly according to local regulations.

Package Contents

Please check the package contents upon unboxing:

- Joyroom JR-BC1 ANC True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Ear Tips (various sizes)
- User Manual



Image: Contents of the Joyroom JR-BC1 ANC Earbuds package. This image displays the earbuds, their charging case, a USB charging cable, multiple sizes of ear tips, and the user manual, all neatly arranged.

Product Overview

Familiarize yourself with the components of your Joyroom JR-BC1 ANC True Wireless Earbuds.



Image: Joyroom JR-BC1 ANC True Wireless Earbuds in their open charging case. The earbuds are visible, with a green indicator light illuminated on the charging case, suggesting charging or power status.

Earbud Components

- **Touch Control Area:** For managing playback, calls, and ANC modes.
- **Microphone:** For calls and voice assistant.

- **Charging Contacts:** Connects to the charging case.
- **Ear Tip:** Provides comfort and sound isolation.



Image: Close-up view of the two Joyroom JR-BC1 ANC True Wireless Earbuds. This image highlights the sleek design of the individual earbuds, including the touch-sensitive surface and microphone placement.

Charging Case Components

- **Charging Port:** USB-C port for charging the case.
- **LED Indicator:** Shows charging status and battery level of the case.
- **Earbud Slots:** Holds and charges the earbuds.



Image: Closed Joyroom JR-BC1 ANC True Wireless Earbuds charging case. The image shows the compact, black charging case with the 'JOYROOM' logo subtly embossed on the lid.

Setup

1. Charging the Charging Case

1. Connect the provided USB charging cable to the charging port on the case.
2. Plug the other end of the cable into a USB power adapter (not included) or a computer's USB port.
3. The LED indicator on the case will show the charging status. A full charge is indicated when the LED remains solid or turns off, depending on the model's specific behavior.

2. Charging the Earbuds

1. Place the earbuds into their respective slots in the charging case. Ensure the charging contacts align.
2. Close the charging case. The earbuds will begin charging automatically if the case has power.
3. The indicator lights on the earbuds (if present) or the case will show their charging status.

3. Initial Pairing with a Device

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash (e.g., white and red alternately).
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices and select "Joyroom JR-BC1" from the list.
5. Once connected, the earbud indicator lights will turn off or flash slowly, and you will hear a confirmation tone.

4. Reconnecting

The earbuds will automatically reconnect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on the device and it is within range.

Operating

Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

Touch Controls

The Joyroom JR-BC1 earbuds feature touch-sensitive controls on each earbud. The specific functions may vary slightly, but common controls are:

Action	Function
Single Tap (Left/Right)	Play/Pause music, Answer/End call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right, 2s)	Reject Call
Long Press (Left/Right, 2s, during music)	Switch ANC/Transparency Mode

Active Noise Cancellation (ANC) and Transparency Mode

The JR-BC1 earbuds feature ANC to reduce ambient noise and Transparency Mode to allow you to hear your surroundings.

- **ANC Mode:** Reduces external noise for an immersive listening experience.
- **Transparency Mode:** Amplifies ambient sounds, allowing you to be aware of your surroundings without removing the earbuds.
- **Normal Mode:** Standard audio playback without noise cancellation or amplification.

To switch between these modes, long press the touch control area on either earbud for approximately 2 seconds until you hear an audible prompt indicating the mode change.



Image: A person wearing a Joyroom JR-BC1 earbud. This image demonstrates how the earbud fits in the ear, highlighting its ergonomic design for comfortable wear.

Maintenance

Cleaning

- Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Do not use sharp objects or abrasive materials to clean any part of the earbuds or case.

Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.

Battery Care

- To prolong battery life, avoid fully discharging the earbuds and charging case frequently.
- Charge the device regularly, even if not in frequent use, to prevent deep discharge.

Troubleshooting

If you encounter issues with your Joyroom JR-BC1 earbuds, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Joyroom JR-BC1" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back into the charging case, close the lid, wait a few seconds, then open and try again. Ensure both earbuds are charged.
No sound	Check device volume. Ensure earbuds are connected. Try playing audio from a different application or device.
Charging issues	Ensure charging cable is securely connected. Clean charging contacts on earbuds and case. Try a different USB port or power adapter.
ANC not effective	Ensure ANC mode is activated. Adjust earbud fit and try different ear tip sizes for a better seal.

Specifications

The following are general specifications for the Joyroom JR-BC1 ANC True Wireless Earbuds. For detailed technical specifications, please refer to the product packaging or official Joyroom website.

- **Model:** JR-BC1
- **Brand:** JOYROOM
- **Color:** Black
- **Connectivity:** True Wireless (Bluetooth)
- **Features:** Active Noise Cancellation (ANC)
- **Components Included:** 1 package (Earbuds, Charging Case, USB Cable, Ear Tips, User Manual)

Warranty and Support

Joyroom products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included in your package or visit the official Joyroom website. Please retain your proof of purchase for warranty claims.

© 2023 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQHW7G7Q

More documents and user manuals: **https://manuals.plus/**