Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Weston 65-0650-W

Weston Pro-1100 Programmable Stainless Steel Vacuum Sealer User Manual

Model: 65-0650-W
Brand: Weston

Product Overview

The Weston Pro-1100 Programmable Stainless Steel Vacuum Sealer is designed for efficient food preservation and sous vide preparation. It features a powerful 460-watt motor and user-friendly digital controls. This vacuum sealer creates strong, airtight seals on bags up to 11 inches wide, offering both automatic and manual operating modes.

Key Features

- **Powerful, Durable, 460 Watt Motor:** Fan-cooled for continuous, repetitive use without overheating.
- **Precise Control:** Manual sealing mode for delicate foods like cookies or pretzels, and non-food items such as photographs. Settings can be saved for repeated use.
- **Adjustable Digital Sealing Time and Easy-to-Use Digital Controls:** Digital control panel with LED lights allows for programmable, automatic, or manual modes and adjustable heating time.
- **Seals Bags Up to 11" Wide – Includes Roll Holder & Bag Cutter:** Accommodates vacuum sealer bags up to 11 inches (28 cm) across. Features a built-in roll holder and bag cutter for convenience.
- **Quickly Creates Strong, Airtight Seals:** Double-piston pump and a fast-acting, wide 5 mm heat bar ensure strong, airtight seals in seconds. The pump achieves up to 28" HG vacuum strength.

Safety Information

Please read all instructions carefully before operating the Weston Pro-1100 Vacuum Sealer.

- Always ensure the unit is unplugged before cleaning or performing maintenance.
- Do not immerse the appliance in water or other liquids.
- Keep hands clear of the sealing bar during operation as it becomes hot.
- Use only Weston brand vacuum sealer bags or compatible bags designed for external vacuum sealers.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is intended for household use only.

Setup

1. **Unpacking:** Carefully remove the vacuum sealer from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the unit on a flat, stable, and dry surface. Ensure adequate ventilation around the appliance.
3. **Power Connection:** Connect the power cord to the appliance and then plug it into a standard electrical outlet. Ensure the power switch is in the "OFF" position before plugging in.
4. **Bag Roll Installation (Optional):** If using a roll, install it into the built-in roll holder at the back of the unit. Pull out the desired length of bag material and use the integrated bag cutter to create a custom-sized bag.
5. **Initial Seal:** Before first use, it is recommended to perform a test seal on an empty bag to familiarize yourself with the process.



Image 1: The Weston Pro-1100 Vacuum Sealer, showing its compact design and control panel.



Image 2: Dimensions of the Weston Pro-1100 Vacuum Sealer, measuring 16.5"L x 15.6"W x 6.4"H.

Operating Instructions

Sealing a Bag

1. **Prepare Bag:** Place items into a vacuum sealer bag, leaving at least 2-3 inches of space from the top edge. Ensure the inside of the bag opening is clean and dry.
2. **Position Bag:** Open the lid of the vacuum sealer. Place the open end of the bag flat across the sealing bar, ensuring it is centered and smooth.
3. **Close Lid:** Firmly press down on both sides of the lid until it latches securely.
4. **Select Mode:**

- **Automatic Mode:** For most items, simply press the "Start" button. The machine will automatically vacuum the air out of the bag and then seal it.
- **Manual Mode (Pulse):** For delicate items or liquids, press the "Pulse" button repeatedly to control the vacuum strength. Once desired vacuum is achieved, press the "Manual Seal" button to seal the bag.

5. **Monitor Progress:** The LED lights and digital display will indicate the vacuuming and sealing progress.
6. **Release Bag:** Once the sealing cycle is complete, the machine will beep, and the lid will automatically release. Carefully remove the sealed bag.



Image 3: Demonstrates how the Weston Pro-1100 seals bags up to 11 inches wide, utilizing its built-in roll holder and bag cutter.



Image 4: Close-up of the fully adjustable sealing time and easy-to-use digital controls on the Weston Pro-1100.



Image 5: Illustrates the precise control feature for manual sealing, ideal for delicate items or objects.



Image 6: Shows the result of the powerful 28" HG double-piston pump and 5 mm heat bar, creating strong, airtight seals on various food items.



Image 7: The powerful 460-watt fan-cooled motor of the Weston Pro-1100, designed for continuous, repetitive use without overheating.

Using the Accessory Port

The Weston Pro-1100 features an accessory port for use with external vacuum canisters or other compatible accessories (sold separately).

1. Connect the accessory hose to the accessory port on the vacuum sealer and to the accessory container.
2. Place food items into the accessory container and secure the lid.
3. Press the "Accessory" button on the control panel. The machine will begin to vacuum air from the container.
4. Once the vacuum is complete, the machine will stop automatically. Disconnect the hose.

Maintenance

Cleaning

- Always unplug the unit before cleaning.
- Wipe down the exterior of the unit with a damp cloth and mild soap. Do not use abrasive cleaners.
- Clean the vacuum channel and sealing bar area regularly to prevent food particles from affecting performance.
- Ensure all parts are completely dry before storing or next use.

Gasket Care

- Inspect the foam gaskets around the vacuum channel regularly for any signs of wear, cracks, or damage.
- Clean the gaskets with a damp cloth. Ensure they are free of debris to maintain a proper seal.
- Replace gaskets if they appear damaged or if the unit is no longer achieving a strong vacuum. A maintenance kit is included with the product.



Image 8: The included maintenance kit, featuring an 11" x 50' vacuum seal roll and replacement gaskets for ongoing care.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Power switch off; Blown fuse.	Ensure unit is properly plugged in. Turn power switch to "ON". Check and replace fuse if necessary (8 AMP fuse only).
Machine not vacuuming properly.	Lid not latched; Gaskets dirty or damaged; Bag not positioned correctly; Bag material incompatible.	Press down firmly on both sides of the lid until latched. Clean or replace gaskets. Reposition bag, ensuring it is flat and smooth over the sealing bar. Use only Weston brand or compatible vacuum sealer bags.
Bag not sealing.	Sealing bar dirty or damaged; Bag too wet; Incorrect seal time setting.	Clean the sealing bar. Ensure the inside of the bag opening is dry. Adjust the seal time setting if needed (refer to digital controls).
Vacuum is too strong/weak for delicate items.	Using automatic mode for delicate items.	Use the "Pulse" function for manual control over vacuum strength.

Specifications

Brand: Weston

Model Number: 65-0650-W

Material: Stainless Steel

Color: Stainless Steel

Product Dimensions: 16.5"L x 15.6"W x 6.4"H

Item Weight: 10.1 Pounds

Power Source: AC/DC

Operation Mode: Semi-Automatic

Wattage: 460 watts

Voltage: 220 Volts

UPC: 812830027108

Warranty and Support

For warranty information, product registration, or technical support, please visit the official Weston website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Weston Official Website: www.westonbrands.com

Protection Plans: Additional protection plans may be available for purchase. Please refer to your retailer for details.

- 3-Year Protection Plan: Available for extended coverage.
- 4-Year Protection Plan: Available for extended coverage.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQKCZKZZ

More documents and user manuals: **https://manuals.plus/**