Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VCJ VCJ-66

VCJ Portable Twin Tub Washing Machine

Model: VCJ-66 Instruction Manual

1. Important Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power outlet matches the voltage requirements (120 volts). Do not operate with a damaged power cord or plug. Avoid touching the plug with wet hands.
- **Water Safety:** Do not immerse the appliance in water. Ensure proper drainage to prevent water accumulation.
- **Child Safety:** Keep children away from the appliance during operation. Do not allow children to play with the machine.
- **Placement:** Place the washing machine on a stable, level surface to prevent vibration and movement during operation.
- **Overloading:** Do not exceed the maximum wash (24 lbs) or spin (16 lbs) capacities to ensure efficient operation and prevent damage.

2. Setup and Installation

2.1 Unpacking

Carefully remove the washing machine from its packaging. Verify that all included components are present:

- VCJ Portable Twin Tub Washing Machine
- Drain Hose
- Spin Cover
- Water Inlet Hose

2.2 Placement

Position the washing machine on a firm, level surface. Ensure there is adequate space around the unit for ventilation and operation. The dimensions of the unit are 19.8"D x 34.4"W x 39.7"H.

2.3 Water Connection

Connect the provided water inlet hose to a suitable water faucet. Ensure the connection is secure to prevent leaks.

2.4 Drainage Setup

The machine is equipped with a built-in drain pump and an extended 4ft drain hose. Position the drain hose to direct water into a sink, tub, or drain. The drain height should ideally be lower than 3.3 feet for optimal drainage.



Figure 1: The VCJ Portable Twin Tub Washing Machine showing its built-in drain pump and extended drain hose for easy water disposal. The recommended drain height is below 3.3 feet.

3. Operating Instructions

The VCJ Portable Twin Tub Washing Machine allows for simultaneous washing and spinning, saving time and effort.

3.1 Washing Clothes

1. **Load Clothes:** Open the wash tub lid and place clothes inside. Do not exceed the 24 lbs wash capacity. Distribute items evenly.
2. **Add Water:** Fill the wash tub with water to the desired level.
3. **Add Detergent:** Pour the appropriate amount of laundry detergent into the wash tub.
4. **Set Wash Cycle:** Turn the 'Wash Selector' knob to either 'Soft' or 'Standard' depending on the fabric type.

5. **Set Wash Timer:** Turn the 'Wash Timer' knob to set the desired washing duration, up to 15 minutes. The machine will start automatically.



Figure 2: Illustration of the VCJ Portable Twin Tub Washing Machine's capacity, capable of handling large loads such as 28 T-shirts, 11 pairs of pants, 5 coats, or 3 sets of sheets.



Figure 3: Top view of the VCJ Twin Tub Washing Machine, highlighting the wash and spin tubs, control knobs for wash selector, wash timer, drain selector, and spin timer. It features 540W washing power and 250W spinning power.

3.2 Spinning Clothes

1. **Transfer Clothes:** Once the wash cycle is complete, transfer the wet clothes from the wash tub to the spin tub. Do not exceed the 16 lbs spin capacity.
2. **Place Spin Cover:** Securely place the spin cover on top of the clothes in the spin tub.
3. **Set Spin Timer:** Turn the 'Spin Timer' knob to set the desired spinning duration, up to 5 minutes. The machine will start spinning automatically.

3.3 Draining Water

After washing or spinning, turn the 'Drain Selector' knob to the 'Drain' position to empty the water from the machine.

3.4 Operational Videos

Video 1: Official VCJ video demonstrating the portable washing machine and its features, highlighting its convenience for daily life.

Video 2: Official VCJ video showcasing the small washing machine in operation, demonstrating its compact size and functionality.

4. Maintenance

4.1 Cleaning the Built-in Filter

Regularly clean the built-in filter located in the wash tub to prevent lint and debris buildup. This ensures optimal washing performance and prevents drainage issues.

1. Carefully remove the filter from its housing.
2. Rinse the filter under running water to remove any accumulated lint or particles.
3. Reinsert the clean filter securely into its position.

4.2 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface.

4.3 Storage

If the machine will not be used for an extended period, ensure all water is drained, and the interior is dry. Store the appliance in a cool, dry place away from direct sunlight.



Figure 4: Close-up view of key components including the water inlet, built-in filter, and drain hose, essential for maintenance and operation.

5. Troubleshooting

If you encounter issues with your washing machine, refer to the following common troubleshooting steps:

- **Machine Not Starting:**
  - Check if the power cord is securely plugged into a working electrical outlet.
  - Ensure the 'Wash Timer' or 'Spin Timer' knob is set to a duration other than '0'.
- **Water Not Draining:**
  - Verify that the drain hose is not kinked, blocked, or positioned too high.
  - Ensure the 'Drain Selector' knob is set to the 'Drain' position.
  - Check the built-in filter for excessive lint or debris that might be obstructing drainage.
- **Excessive Vibration or Noise:**

- Ensure the machine is placed on a stable and level surface.
- Redistribute clothes evenly within the wash or spin tub to balance the load.

- **Poor Washing Performance:**
  - Avoid overloading the wash tub; adhere to the 24 lbs capacity.
  - Use the appropriate amount and type of detergent for your load.
  - Ensure sufficient water is added for the wash cycle.

6. Specifications

Feature	Specification
Brand	VCJ
Model Name	VCJ-66
Product Dimensions (D x W x H)	19.8"D x 34.4"W x 39.7"H
Wash Capacity	24 pounds
Spin Capacity	16 pounds
Item Weight	47.4 pounds
Material	Polypropylene (PP plastic drum)
Color	Blue and white
Operation Mode	Semi Automatic
Max Rotational Speed	1300 rpm
Voltage	120 volts
Special Feature	High Efficiency
Included Components	Drain Hose, Spin cover, Water inlet hose



Figure 5: Dimensions of the VCJ Portable Twin Tub Washing Machine, showing its height (39.7 inches), width (34.4 inches), and depth (19.8 inches).

7. Warranty and Support

7.1 Warranty Information

This VCJ Portable Twin Tub Washing Machine (Model VCJ-66) comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact VCJ customer support. Refer to your purchase documentation or the VCJ official website for contact details.

© 2023 VCJ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQLT64HG

More documents and user manuals: **https://manuals.plus/**