Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Outspurge Full Automatic Washer Machine

Outspurge Full Automatic Portable Washer Instruction Manual

Model: YX01-104M

Product Overview

The Outspurge Full Automatic Portable Washer is designed for household use, offering convenience and efficiency in a compact form factor. Ideal for apartments, RVs, dormitories, and other small living spaces, this washing machine features 10 wash programs, 5 water level selections, and an intuitive LED display. Its portable design with built-in wheels and handles ensures easy transit, while energy-saving features contribute to reduced utility consumption. Safety features like child lock and automatic unbalance detection enhance user experience.





Figure 1: Front view of the Outspurge Full Automatic Portable Washer.

Setup Guide

1. Unpacking and Positioning

Carefully remove the washing machine from its packaging. Ensure all packing materials, especially the inner tube protection foam board located at the bottom, are removed before operation. The unit is equipped with two wheels for easy mobility. Tilt the machine slightly and roll it to your desired location.

Your browser does not support the video tag.

Video 1: Demonstrates unpacking, installing the bottom rodent panel, and utilizing the wheels for mobility.



Figure 2: Underside of the washing machine, showing the area for bottom cover installation to reduce noise and protect internal components.



Figure 3: Detail of the portable wheels, allowing the washer to be easily moved across surfaces.

2. Connecting Water Inlet

Connect the water inlet hose to the designated port at the back of the washing machine. Ensure a tight connection to prevent leaks. Use the provided quick connect adapter kit (US Standard size faucet adaptor) to attach the other end of the hose to your faucet. Verify that the faucet is compatible (not pull-out, non-removable aerator, or spout faucet).



Figure 4: Water inlet hose connection point on the washing machine.



Figure 5: Quick connect adapter kit for attaching the water hose to a standard faucet.

Your browser does not support the video tag.

Video 2: Shows the process of connecting the water inlet hose to the washer and faucet.

3. Drainage Setup

The washing machine features a built-in powerful pump for drainage. Simply hang the drain hose over a bathtub or sink. Ensure the hose is securely positioned to prevent it from falling during drainage.



Figure 6: Drain hose connection on the side of the washing machine.

Your browser does not support the video tag.

Video 3: Illustrates how to position the drain hose for effective water discharge.

Operating Instructions

1. Control Panel Overview

The control panel features an LED display and push buttons for easy operation. It provides options for 10 wash programs and 5 water level selections.



Figure 7: Detailed view of the control panel, showing water levels, functions, and wash programs.

Your browser does not support the video tag.

Video 4: Demonstrates the control panel functions, including water level and program selection.

2. Washing Programs and Water Levels

- **Water Levels:** Choose from 5 levels (1/17L, 2/22L, 3/27L, 4/32L, 5/37L) to match your laundry load and conserve water.
- **Functions:** Options include Soak, Wash, Rinse, and Spin.
- **Programs:** Select from 10 programs: Normal, Standard, Quick Wash, Heavy Duty, Soak & Wash, Wash, Wash & Rinse, Rinse & Spin, Spin, and Air Dry.
- **Delay Start:** Program the washer to start up to 24 hours later.



Figure 8: Visual representation of the washer's features, including 10 programs, child lock, and energy saving.

3. Child Lock Function

To prevent accidental operation by children, the washer includes a child lock function. Refer to the detailed user manual for specific instructions on activating and deactivating this feature. The washer also stops operation when the lid is opened during a cycle.



Figure 9: The child lock feature ensures safety by preventing unintended operation.

Maintenance

1. Lint Filter Cleaning

The washer is equipped with a built-in lint filter to collect debris during washing. Regularly clean the lint filter to maintain optimal performance and prevent clogging. The filter is easily removable for cleaning.



Figure 10: The built-in filter effectively collects lint and debris during the wash cycle.

2. Tub Self-Clean

Utilize the Tub Self-Clean function periodically to prevent bacterial spread and maintain hygiene within the stainless steel inner tub.

Specifications

Feature	Detail
Brand	Outspurge
Model Number	YX01-104M

Feature	Detail
Capacity	1.34 Cubic Feet
Dimensions (D x W x H)	18.5" x 18.5" x 30.7"
Item Weight	39.6 pounds
Material Type	PP plastic
Color	White
Control Console	Push Button
Access Location	Top Load
Voltage	110 Volts
Special Features	Child Lock, Auto Unbalance Detection (AUD)
Included Components	Adaptor, Water inlet hose, Bottom cover, Manual

Customer Support

For any issues or inquiries regarding your Outspurge Full Automatic Portable Washer, please contact our customer service team. We are committed to providing perfect after-sales service and ensuring your satisfaction.
You can find contact information on the official Outspurge website or through your purchase platform.

© 2024 Outspurge. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQLVHMND

More documents and user manuals: **https://manuals.plus/**