Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi EN127.S

De'Longhi Nespresso Pixie EN127.S Coffee Machine User Manual

Model: EN127.S

Introduction

This manual provides detailed instructions for the safe and efficient use of your De'Longhi Nespresso Pixie EN127.S coffee machine. Designed for ease of use, this compact machine allows for the preparation of espresso and lungo coffees with a simple touch.
Please read this manual thoroughly before first use and keep it for future reference.

Safety Instructions

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands and cords away from hot parts of the appliance during operation.
- This appliance is for household use only.
- Do not use accessories not recommended by the manufacturer.

Setup

1. Unpacking and Initial Placement

Carefully remove the coffee machine from its packaging. Place the machine on a flat, stable, heat-resistant surface, away from water splashes and heat sources. Ensure adequate space around the machine for ventilation and access.



Image: The Nespresso Pixie EN127.S coffee machine, silver and black, shown with a selection of Nespresso coffee capsules.

2. Rinsing Before First Use

Before preparing your first coffee, it is essential to rinse the machine to clean the internal system.

1. Fill the water tank with fresh drinking water.
2. Place a container (at least 0.5L) under the coffee outlet.
3. Press either the Espresso or Lungo button. The machine will start pumping water. Repeat this process 2-3 times until clean water flows through.





Image: Rear view of the Nespresso Pixie EN127.S, highlighting the transparent water tank on the right side.

3. Filling the Water Tank

Lift the water tank lid and fill the tank with fresh drinking water up to the 'MAX' level indicator. Close the lid securely.

Operating Instructions

1. Powering On

Plug the machine into a grounded power outlet. Press either the Espresso or Lungo button to turn on the machine. The buttons will blink while heating up (approximately 25 seconds) and become steady when ready for use.

NESPRESSO

COME ADERIRE ALLA PROMOZIONE CAFFÈ:

1. Cerca il **codice seriale** che trovi sull'etichetta sulla macchina

2. Utilizza il **codice promozionale** che ti ha inviato Amazon sulla tua email dopo che hai acquistato la macchina

3. Segui le istruzioni che trovi nella email per usare subito il tuo sconto nel tuo primo ordine di caffè **Nespresso**

Promozione valida sulle macchine vendute e spedite da Amazon.

Image: Top-down view of the Nespresso Pixie EN127.S, clearly showing the two coffee selection buttons for Espresso and Lungo.

2. Preparing Coffee

1. Lift the lever completely to open the capsule insertion slot.
2. Insert a Nespresso capsule into the slot.
3. Close the lever firmly.
4. Place a cup under the coffee outlet.
5. Press the **Espresso** button for a small cup (40 ml) or the **Lungo** button for a larger cup (110 ml). The machine will automatically stop when the programmed volume is reached.
6. After brewing, lift the lever to eject the used capsule into the capsule container.



Image: The Nespresso Pixie EN127.S machine actively dispensing coffee into a clear glass cup, showcasing the brewing process.

3. Programming Coffee Volume

You can customize the volume for Espresso and Lungo buttons:

1. Ensure the machine is on and ready.
2. Insert a Nespresso capsule.

3. Press and hold the button (Espresso or Lungo) you wish to program. Release the button when the desired volume of coffee has been dispensed into your cup. The machine will remember this volume for future use.

4. Powering Off

The machine will automatically turn off after 9 minutes of inactivity to save energy. To manually turn it off, press and hold both the Espresso and Lungo buttons simultaneously for 3 seconds.

Maintenance

1. Daily Cleaning

- **Drip Tray and Capsule Container:** Empty and rinse the drip tray and used capsule container daily. These components are not dishwasher safe.
- **Water Tank:** Rinse the water tank with fresh water daily.
- **Machine Exterior:** Wipe the machine's exterior with a soft, damp cloth. Do not use abrasive cleaning agents or immerse the machine in water.

2. Descaling

Regular descaling is crucial to maintain the machine's performance and coffee quality. The frequency depends on water hardness and usage. Refer to the Nespresso descaling kit instructions for the specific procedure. Generally, descaling is recommended every 3-6 months.
Note: The machine does not have a dedicated descaling alert light, so manual tracking is required.

Troubleshooting

Problem	Possible Cause	Solution
No coffee flow or very slow flow.	Water tank empty, machine needs descaling, or capsule is blocked.	Fill water tank. Perform descaling. Check capsule for proper insertion or try a new capsule.
Coffee is not hot enough.	Machine not fully heated, or cups are cold.	Wait for buttons to stop blinking. Preheat cups with hot water.
Water leaking from machine.	Water tank not correctly positioned, or internal issue.	Ensure water tank is seated properly. If problem persists, contact customer support.
Machine does not turn on.	No power supply.	Check power cord connection and wall outlet.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Brand:** De'Longhi / Nespresso
- **Model Name:** EN127.S
- **Product Dimensions:** 12.76"D x 4.61"W x 9.25"H
- **Item Weight:** 5.5 pounds
- **Coffee Maker Type:** Espresso Machine
- **Operation Mode:** Fully Automatic
- **Special Feature:** Programmable coffee volume

- **Pressure:** 19 Bar
- **Power:** 1260W
- **Coffee Input Type:** Nespresso Coffee capsule
- **Included Components:** Cup Removable Drip Tray, Used Capsule Tray (holds 11 capsules)
- **Exterior Finish:** Silver, Aluminum

Warranty and Support

Your De'Longhi Nespresso Pixie EN127.S coffee machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.
For technical assistance, troubleshooting beyond this manual, or to inquire about spare parts, please contact Nespresso or De'Longhi customer service. EU spare part availability duration is 2 years.
You can find contact information on the official Nespresso or De'Longhi websites, or through your local retailer.

© 2025 De'Longhi / Nespresso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQPN4ZT3

More documents and user manuals: **https://manuals.plus/**