MIUZZY M241

MIUZZY M241 Cordless Vacuum Cleaner Detachable Battery Instruction Manual

Model: M241 | Brand: MIUZZY

Introduction

This manual provides essential instructions for the safe and effective use of your MIUZZY M241 detachable battery for cordless vacuum cleaners. Please read this manual thoroughly before using the battery and retain it for future reference. Proper use and maintenance will ensure optimal performance and extend the battery's lifespan.

Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this battery.

- Use only the charger specified by the manufacturer for this battery model. Using an incompatible charger may cause fire, electric shock, or damage to the battery.
- Do not disassemble, open, or shred the battery pack.
- Do not expose the battery to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit a battery pack. Do not store battery packs haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by conductive materials.
- Do not subject battery packs to mechanical shock.
- In the event of battery leakage, do not allow the liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Keep battery packs out of the reach of children.
- Do not use any battery pack that is not designed for use with the MIUZZY M241 cordless vacuum cleaner.
- Dispose of batteries properly according to local regulations.

Package Contents

Please check the package for the following items:

- MIUZZY M241 Detachable Battery (1 unit)
- Instruction Manual (this document)



Image: The MIUZZY M241 detachable battery, a black rectangular unit with connection points.

Product Overview

The MIUZZY M241 detachable battery is a Lithium-Ion power source designed specifically for MIUZZY M241 cordless vacuum cleaners. It provides reliable and consistent power for extended cleaning sessions. Its detachable design allows for convenient charging and replacement.



Image: A MIUZZY cordless vacuum cleaner, illustrating where the detachable battery is typically located on the main unit.

Setup and Installation

1. **Ensure Compatibility:** Verify that the battery model M241 is compatible with your MIUZZY cordless vacuum cleaner.
2. **Align Battery:** Locate the battery slot on your vacuum cleaner. Align the battery with the slot, ensuring the connectors match.
3. **Insert Battery:** Gently slide the battery into the slot until it clicks securely into place. Do not force the battery.
4. **Verify Connection:** Once installed, ensure the battery is firmly seated and does not wobble.

Charging the Battery

The MIUZZY M241 battery can be charged either while attached to the vacuum cleaner or separately, depending on your vacuum model's design. Always use the original MIUZZY charger provided with your vacuum cleaner.

1. **Connect Charger:** Plug the charger into a standard wall outlet.
2. **Attach to Battery:** Connect the charger's plug to the charging port on the battery (or on the vacuum cleaner if charging while attached).
3. **Monitor Charging:** The battery indicator lights on the vacuum or battery will typically show the charging status. Refer to your vacuum cleaner's manual for specific light patterns.
4. **Full Charge:** Disconnect the charger once the battery is fully charged to prevent overcharging.

Note: A new battery may not be fully charged and should be charged before first use.

Operation

Once the battery is fully charged and securely installed in your MIUZZY M241 cordless vacuum cleaner, you can operate the vacuum as usual. The battery provides power to the motor and other functions.

- **Power On/Off:** Use the power button on your vacuum cleaner to turn it on or off.
- **Power Modes:** If your vacuum has multiple power modes, the battery will supply power accordingly. Higher power modes will consume battery life faster.
- **Battery Indicator:** Pay attention to the battery indicator lights on your vacuum cleaner to monitor the remaining charge. Recharge the battery when it runs low.

Maintenance and Storage

- **Cleaning:** Wipe the battery's exterior with a dry, soft cloth. Do not use harsh chemicals or immerse the battery in water.
- **Storage:**
    - Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.

- For long-term storage, charge the battery to approximately 50-60% capacity. Do not store a fully depleted or fully charged battery for extended periods.
- If storing for several months, periodically check the charge level and recharge to 50-60% if necessary.

- **Disposal:** When the battery reaches the end of its life, dispose of it responsibly at a designated recycling facility. Do not dispose of batteries in household waste.

Troubleshooting

Problem	Possible Cause	Solution
Battery not charging	Charger not properly connected; Faulty charger or outlet; Battery too hot/cold; Damaged battery.	Ensure charger is securely plugged in. Try a different outlet. Allow battery to reach room temperature. If damaged, replace the battery.
Vacuum cleaner not powering on with battery	Battery not fully charged; Battery not properly installed; Battery fault; Vacuum cleaner fault.	Charge the battery fully. Reinstall the battery, ensuring it clicks into place. If issues persist, contact MIUZZY support.
Short operating time	Battery not fully charged; Using high power mode excessively; Battery degradation over time.	Ensure battery is fully charged before use. Use standard power mode for general cleaning. Battery capacity naturally decreases with age and cycles.

Specifications

Feature	Detail
Model Name	M241 Battery
Brand	MIUZZY
Battery Type	Lithium-Ion
Product Dimensions	5"L x 5"W x 5"H
Item Weight	1.08 pounds
Color	Black
Manufacturer	MIUZZY

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your MIUZZY M241

cordless vacuum cleaner or visit the official MIUZZY website. Keep your purchase receipt as proof of purchase for warranty claims.
If you encounter any issues not covered in this manual, please contact MIUZZY customer service for assistance.

© 2024 MIUZZY. All rights reserved.