Tefal EY905D28

Tefal Easy Fry & Grill Dual Air Fryer Instruction Manual

Model: EY905D28

Product Overview

The Tefal Easy Fry & Grill Dual Air Fryer, model EY905D28, is an innovative kitchen appliance designed to simplify your cooking experience. With its 8.3-liter capacity and independent dual drawers, it allows you to cook two different dishes simultaneously, ensuring a complete family meal is ready at the same time. This versatile appliance combines air frying and grilling functions, offering a healthier alternative to traditional frying with up to 99% less added fat.

It features eight pre-set cooking programs for various dishes, including grilling, air frying, roasting, baking, and broiling, all without the need for constant monitoring. The appliance is also energy-efficient, consuming up to 70% less energy and cooking up to 40% faster than a traditional oven. Cleanup is made easy with dishwasher-safe parts. Additionally, a free companion app provides a wealth of recipes and cooking inspiration, from quick 15-minute meals to ultra-healthy air-fried options.



Front view of the Tefal Easy Fry & Grill Dual Air Fryer, showcasing its sleek stainless steel design and digital control panel.

Safety Instructions

- Always place the appliance on a stable, heat-resistant surface, away from walls or other appliances, to ensure proper ventilation.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep children and pets away from the appliance during operation. The surface can become hot.
- Do not block the air inlet or outlet vents during operation.
- Unplug the appliance from the power outlet when not in use and before cleaning. Allow it to cool down completely before handling.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact authorized service personnel for repair.
- Use only accessories recommended by the manufacturer.

Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the appliance.

2. **Initial Cleaning:** Before first use, wipe the main unit with a damp cloth. Wash the removable drawers and grill plates with warm, soapy water, then rinse and dry thoroughly. All removable parts are dishwasher safe.
3. **Placement:** Place the air fryer on a flat, stable, heat-resistant surface. Ensure there is sufficient space around the appliance for air circulation (at least 10 cm on all sides).
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Side view of the air fryer showing its dimensions: approximately 42 cm (length), 40 cm (width), and 30.6 cm (height).

Operating Instructions

General Operation

1. **Prepare Food:** Place your ingredients into the appropriate drawer(s). The large drawer has a 5.2L capacity, and the smaller drawer has a 3.1L capacity.
2. **Select Program:** Choose one of the eight pre-set cooking programs (Fries, Chicken, Vegetables, Fish, Dessert, Dehydration, Manual, Grill) or manually set the temperature and time.
3. **Set Temperature and Time:** Use the digital controls to adjust temperature (up to 200°C) and cooking time as needed.
4. **Start Cooking:** Press the Start/Stop button to begin the cooking process.
5. **Shake/Flip (Optional):** For even cooking, especially with fries or smaller items, you may need to shake or flip the

food halfway through the cooking cycle. The appliance may beep to remind you.

6. **Finish Cooking:** The appliance will beep when the cooking cycle is complete. Carefully remove the drawers and serve.

Dual Zone Cooking

The Tefal Easy Fry & Grill Dual allows for synchronized cooking of two different dishes. Use the SYNC function to ensure both drawers finish cooking at the same time, even if they require different temperatures and cooking durations.

- **Drawer 1 (5.2L):** Ideal for larger items like a whole roasted chicken (up to 1.2kg) or substantial portions.
- **Drawer 2 (3.1L):** Suitable for smaller sides like fries (up to 800g) or vegetables.



The dual drawers of the air fryer, showing a larger drawer (5.2L) with grilled meat and a smaller drawer (3.1L) with grilled tomatoes, demonstrating simultaneous cooking.



The air fryer with a roasted chicken in the large drawer and fries in the smaller drawer, illustrating its family-friendly 8.3L capacity.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. **Unplug and Cool Down:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Drawers and Grill Plates:** The removable drawers and grill plates are dishwasher safe. For hand washing, use warm water and a non-abrasive sponge with dish soap. Do not use metal scouring pads or abrasive cleaning materials.
3. **Clean Main Unit:** Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
4. **Clean Heating Element:** If necessary, gently clean the heating element with a cleaning brush to remove any food residue.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.



The Extra-Crisp technology ensures golden, crispy results with minimal oil, making cleaning easier due to less grease buildup.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; drawer not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the drawer(s) firmly until they click into place.
Food is not cooked evenly.	Too much food in the drawer; food not shaken/flipped.	Do not overfill the drawers. Shake or flip food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the drawers and heating element thoroughly after each use. For fatty foods, consider using a small amount of water at the bottom of the drawer to reduce smoke.
Fries are not crispy.	Not enough oil; wrong potato type; temperature too low.	Ensure potatoes are dry before adding a small amount of oil. Use fresh potatoes suitable for frying. Increase temperature slightly.

Specifications

Model: EY905D28

Brand: Tefal

Capacity: 8.3 Liters (5.2L large drawer + 3.1L small drawer)

Power: 2700 Watts

Material: Aluminum

Color: Stainless Steel

Dimensions (L x W x H): Approximately 41.8 cm x 40.2 cm x 30.5 cm

Weight: 7.8 Kilograms

Special Features: Dual Zone features, Temperature Control, Timer, Stain Resistant, Programmable

Warranty and Support

The Tefal Easy Fry & Grill Dual Air Fryer (Model EY905D28) comes with a**two-year warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal household use.
What is covered:

- Defects in materials or workmanship.
- Malfunctions occurring during normal operation as per the instruction manual.

What is not covered:

- Damage caused by misuse, abuse, neglect, or accident.
- Normal wear and tear.
- Damage resulting from unauthorized repairs or modifications.
- Commercial use.

For warranty claims, technical support, or service inquiries, please contact Tefal customer service. Keep your proof of purchase for warranty validation.
You can also visit the officialTefal Store on Amazon for more information and product registration.

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question