Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sirena VC3968

Sirena Proflex PetVac 2-in-1 Cordless Stick Vacuum Cleaner

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Sirena Proflex PetVac 2-in-1 Cordless Stick Vacuum Cleaner. This versatile and powerful cleaning solution is designed to make your home cleaning tasks easier and more efficient, especially for pet owners. With its 350-Watt brushless motor, detachable handheld cleaner, and specialized attachments, the Sirena Proflex PetVac offers exceptional suction power for both hard floors and carpets, effectively removing dirt, dust, and pet hair.

Please read this manual thoroughly before operating the vacuum cleaner to ensure safe and optimal performance. Keep this manual for future reference.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything

that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Store the appliance indoors. Put away after use to prevent accidents.
- Use only the charger supplied by the manufacturer to recharge.

Package Contents

Please ensure all items are present and in good condition upon unpacking:

- Sirena Proflex PetVac Main Unit (Handheld Cleaner)
- Extension Wand
- Motorized Pet Brush
- Hard Brush Roller
- Foam Brush Roller
- Crevice Tool
- 2-in-1 Dusting Brush
- Dirt Cup
- HEPA Filter (1 pre-installed, 1 extra)
- Charging Base
- Power Adapter



Figure 1: Overview of Sirena Proflex PetVac components and accessories.

Setup

Assembly

1. **Attach the Extension Wand:** Align the main unit (handheld cleaner) with the top end of the extension wand. Push firmly until it clicks into place.
2. **Attach the Floor Head:** Connect the desired floor head (Motorized Pet Brush or Hard Brush Roller) to the bottom end of the extension wand. Ensure it clicks securely.
3. **Install the Dustbin and Filter:** Ensure the dirt cup and HEPA filter are correctly installed in the main unit. Refer to the 'Maintenance' section for filter installation details.

Charging the Battery

The Sirena Proflex PetVac comes with a rechargeable 25.2V/25000mAh battery. For optimal performance, fully charge

the battery before first use.

1. Mount the charging base to a wall in a convenient location, ensuring it's near a power outlet.
2. Connect the power adapter to the charging base and plug it into a wall outlet.
3. Place the vacuum cleaner onto the charging base. The LED display on the main unit will indicate charging status.
4. A full charge typically takes approximately 4 hours.



Figure 2: The vacuum cleaner charging on its wall-mounted dock, showing the LED display.

Operating Instructions

Power Modes

The Sirena Proflex PetVac features 3 power levels (Low, Medium, High) to suit various cleaning needs. The LED display

shows the current power mode and battery status.

- Press the power button once to turn on the vacuum in Low mode.
- Press the power button again to cycle through Medium and High modes.
- Press the power button a fourth time to turn off the vacuum.

Using Attachments

The 2-in-1 design allows for easy transition between stick and handheld modes, utilizing various attachments for comprehensive cleaning.

Video 1: Demonstrates the versatility of the Sirena Proflex with various attachments for different cleaning tasks.

- **Motorized Pet Brush:** Ideal for deep cleaning carpets and removing stubborn pet hair from upholstery. The rotating brush agitates fibers to lift embedded dirt and hair.
- **Hard Brush Roller:** Designed for effective cleaning on hard floor surfaces, preventing scratches while picking up debris.
- **Crevice Tool:** Perfect for reaching tight spaces, corners, and crevices in furniture, car interiors, and along baseboards.
- **2-in-1 Dusting Brush:** Use the brush bristles for delicate surfaces like keyboards, blinds, and shelves, or slide the bristles back to use as an upholstery tool for fabrics.



Figure 3: The vacuum's powerful suction and LED headlights effectively illuminate and capture hidden debris.



Figure 4: The lightweight design and versatile attachments allow for easy and comfortable cleaning in various areas.



Figure 5: The innovative combination brush head and various tools enable thorough deep cleaning throughout the entire home.

Maintenance

Emptying the Dustbin

For optimal suction and performance, empty the dustbin regularly, especially after each use or when debris reaches the MAX fill line.

1. Ensure the vacuum cleaner is turned off.
2. Locate the dustbin release button on the main unit.
3. Press the release button to open the bottom flap of the dustbin.
4. Hold the dustbin over a trash can and shake gently to empty all contents.

5. Close the dustbin flap securely until it clicks.

Cleaning the Filters

Regular cleaning of the HEPA filter and metal screen filter is crucial for maintaining suction power and air quality. It is recommended to clean the filter every 3 months or as needed.

1. Twist and pull to remove the dustbin from the main unit.
2. Carefully remove the HEPA filter and the metal screen filter from the dustbin.
3. Tap the filters gently over a trash can to remove loose dust and debris.
4. Rinse the HEPA filter and metal screen filter under cool, running water until the water runs clear. Do not use detergent.
5. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or other heating methods.
6. Once completely dry, reinsert the filters into the dustbin, then reattach the dustbin to the main unit.



Figure 6: The dustbin features a one-key opening for easy disposal, and the filters are washable for repeated use.



Figure 7: Detailed view of the 4-layer filtration system, including the HEPA filter and transparent dust bin.

Troubleshooting

If you encounter any issues with your Sirena Proflex PetVac, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged.	Charge the battery fully.

Problem	Possible Cause	Solution
	Power button not pressed correctly.	Ensure the power button is pressed firmly.
Low suction power	Dustbin is full.	Empty the dustbin.
	Filters are clogged.	Clean or replace the HEPA and metal screen filters.
	Brush roll is tangled.	Remove any hair or debris tangled around the brush roll.
	Hose or nozzle is blocked.	Check for and remove any blockages in the hose or nozzle.
Short battery runtime	Battery not fully charged.	Ensure the battery is fully charged before use.
	Using High power mode excessively.	High power mode consumes more battery. Use lower modes for lighter tasks.
Vacuum head lights not working	Connection issue.	Ensure the extension wand and floor head are securely connected.

Specifications

Feature	Detail
Brand	Sirena
Model Name	Proflex (VC3968)
Special Feature	Cordless
Filter Type	HEPA Filter
Included Components	Extension wand, crevice tool, dusting brush, upholstery tool, motorized pet brush, dirt cup, HEPA filter
Runtime	45 minutes
Recommended Uses	Carpet, Hard Floor, Pet Hair Removal
Form Factor	Stick
Color	Black
Battery Type	25.2V/25000mAh Lithium Ion (included)
Amperage	29.17 Amps

Feature	Detail
Motor Horsepower	0.47 horsepower
Number of Speeds	3
Product Dimensions	10 x 7 x 44 inches
Item Weight	11.62 pounds
Country of Origin	China
UPC	860006572822

Warranty and Support

The Sirena Proflex PetVac 2-in-1 Cordless Stick Vacuum Cleaner is covered by a manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included in your product packaging or visit the official Sirena website.

For technical support, replacement parts, or any inquiries regarding your product, please contact Sirena customer service through the contact information provided on the official Sirena website or your purchase documentation. Our dedicated support team is available to assist you with any questions or concerns.

© 2024 Sirena Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQRTR591

More documents and user manuals: **https://manuals.plus/**