Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo gazebo3x3

Bonnlo 3m x 3m Pop Up Gazebo with Sides Instruction Manual

Model: gazebo3x3

1. Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and care of your Bonnlo 3m x 3m Pop Up Gazebo with Sides. Designed for versatility and convenience, this outdoor shelter is suitable for various events such as picnics, parties, trade shows, and general outdoor use. Its easy-to-use design allows for quick setup and takedown, providing protection and privacy with its durable sidewalls.



Image 1.1: The Bonnlo 3m x 3m Pop Up Gazebo with Sides in gray, set up in a garden.

2. Safety Information

Please read and understand all safety warnings before assembly and use.

- **Anchoring:** Always ensure the gazebo is properly anchored to the ground using the provided ground nails and ropes to prevent it from tipping over, especially in windy conditions.
- **Weather Conditions:** Do not use the gazebo in high winds, heavy rain, or during thunderstorms. Disassemble and store the gazebo during adverse weather to prevent damage or injury.
- **Heat Sources:** Keep the gazebo away from open flames, heaters, barbecues, and other heat sources to prevent fire hazards. The fabric is not fireproof.
- **Assembly:** While designed for easy setup, it is recommended that at least two people assist with assembly to ensure stability and prevent injury.
- **Children:** Keep children away from the gazebo during assembly and disassembly. Do not allow children to play

unsupervised around or inside the gazebo.

3. Package Contents

Verify that all components listed below are present in your package before beginning assembly.

- 1x Folding Frame (Alloy Steel)
- 1x Canopy Cover (Polyester)
- 4x Sidewalls (Polyester)
- 8x Ground Nails
- 4x Ropes
- 1x Carry Bag



Image 3.1: All components included in the Bonnlo Pop Up Gazebo package.

4. Product Features

The Bonnlo Pop Up Gazebo is designed with user convenience and durability in mind.

- **Solid Construction:** Features a first-rate alloy steel frame and 210D oxford material for the canopy and sidewalls, ensuring durability.
- **Easy Setup:** Utilizes pull-pin sliders and push-button leg extenders for quick and straightforward assembly.
- **Sun Protection:** The waterproof polyester top provides 99% UV protection from the sun.
- **Water Resistance:** Canopy and sidewalls are waterproof, offering protection from light rain.
- **Adjustable Height:** The frame offers three height positions for customizable clearance.
- **Portability:** Folds compactly and includes a carry bag for easy transport and storage.



Image 4.1: Key structural details of the gazebo, including height adjusters and frame connections.

5. Setup Instructions

Follow these steps for a quick and easy assembly of your pop-up gazebo. It is recommended to have at least two people

for assembly.



Image 5.1: Visual representation of the four main setup steps.

1. **Step 1: Remove Frame from Bag.** Take the folded iron frame out of its carry bag and place it in the desired setup location.
2. **Step 2: Partially Unfold the Frame.** With a person at each end, gently pull the frame outwards to partially unfold it. Do not fully extend the legs yet.
3. **Step 3: Attach the Canopy.** Drape the canopy top cloth over the partially unfolded frame. Align the four corners of the canopy with the four corners of the frame. Secure the canopy to the frame using any attached fasteners (e.g., hook-and-loop straps).
4. **Step 4: Fully Extend and Lock the Frame.**Continue to pull the frame outwards until it is fully extended. Push up on the center hub of the frame until it locks into place. Extend each leg individually by pressing the push-button leg extenders and pulling the inner leg section down until it clicks into one of the height positions.
5. **Step 5: Attach Sidewalls (Optional).** If desired, attach the sidewalls to the gazebo frame using the integrated fasteners.

6. **Step 6: Secure the Gazebo.** Use the provided ground nails to anchor each leg to the ground. Attach the ropes to the canopy corners and stake them into the ground at an angle to provide additional stability.

Adjusting Height

The gazebo features three adjustable height positions. To adjust the height, locate the push-button leg extenders on each leg. Press the button and slide the inner leg section up or down to the desired height, ensuring it clicks securely into place at all four legs.



Image 5.2: Dimensions of the gazebo, including three adjustable height settings (2.5m, 2.59m, 2.68m).

6. Operating Instructions

Using the Sidewalls

The included sidewalls can be attached or removed as needed for privacy, shade, or protection from light wind and rain. They typically attach to the gazebo frame using hook-and-loop fasteners or ties. Ensure they are securely fastened to prevent flapping in the wind.

Disassembly

To disassemble the gazebo, reverse the setup steps:

1. Remove ground nails and ropes.
2. Detach sidewalls and canopy.
3. Press the push-button leg extenders and retract the inner leg sections.
4. Release the center hub lock and gently push the frame inwards to fold it.
5. Place all components back into the carry bag for storage.

7. Maintenance and Care

Cleaning

- Clean the canopy and sidewalls with a mild soap and water solution. Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric's waterproof and UV-protective coatings.
- Rinse thoroughly and allow all fabric components to air dry completely before folding and storing to prevent mildew.
- Wipe the steel frame with a damp cloth to remove dirt. Ensure the frame is dry before storage to prevent rust.

Storage

When not in use, store the gazebo in its carry bag in a cool, dry place, away from direct sunlight and extreme temperatures. Proper storage extends the product's lifespan.



Image 7.1: The gazebo folds compactly into its carry bag for easy transport and storage.

8. Troubleshooting

- **Difficulty Unfolding/Folding:** Ensure all locking mechanisms are disengaged before attempting to fold or unfold. Apply gentle, even pressure. Do not force the frame. Lubricate moving parts if necessary.
- **Gazebo Instability:** Confirm all legs are fully extended and locked into position. Ensure ground nails and ropes are properly secured. Disassemble the gazebo if wind conditions are too strong.
- **Water Leaks:** Check that the canopy is correctly positioned and taut on the frame. Ensure no tears or punctures in the fabric. While waterproof, extreme downpours may exceed its resistance.
- **Damaged Parts:** Inspect all components regularly for wear and tear. If any part is damaged, contact customer support for assistance. Do not use a damaged gazebo.

9. Specifications

Feature	Specification
Brand	Bonnlo
Model Number	gazebo3x3
Product Dimensions	118.11"L x 118.11"W x 105.51"H (approx. 3m x 3m x 2.68m)
Floor Area	9 Square Meters
Frame Material	Alloy Steel
Canopy/Sidewall Material	210D Oxford Polyester
Color	Gray
UV Protection	99% UV Protection
Water Resistance Level	Waterproof
Assembly Required	Yes
Recommended Uses	Beach, Outdoor Activities, Party, Trade Show

10. Warranty Information

Specific warranty details for the Bonnlo 3m x 3m Pop Up Gazebo with Sides are not provided within this instruction manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging, any included warranty cards, or contact Bonnlo customer support directly.

11. Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Bonnlo customer support. Refer to the contact information provided on the product packaging or the official Bonnlo website for the most up-to-date support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQXHXZX9

More documents and user manuals: **https://manuals.plus/**