Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood TAN-6055

Techwood TAN-6055 Portable Spot Cleaner and Stain Remover

User Manual

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the appliance from the power supply before cleaning or maintenance.
- Do not immerse the appliance in water or any other liquid.
- Keep the appliance away from children and pets.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not handle plug or appliance with wet hands.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Store the appliance indoors in a cool, dry place.

2. Package Contents

Verify that all items are present and in good condition upon opening the package.

- Techwood TAN-6055 Portable Spot Cleaner
- 2-in-1 Nozzle Attachment
- Crevice Tool
- User Manual

3. Product Overview

Familiarize yourself with the components of your Techwood TAN-6055 spot cleaner.



Figure 3.1: Front view of the Techwood TAN-6055 Portable Spot Cleaner, showing the main unit, handle, two tanks, and attached hose with a cleaning head.



Figure 3.2: The spot cleaner demonstrating its multi-surface cleaning capabilities for carpets, cushions, vehicle interiors, and stairs, powered by a 600W motor.



Figure 3.3: Close-up view emphasizing the 600W power and the extra-large brush attachment for efficient stain removal.

Key Components:

- **Clean Water Tank (1.5 L):** For filling with water and cleaning solution.
- **Dirty Water Tank (0.85 L):** Collects extracted dirty water and debris.
- **Main Handle:** For carrying the unit.
- **Hose and Cleaning Head:** Flexible hose with an attached cleaning head for targeted stain removal.
- **Power Cord (4m):** For connecting to an electrical outlet.

- **Power Switch:** To turn the unit on/off.

4. Setup

Follow these steps to prepare your spot cleaner for use.

1. **Fill the Clean Water Tank:**
    - Remove the clean water tank from the unit.
    - Unscrew the cap and fill the tank with warm tap water (not exceeding 60°C) up to the 'MAX' line.
    - Add a small amount of approved carpet/upholstery cleaning solution as per the solution manufacturer's instructions. Do not overfill.
    - Securely replace the cap and reinsert the tank into the unit until it clicks into place.
2. **Attach the Cleaning Tool:**
    - Connect the desired cleaning tool (e.g., 2-in-1 nozzle or crevice tool) firmly to the end of the hose until it locks.
3. **Prepare the Area:**
    - Remove any loose dirt or debris from the area to be cleaned.
    - Test the cleaning solution on an inconspicuous area of the surface to ensure colorfastness.
4. **Plug In:**
    - Unwind the 4-meter power cord and plug the unit into a suitable electrical outlet.

5. Operating Instructions

Follow these steps for effective stain removal.

1. **Turn On the Unit:**
    - Press the power switch to turn on the spot cleaner. The unit will begin to operate.
2. **Apply Solution and Scrub:**
    - Hold the cleaning tool over the stained area.
    - Press the trigger on the cleaning tool handle to spray cleaning solution onto the stain.
    - Gently scrub the stain with the brush on the cleaning tool. For stubborn stains, allow the solution to soak for a few minutes.
3. **Extract Dirty Water:**
    - Release the spray trigger.
    - Tilt the cleaning tool slightly and pull it slowly over the wet area to suction up the dirty water and solution.
    - Repeat this process until the stain is removed and the water being extracted appears clean.
4. **Rinse (Optional):**
    - For best results, you may rinse the area by filling the clean water tank with only clean water (no solution) and repeating step 5.2 and 5.3.
5. **Turn Off and Unplug:**
    - Once cleaning is complete, press the power switch to turn off the unit.
    - Unplug the power cord from the electrical outlet.

6. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the life of your appliance.

1. **Empty and Clean Dirty Water Tank:**
    - Remove the dirty water tank from the unit.
    - Carefully pour out the dirty water into a sink or drain.
    - Rinse the tank thoroughly with clean water.
    - Allow the tank to air dry before reinserting it into the unit.
2. **Clean Cleaning Tools:**
    - Disconnect the cleaning tool from the hose.
    - Rinse the tool under running water to remove any debris or residue.
    - Ensure the nozzle opening is clear.
    - Allow to air dry.
3. **Wipe Down the Unit:**
    - Wipe the exterior of the spot cleaner with a soft, damp cloth.
    - Do not use harsh chemicals or abrasive cleaners.
4. **Store the Appliance:**
    - Store the spot cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
    - Ensure the power cord is neatly wrapped.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on	Not plugged in; Power outlet not working; Power switch off	Ensure unit is securely plugged in; Test outlet with another appliance; Press power switch to ON position
No spray or low spray	Clean water tank empty; Tank not seated correctly; Nozzle clogged; Spray trigger not pressed	Refill clean water tank; Re-seat tank firmly; Clean nozzle; Ensure spray trigger is fully pressed
Poor suction	Dirty water tank full; Tank not seated correctly; Hose/nozzle clogged; Tank lid not sealed	Empty dirty water tank; Re-seat tank firmly; Clear any blockages in hose/nozzle; Ensure dirty water tank lid is properly sealed
Water leak from unit	Tanks not properly seated; Tank caps not secured; Damaged seal	Ensure both clean and dirty water tanks are correctly seated; Verify tank caps are tightly closed; If problem persists, contact customer support for inspection of seals.

8. Specifications

Brand	Techwood
Model Number	TAN-6055
Power	600W
Clean Water Tank Capacity	1.5 Liters
Dirty Water Tank Capacity	0.85 Liters
Product Dimensions (L x W x H)	37.8 x 34.1 x 37 cm
Item Weight	4.64 kg
Power Cord Length	4 meters
Color	Black
Country of Origin	China

9. Warranty and Support

This Techwood appliance is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts availability, or warranty claims, please contact your retailer or the official Techwood customer service. Keep your proof of purchase for warranty validation.

Spare parts are generally available for 5 years from the date of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQYYPQWG

More documents and user manuals: **https://manuals.plus/**