Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYO JT-01

JOYO JT-01 Clip-on Chromatic Tuner User Manual

Model: JT-01 | Brand: JOYO

Introduction

The JOYO JT-01 Clip-on Chromatic Tuner is a versatile and easy-to-use device designed for accurate tuning of various string instruments. Its compact design, clear display, and multiple tuning modes make it an essential tool for musicians of all levels. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

What's in the Box

- JOYO JT-01 Clip-on Chromatic Tuner
- CR2032 Lithium Battery (1 included)
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your JOYO JT-01 tuner:



Figure 1: JOYO JT-01 Tuner with labeled components. The display shows tuning information, with a button below for operation. The tuner is attached to a clip via an adjustable axis.

- **Display:** Shows note name, tuning accuracy, and mode.
- **Power/Mode Button:** Long press to power on/off, short press to cycle through tuning modes.
- **Clip:** Attaches the tuner securely to your instrument's headstock.
- **Axis:** Allows for 360-degree rotation and 90-degree adjustment of the display for optimal viewing.

Setup

1. Battery Installation

The JOYO JT-01 tuner uses one CR2032 lithium battery. A battery is included with your purchase.



Figure 2: Battery installation process. Twist the battery compartment cover to open, insert the CR2032 battery with the positive (+) side facing up, and close the cover securely.

1. Locate the battery compartment on the back of the tuner.
2. Twist the battery cover counter-clockwise to open it.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Replace the battery cover and twist clockwise to secure it.

2. Attaching the Tuner

The tuner's clip is designed to securely attach to the headstock of your instrument.



Figure 3: The JOYO JT-01 tuner securely clipped to a guitar headstock, displaying a green 'E' for an in-tune E string.

1. Open the clip by pressing the two ends together.
2. Attach the tuner to the headstock of your guitar, bass, ukulele, or violin. Ensure it is firmly in place but not overly tight to avoid damaging the instrument.
3. Adjust the display angle using the axis for optimal visibility. The tuner allows for 360-degree rotation and 90-degree tilt.

Operating Instructions

1. Power On/Off

- **To Power On:** Long press the Power/Mode button for 2 seconds.
- **To Power Off:** Long press the Power/Mode button for 2 seconds.
- **Automatic Shut-off:** The tuner will automatically power off after 5 minutes of inactivity to conserve battery life.

2. Mode Selection

Short press the Power/Mode button to cycle through the available tuning modes:

- **C (Chromatic):** Tunes to any note.
- **G (Guitar):** Tunes specifically for guitar.
- **B (Bass):** Tunes specifically for bass.
- **V (Violin):** Tunes specifically for violin.
- **Uc (Ukulele C):** Tunes specifically for ukulele in C tuning.
- **Ud (Ukulele D):** Tunes specifically for ukulele in D tuning.

3. Tuning Process

Once the tuner is attached and the correct mode is selected, pluck a single string on your instrument.

Figure 4: Tuner display indicating a flat note. The needle is to the left, and the screen is blue.



Figure 5: Tuner display indicating a sharp note. The needle is to the right, and the screen is blue.



Figure 6: Tuner display indicating an in-tune note. The needle is centered, and the screen is green.

- The display will show the note name and a needle indicator.
- If the note is flat, the needle will point to the left, and the screen will be blue. Tighten the string.
- If the note is sharp, the needle will point to the right, and the screen will be blue. Loosen the string.
- When the note is in tune, the needle will be in the center, and the screen will turn green.

4. Official Product Video

Watch this official product video for a demonstration of the JOYO Clip-on Tuner in action.

Video 1: A short demonstration of the JOYO Clip-on Tuner (JT-01) being used to tune a guitar, bass, and ukulele. The video highlights the ease of use and the clear display indicators.

Features

- **Highly Sensitive:** Ensures accurate tuning even in noisy environments.
- **Wide Tuning Range:** Supports OA (27.5Hz) to 8C (4186.01Hz).
- **Clear LCD Digital Display:** Easy to read with color-changing indicators (blue for flat/sharp, green for in-tune).
- **360-Degree Rotatable Screen:** Allows for flexible viewing angles.
- **Multi-Instrument Support:** Compatible with guitar, bass, ukulele, and violin.
- **Automatic Shut-off:** Powers down after 5 minutes of inactivity to save battery.
- **Durable Construction:** Made from environmentally friendly ABS plastic.

Specifications

Specification	Detail
Model Number	JT-01
Tuning Range	0A (27.5Hz) - 8C (4186.01Hz)
Tuning Modes	Chromatic, Guitar, Bass, Violin, Ukulele (C/D)
Power Supply	1 x CR2032 Lithium Battery (included)
Automatic Shut-off	5 minutes
Material	ABS Plastic
Item Weight	3.87 ounces
Package Dimensions	4.17 x 3.31 x 1.3 inches

Maintenance

- **Battery Replacement:** Replace the CR2032 battery when the display becomes dim or the tuner's response is slow. Follow the battery installation steps in the Setup section.
- **Cleaning:** Wipe the tuner with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the tuner in a dry place away from extreme temperatures and direct sunlight when not in use.

Troubleshooting

- **Tuner not powering on:** Check if the battery is correctly installed with the positive (+) side up. Replace the battery if it is depleted.
- **Inaccurate tuning:** Ensure the tuner is securely clipped to the instrument's headstock. Verify that the correct tuning mode (e.g., Guitar for guitar) is selected. Tune in a quiet environment to minimize interference.
- **Display is dim:** Replace the CR2032 battery.

Warranty & Support

For warranty information or technical support, please refer to the contact details provided by your retailer or visit the official JOYO

website. Keep your purchase receipt as proof of purchase.

© 2023 JOYO Technology Co.,LTD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQZPNHP9

More documents and user manuals: **https://manuals.plus/**